



4AO INSTALLATION GUIDE



1. Connect board to power transformer.
2. Connect 4AO to the RS485 I/O Network.
3. Set the network address on the first five rockers of dip switch S1.
4. Set the network baud rate using rockers 6 and 7 of dip switch S1.
5. Set RS485 termination jumpers UP if at either end of a daisy chain. Otherwise, set jumpers DOWN.

Note: If you change any dip switch settings while the board is powered, disconnect the power and re-power the board to reset



This sheet is intended for use as a quick reference only. All installation technicians should read the installation and operation manuals for their CPC control systems for complete information. A list of these manuals and their CPC part numbers is given below:

026-1102 RMCC Manual
026-1601 Einstein RX Manual

026-1103 BEC Manual
026-1602 Einstein BX Manual

026-1105 BCU Manual