

roof as a closed input

nvFault as normally open


Pin	On/Off Inputs	Pin	On/Off Inputs
1	12V	16	12V
2	12V	17	12V
3	12V	18	12V
4	12V	19	12V
5	12V	20	12V
6	12V	21	12V
7	12V	22	12V
8	12V	23	12V
9	12V	24	12V
10	12V	25	12V
11	12V	26	12V
12	12V	27	12V
13	12V	28	12V
14	12V	29	12V
15	12V	30	12V

annual off

not be taken out of ove

or reset the rack contr
(2.5 volts) cycling betwe

the side of the module for
status screen and clear



Copeland Digital Scroll Analog Unloader



Step 1 Gear Icon  Config. → Refrigeration → Suction, Invt_Sensitivity

Step 2 Down page, highlight 10, and double-click to set at 2.4

