

RC-1000
REFRIGERATION CONTROL
OPERATIONS AND INSTALLATION MANUAL
VERSION 5.2
RELEASE : 2/1/93

ATTENTION

We strongly recommend that you read the RC-1000
installation manual before installing this unit.

Pages 19 through 27 concentrate on Installation

**ALWAYS REMOVE POWER FROM THE
REFRIGERATION SYSTEM PRIOR TO
INSTALLING THE RC-1000**

TABLE OF CONTENTS

<u>CHAPTER 1 - USER ORIENTATION</u>	1
INTRODUCTION	1
RC-1000 HARDWARE SYSTEM OVERVIEW	2
POWER SOURCE	2
CPU BASE UNIT	2
CPU Board	3
LCD and Rubber Keypad	4
Sixteen-Position Card Cage and Snap Track	5
Backup Battery	6
I/O MODULE KITS	6
Relay Driver Module	7
Relay Board	8
Analog Input Modules	9
Digital Input Module	11
Analog Output Module	12
RC-1000 SOFTWARE CAPABILITIES OVERVIEW	13
CIRCUITS - TEMPERATURE/DEFROST CONTROL	13
RACKS - SUCTION/HEAD PRESSURE CONTROL	14
REFRIGERANT LEAK MONITORING	15
LOGIC STATEMENTS	15
LOGGING	15
COMMUNICATIONS	15
ALARMING	16
THE RC-1000 CHANNEL NUMBERING SYSTEM	17
THE WINDOW/PAGE APPROACH TO USER INTERFACE	18
<u>CHAPTER 2 - INSTALLATION INSTRUCTIONS</u>	19
MOUNTING AND POWER CONNECTION	19
UNPACKING	19
I/O WIRING	20
RELAY BOARDS	21
SYSTEM POWER CONNECTION	21
INSTALLING AND INTERFACING TO I/O MODULE KITS	22
TERMINATION BOARDS	22
SWITCH BLOCK	22
MAKING CABLES	24
INSERTING I/O MODULE CARDS INTO CARD CAGE	25
COMMUNICATION CONNECTIONS	26
MODEM SWITCH SETTINGS	27
<u>CHAPTER 3 - PROGRAMMING AND INTERROGATING THE RC-1000</u>	29
RC-1000 DATA ACCESS AND DATA ENTRY	30
RC-1000 MENU FLOWCHART	32
RC-1000 MENUS, SCREENS, AND RELATED DATA FIELDS	33
RC-1000 INITIAL TITLE SCREEN	33
NOTE ON ACCESS CODES	33
RC-1000 TITLE SCREEN	34
RC-1000 MAIN MENU	35

CIRCUIT MENU	35
Circuit Status Screen	36
Circuit Setpoints Screen	39
Circuit Overview	43
Circuit Defrost Map Screen	44
Circuit Sensor/Names Menu	44
Circuit Name Screen	45
Circuit Sensor Name Screen	46
Circuit Configuration Screen	47
RACK MENU	51
Rack Status Screen	52
Rack Setpoint Menu	54
Rack Setpoint Screen	55
Desuperheater Setpoint Screen	62
Monitor Setpoint Screen	62
Rack Overview Screen	63
Rack Name Screen	63
Rack Sensor Name Menu	64
Rack Sensor Names Screen	64
Monitor Sensor Names Screen	65
Rack Configuration Screen	66
AUX FUNCTIONS MENU	70
Leak Detect Menu	70
Leak Detect Status Screen	70
Leak Detect Setpoint Screen	71
Leak Detect Overview Screen	71
Leak Detect Group Names Screen	72
Leak Detect Sensor Names Screen	72
Leak Detect Configuration Screen	73
Logic Statement Menu	74
Logic Statement Status Screen	74
Logic Statement Setpoint Screen	75
Logic Statement Name Screen	80
Logic Statement Clear Latch Screen	80
Logic Statement Sensor Name	81
Logic Statement Configuration Screen	81
OVERVERRIDE MENU	82
Temp Control Override Screen	82
Alarm Override	83
Override Log	83
Digital Output Override Screen	84
Digital Input Override Screen	85
Sensor Input Offset Screen	86
LOG MENU	87
RUN TIME LOGS MENU	87
Circuit Log Screen	87
Rack Log Screen	88
Note Log Screen	89
Alarm Log Screen	90
Event Log Screen	90
POWER LOG MENU	91
Hourly Power Log Screen	91
Daily Power Log Screen	92

I/O LOG MENU	93
I/O Log	93
EMERGENCY DEFROST SCREEN	94
SYSTEM MENU	94
Date & Time Screen	95
Daylight Savings Screen	95
Alarm Dial Out Menu	95
Alarm Phone Numbers Screen	96
Alarm Setup Screen	98
Circuit Alarm Setup Screen	99
Rack Alarm Setup Screen	100
Leak Detect Alarm Setup Screen	101
Logic Statement Alarm Setup Screen	102
System Alarm Setup Screen	103
Dial Log Screen	104
Miscellaneous Dial Out Screen	105
I/O List Menu	107
Analog Input List Screen	107
Analog Output Screen	108
Digital Input List Screen	109
Digital Output List Screen	110
Access Codes Screen	111
System Configuration Menu	112
Miscellaneous Parameters Screen	112
Temp Board Configuration Screen	114
Master Clear Screen	114

CHAPTER 4 - TROUBLESHOOTING 115

MASTER CLEAR PROCEDURES	115
RC-1000 POWER	116
TEMPERATURE SENSORS	116
PRESSURE TRANSDUCERS	117
RELAY BOARD	118
RC-1000 TROUBLESHOOTING GUIDE	119
CIRCUIT SETPOINT DEFINITIONS	123
RACK SETPOINT DEFINITIONS	129
SENSOR VOLTAGE CONVERSION TABLES	136
Table 1: % RH to Voltage	136
Table 2: Foot Candle to Voltage	137
Table 3: Pressure to Voltage (SA-100)	138
Table 4: Pressure to Voltage (SA-500)	139
Table 5: Dewpoint to Voltage (DR to W)	144
Table 6: Dewpoint to Voltage (DP to W)	145
Table 7: Temperature to Voltage (TP-1)	146

APPENDIX A: WARRANTY AND REPLACEMENT PARTS 149

WARRANTY	151
RC-1000 REPLACEMENT PARTS LIST	153
REPAIR PROCEDURE	155

Field Wiring Reference Guide
 Programming Worksheets (copy as needed)

Figure 1	Relay Interface Diagram
Figure 2	Variable Speed Compressor Interface Diagram
Figure 3	Analog Input Interface Diagram
Figure 4	Mounting and Power Hookup Diagram
Figure 5	CPU and I/O Power Hookup Diagram(TF-4)
Figure 6	Phone Cable Assembly
Figure 7	Rack Power Monitoring Hookup Diagram
Figure 8	Sample Layout Configuration
Figure 9	Store Communications Hookup Diagram
Figure 10	PC Direct Communications Diagram
Figure 11	Store Communications Hookup w/COM-99 Diagram
Figure 12	Inverter Interface Diagram (Toshiba)
Figure 13	Inverter Interface Diagram (Yasgowa 616G, Safetronics 616G, Lancer GPP502)
Figure 14	Relay Board Power Hookup Diagram(TF-5)
Figure 15	Recommended RC-1000 Power Hookup Diagram
Figure 16	Refrigerant Leak Sensor Hookup Diagram
Figure 17	PC Direct Communications w/COM-99 Diagram
Figure 18	Typical Case Temp. Sensor Installation
Figure 19	High Voltage to Dry Contact Interface Diagram
Figure 20	Block Diagram of Typical Energy Mgmt. System
Figure 21	RA-2 Alarm Panel Hookup Diagram
Figure 22	Mounting Diagram (OEM Version)
Figure 23	Liquid Level Hookup Diagram (0-10 VDC)
Figure 24	CPU communications ID switch location.
Figure 25	Refrigerant Leak Transducer Hookup Diagram
Figure 26	12 VAC Power Supply
Figure 27	Watt Transducer Connection Diagram (A-12080, A-12081)
Figure 28	Watt Transducer Connection Diagram (A-12083, A-12084)
Figure 29	Liquid Level Hookup Diagram (0-5 VDC)

CHAPTER 1 - USER ORIENTATION

INTRODUCTION

The RC-1000 is a microprocessor-based system designed to control virtually all parameters of a commercial refrigeration system. It can be used as either a wall-mounted or rack-mounted control. The state-of-the-art hardware and software combine to provide advanced control strategies and I/O flexibility. This is accomplished within a non-intimidating, user-friendly environment that is uncommon to other units of similar capability.

ABOUT THIS MANUAL

You are **STRONGLY ENCOURAGED** to read this **ENTIRE** manual prior to installing and operating the RC-1000.

IF YOU WANT

THEN READ

To learn about the RC-1000's capabilities.	Chapter 1 - USER ORIENTATION
To become familiar with the RC-1000 user interface.	Chapter 1 - USER ORIENTATION
To install and label an RC-1000.	Chapter 2 - INSTALLATION INSTRUCTIONS
To install and label any of the RC-1000 I/O Module Kits.	Chapter 2 - INSTALLATION INSTRUCTIONS
To learn how to enter setpoints and assign sensors and outputs.	Chapter 3 - PROGRAMMING AND INTERROGATING THE RC-1000
To diagnose a problem with the RC-1000.	Chapter 4 - TROUBLESHOOTING GUIDE
To obtain part numbers for replacement parts.	Appendix A - WARRANTY AND REPLACEMENT PARTS
Installation diagrams for probes, inverters, etc.	Appendix B - INSTALLATION DRAWINGS

RC-1000 HARDWARE SYSTEM OVERVIEW

The RC-1000 system is comprised of a power source, a CPU Base Unit, and up to sixteen plug in I/O (Input/Output) module kits. The RC-1000 is UL Listed and CSA approved in both the cabinet enclosure and the OEM style panel. (UL number 4L53, CSA number LR 89864)

POWER SOURCE

The RC-1000 CPU Board, I/O Modules, and Relay Boards require two (2) separate 12 VAC sources. If desired, the customer can supply the power sources, or obtain them from EIL. EIL offers a power source: model TF-5 transformer. The transformer is pre-wired with color coded wire terminations.

The TF-5 when used for the CPU Board and I/O Modules, provides a dual voltage primary and produces an isolated 12 VAC secondary output. The TF-5 can be powered by 120 VAC or 240 VAC (208V) sources. (see Figures 5 and 14) The primary of the transformer should be wired through a 5A max circuit breaker. The CPU board is fused at 2 amps.

The TF-5 when used for the relay boards, can power up to eight relay boards. The TF-5 provides a dual voltage primary and produces one isolated 12 VAC secondary output. The TF-5 can be powered by 120 VAC or 240 VAC (208V) sources (see Figures 5 and 14). Each relay board is fused at one amp.

CPU BASE UNIT

The CPU Base Unit consists of a sturdy enclosure that houses the CPU (Central Processing Unit) Board, a four-line, forty-character wide (4x40) LCD (liquid crystal display), a keypad, a sixteen-position card cage to receive I/O Modules (described later), and a snap track for mounting the Termination Boards packaged with each I/O Module kit. The door contains a keyed latch and is removable from the enclosure for ease of installation, wiring, and maintenance. Conveniently placed knockouts provide pilot holes for conduit fittings used during installation. Listed are some features of the components contained within the CPU Base Unit:


CPU Board - This compact design features a state-of-the-art V40 microprocessor that can address up to 1MB (one megabyte) of memory. The RC-1000 currently uses 128K bytes (one hundred twenty eight kilobytes) of RAM (Random Access Memory) and 128K bytes of ROM (Read-Only Memory). An expanded RAM option is available that will add another 128K bytes. (see parts list for part number) A watchdog timer circuit is provided to insure proper recovery from a processor lock-up. The system I/O interface is achieved with an optically coupled, twenty-pin data bus that isolates the processor circuitry from electrical noise present in harsh environments. Both power and communications hookups are made on this board. The 8 position dip switch has several purposes. Switches 1 through 5 are for setting the unit ID as follows:

Unit 1	switch 1 closed
Unit 2	switch 2 closed
Unit 3	switch 3 closed
Unit 4	switch 4 closed
Unit 5	switch 5 closed
Unit 6	switch 1 + 5 closed
Unit 7	switch 2 + 5 closed
Unit 8	switch 3 + 5 closed

Dip switch 6 is used to set the remote baud rate setting. For 1200 baud, switch 6 should be open. For 2400 baud, switch 6 should be closed.


Switches 7 and 8 are not used on the current version of cpu and should remain open.

LCD and Rubber Keypad - Mounted on the RC-1000 door, these two components work together with the firmware to provide the smartest user interface on the market. An standard back lit display is supplied and uses power supplied from the cpu board power supply. The user responds to clear menu choices on each screen by using the number and arrow keys available on the keypad (refer to Chapter 3, Programming and Interrogating the RC-1000).




Keypad

Sixteen-Position Card Cage and Snap Track - Mounted on the back wall of the RC-1000 cabinet, these two components provide the mounting mechanism for interfacing the I/O module kits with the CPU Base Unit. Sixteen slots are available for plugging in any required combination of I/O cards. Off-center connectors make it **impossible** to plug in the cards incorrectly. All I/O card types except the Relay Driver connect to I/O Termination Boards that mount on the snap track below the card cage. This provides terminal strips for connecting the RC-1000 I/O to the various types of sensors and loads. Up to ten of these boards can fit on the snap track at one time. If additional termination boards are required, they can be mounted in an expansion cabinet.



Card Cage and Termination Boards

Backup Battery - Each RC-1000 is supplied with a 3VDC Lithium battery that is U.L. approved for installation in electronic equipment. The battery is located near the top-middle of the CPU Board and is mounted in a holding clip. The battery is sufficient to retain all data (setpoints, etc.) for a minimum period of one year when the RC-1000 loses power. The life expectancy of the battery is eight years under normal conditions. **The battery should only be replaced by a qualified technician. Consult the factory for battery replacement.**



Battery in Holding
Clip

I/O MODULE KITS

At present there are four basic types of I/O modules and one type of Relay Board. The I/O Modules and Relay Boards are packaged in "kits" containing all of the necessary parts and labels required for installation in the CPU Base Unit. In general, each module kit is installed and tested at the factory prior to shipment. The four existing types of I/O Module kits are:

- * Relay Driver Module
- * Analog Input Modules (4 types: Temperature, Pressure, 0-10V and thermistor.)
- * Digital Input Module
- * Analog Output Module


Each I/O Module provides either four or eight channels of input or output. The user can configure the RC-1000 with any combination of I/O Modules, provided that no more than eight modules of one type are installed, and the maximums of sixty-four inputs and sixty-four outputs are not exceeded. Also, it makes no difference which slot an I/O card is plugged into because each card contains an eight-position DIP (dual in-line package) switch that is used to identify it to the RC-1000's microprocessor (further information is provided in the section titled "Switch Block" in Chapter 2).

Relay Driver Module

Kit contains: Relay Driver Module
Mounting plate

Description: These I/O cards are the only cards with four connectors and eight LEDs (see figure below).

Connects to: Relay Board via four, six-conductor phone cables marked A,B,C, and D. Each module drives a single, eight-channel Relay Board. The A and B connectors are outputs (from the module) and the C and D connectors are feedbacks which indicate override status.




(further information on the phone cables is provided in the section titled "Making Cables" in Chapter 2).

Relay Board

Kit contains: Relay Board

Description: Relay Boards have eight relays, eight fuses, a 24-position terminal block, and eight control switches. It also has four modular quick-connect (phone cable) jacks.

Connects to: Relay Driver Module via four, six-conductor phone cables (refer back to the Relay Driver Module section). This board requires 12 VAC supply (specs are provided in Chapter 2: see Figure 1).



Relay Board

The Relay Board should be located in the rack control panel, as it is interfaced to the compressor and valve control circuits. Each Relay Board requires a 12 VAC external supply and is protected by a 1A fuse on the relay board. The Relay Boards contain eight individual DPST (double-pole, single-throw) relays. Terminals are provided for common (C-#), normally open (NO), and normally closed (NC) relay operations. All relays are fused at 3A, 240 VAC through the common terminal.

A three-position control switch is provided for each relay. The positions are marked "ENERG" (energized), "AUTO" (automatic or programmable), and "DE-ENERG" (de-energized). The positions "ENERG" and "DE-ENERG" override the RC-1000's control of the relay's state. When a relay is energized, either by the RC-1000 or the "ENERG" override, a red LED is lit, indicating that the relay coil is energized. A green LED is lit when the control switch is moved from the "AUTO" position to either of the two override positions. (On the new relay boards R8/12, a yellow led is lit indicating a relay is in override). Relay Driver Modules have eight red LEDs that correspond directly with the red LEDs on the Relay Boards.

Analog Input Modules

There are four types of Analog Input Modules: Temperature, Pressure, Thermistor and 0-10V.


Kit contains: Required Analog Input Module
Mounting plate
Termination Board
Two ten-inch, six-conductor phone cables

Description: No Analog Input Modules have LEDs.
Most Analog Input Modules have five test points and four calibration potentiometers (see figure below).
Temperature Boards have transistors next to the phone connectors (see ID area in figure below).
Pressure Boards have no transistors in the ID area.
0-10V Boards have resistors in the ID area.

The standard temperature module ranges from -30° to 97° . A specially calibrated high temperature module is available which ranges from 0° to 255° . This hi-temp module must be set up during Unit System Configuration.

There are two style of thermistor boards available. One is for use with 2.2k thermistors and the other is for use with 10k thermistors. The operation of these cards are transparent to the user and no special setup is required.

Connects to: The two phone cables supplied in the kit connect to the Termination Board. Termination Boards are mounted in the PCB track located below the card cage. When the Analog Input Module is installed in the card cage, the phone connectors on the card plug into the respective phone connectors on the Termination Board (top to top, bottom to bottom, see Figure 3).



Analog Input Modules provide for eight channels of input from temperature sensors (EIL TP-1s), thermistors, pressure transducers (EIL SA-100s and 500s), watt transducers, and other standard measurement devices. The Pressure and 0-10v termination Boards supply 12 VDC for use with sensors. The 0-10V Board accepts 0-10 VDC or 0-1 mA (milliampere) input. Possible uses are for refrigerant liquid level monitoring, variable speed compressor frequency and current feedback. Figure 3 shows a typical RC-1000 analog temperature input and pressure transducer hookup. Figure 7 shows an EIL watt transducer hookup. Figure 16 shows an EIL refrigerant leak sensor unit hookup. Figure 23 shows a liquid level gauge hookup.


A High Temperature Analog Input module will have a cover plate labeled "HI-TEMP".

Digital Input Module

Kit contains: Digital Input Module
Mounting plate
Termination Board
Two ten-inch, six-conductor phone cables

Description: This module has two phone connectors and eight LEDs. There are very few components on this board (approximately three chips).

Connects to: The two phone cables supplied in the kit connect to the Termination Board. Termination Boards are mounted in the PCB track located below the card cage. When the Digital Input Module is installed in the card cage, the phone connectors on the card plug into the respective phone connectors on the Termination Board (top to top, bottom to bottom).




The Digital Input Module provides eight channels of digital input (**dry contact closures**) such as defrost termination, defrost initiation, phase-loss alarm, proof of run verification, or any other digital input supported by the RC-1000 firmware. Eight red LEDs are provided that light when the respective inputs are active. Figure 19 shows a high voltage to dry contact digital input connection diagram.

Analog Output Module

Kit contains: Analog Output Module
Mounting plate
Termination Board
Two ten-inch, six-conductor phone cables

Description: This board has one or two phone connectors and no LEDs. However, unlike the Analog Input Module, this board has no test points or calibration potentiometers.

Connects to: The two phone cables supplied in the kit connect to the Termination Board. Termination Boards are mounted in the PCB track located below the card cage. When the Analog Output Module is installed in the card cage, the phone connectors on the card plug into the respective phone connectors on the Termination Board (top to top, bottom to bottom).



Each Analog Output Module provides eight channels for sending 0-10 VDC control signals to other control systems such as DC Inverters (for variable speed compressors). This 0-10 VDC output is connected to the inverter via a Termination Board (see Figure 2). See figures 12 and 13 of the appendix section of this manual for examples of two inverter interface diagrams.

RC-1000 SOFTWARE CAPABILITIES OVERVIEW

The control software of the RC-1000 is divided in three functional groups: **CIRCUITS, RACKS and AUX FUNCTIONS.** The CIRCUITS area contains software for controlling the temperature and defrost in the case line-ups. The RACKS area contains software for controlling the suction and head pressure on commercial refrigeration systems. The AUX FUNCTIONS area provides the REFRIGERANT LEAK MONITORING and LOGIC (Boolean) STATEMENTS. Other miscellaneous software capabilities include LOGGING, COMMUNICATIONS, and ALARMING.

A brief list of the control strategies that come standard with the RC-1000 follows. (Chapter 3 will cover this area in complete detail)

CIRCUITS - TEMPERATURE/DEFROST CONTROL

This software group will control up to 32 individual circuits, supporting time or temperature termination, digital termination, demand defrost initiation, and programmable hot-gas relay outputs. Included also are refrigeration and runoff time delays, high and low alarm setpoints, and defrost skipping on dewpoint. Up to six defrost times are available per day.

Each CIRCUIT and SENSOR can be given a name (or description) up to 34 characters long. Both the input sensors and output relays are programmable for ultimate flexibility in meeting each individual installation's requirements. A simple configuration section allows the user to add or subtract features. This feature will be discussed more fully later, but the result is that if certain features are not used, the various screens do not contain needless references to them.

Other features included are:

- Suction and/or liquid line solenoid control by temperature.
- Industrial hot gas defrost control strategy:
 - pump out phase
 - defrost phase
 - equalize phase
- Individual case defrost control.
- Defrost restart control option.
- Temperature dead band.

RACKS - SUCTION/HEAD PRESSURE CONTROL

This software group will control Suction and Head pressure on up to 4 racks (i.e. individual suction pressures). Extensive research has yielded an advanced new algorithm (software decision making process) that requires only cut-in and cut-out setpoints, the actual capacities of the motors (usually rated in horsepower, or B.T.U), a control gain, and a few anti-short cycle time delays. Built into the algorithm is the ability to optimize run-time on virtually any type of RACK, even those with uneven capacity compressors. The same algorithm is used for condenser fan control. For both Suction and Head control, alternating or sequential cycling is available. The strategy also includes the ability to control variable speed compressors, either alone, or in tandem with the standard motors. (Much more on this strategy will appear in Chapter 3)

Other features included are:

- Temperature Compensation of the suction setpoints by automatically referencing the most critical CIRCUITS.
- Digital inputs that activate auxiliary suction and/or head setpoints.
- Digital inputs for phase loss, liquid level, oil failure, defrost sensing, and run verification.
- Oil pressure input for variable speed compressors (used to monitor pressure against user-defined minimum differential pressure, alarm and take action on failure).
- Head pressure control via temperature differential. Condenser fans cycle based on ambient temperature, with upper and lower pressure control limits.
- Two stage interlocking of racks. (ie: lock-out the low temperature rack if the medium temp rack compressors are not running.
- Additional monitor only points for up to 8 temperature sensors, 8 pressure sensors, 4 relays, 4 digital inputs and 1 analog input per rack.
- Desuperheater control based on manifold temperatures.
- High head pressure override of compressors.

As in the CIRCUIT software, each RACK and SENSOR can be given a name (or description). Each Rack description can be up to 16 characters long, and each Sensor description can be up to 24 characters long. Both the input sensors and output relays are

programmable for ultimate flexibility in meeting each individual installation's requirements. A simple configuration section allows the user to add or subtract features. This feature will be discussed more fully later, but the result is that if certain features are not used, the various screens do not contain needless references to them.

REFRIGERANT LEAK MONITORING

The RC-1000 can provide four systems for refrigerant leak monitoring. Each system can monitor either one digital contact or three analog inputs from a remotely located leak detector. Each analog input can have a separate alarm setpoint.

LOGIC STATEMENTS

Logic statements are used to design a custom control system based on a variety of input and output configurations. Basic operation is based on 'If ..., Then ...' decisions.

The RC-1000 provides a maximum of thirty-two logic statements. These statements can be 'stand alone system control' or used to supplement existing control of CIRCUIT or RACK loads. Loads can be put into a software override condition at any time. When a load is returned to its normal system control, it assumes the state called for by the current logic statement control.

LOGGING

The RC-1000 automatically logs all analog inputs, all digital outputs (Relay Driver), and all analog outputs that are assigned. A logging interval must be used to have this information available. The default interval is 180s. This logging information is available from a remote computer via graphs, or at the unit via a tabular data format. These logs are classified as interval logs. In addition, the RC-1000 logs power/demand consumption, run-times, and cycles. This information is accessible on site or remotely for analysis of overall system performance.

COMMUNICATIONS

Each RC-1000 includes a dual serial port which allows for connection to any Hayes-compatible telephone modem rated for 1200 or 2400 baud. All RC-1000 units in the facility can be "daisy chained" together (see Figure 9 + 11) to create a local network accessible either on site or remotely with a "dumb terminal" or EIL's CNET terminal software package. This package features high resolution graphics and state-of-the-art user interface technology.

ALARMING

Virtually all measured inputs can be compared against user defined setpoints for the purpose of alarming. All alarms are listed in the alarm log, and can be "sent out" via system relays or dial out capability through the modem. As is the case throughout this system, the user has complete flexibility in selecting how many and which relays will be used for this purpose. Additionally, all major alarm types can either be enabled or disabled for dial out activity. Each circuit, rack, refrigerant leak group and logic statement has individual control of the dialout parameters. Alarms can be sent to a local dumb terminal and up to 6 occupied phone numbers and 6 unoccupied phone numbers. Daily out tests are provided up to twice per day. All dial outs are logged whether successful or not.

THE RC-1000 CHANNEL NUMBERING SYSTEM

Due to the relatively large number of inputs and outputs the RC-1000 can control (64 analog inputs, 64 analog outputs, 64 digital inputs and 64 digital outputs), a special channel numbering convention has been adopted.

Each input or output module may contain at most eight channels. There can be up to a total of eight modules of any one specific type, each numbered one to eight according to their switch block setting (refer to the section titled "Switch Block" in Chapter 2). The numbering convention is defined as follows:

Each channel number contains two digits separated by a dash ("-"). The first digit indicates which module the channel can be found on, and the second digit indicates the actual channel number on that module. For example, digital input channel 6-5 would correspond to the fifth channel on the sixth Digital Input Module.

This channel numbering convention is consistent throughout the RC-1000 environment, including channel references found on hardware labels, firmware menus and screens, and within the remote communications software.

THE WINDOW/PAGE APPROACH TO USER INTERFACE

The 4x40 character LCD used by the RC-1000 presents a concise, organized view of system control and status information. The 'smart' numeric keypad makes programming and interrogating the RC-1000 quick and easy. However, in order to efficiently access the RC-1000's stored information, the user must have a general understanding of how the firmware organizes data.

A single user-accessible data item (such as a setpoint) is referred to as a **data field**. Related data fields are grouped into **screens**. In the event that a screen contains information concerning multiple circuits or racks, the screen will be subdivided into a series of **pages**. Screens are then grouped into **menus**, which are in turn placed into a tree-like hierarchy that begins with the RC-1000 Main Menu (refer to the diagram in the "Introduction" section of Chapter 3).

The RC-1000's LCD acts as a four line view port, or **window**, to a single page of RC-1000 information. By using the up arrow and down arrow keys, the user can move the four line window **vertically over the contents of a single page**, analogous to moving a magnifying glass down one column of the classified section in a newspaper. This action is referred to as **scrolling down a page**. Similarly, using the left arrow and right arrow keys, the user can move the four line window **horizontally from one page to the next**, like moving the magnifying glass over to an adjacent column. This action is referred to as **changing pages**. The user can also "jump" to a specific page by simply typing the appropriate page number (e.g. pressing the keys marked "0" and "8" would then display page number eight).

This type of intuitive approach is consistently adhered to throughout the RC-1000 firmware to keep keystrokes to an absolute minimum. When moving through menus, screens, pages, and data fields, the user can speed the process by holding down the desired arrow key, causing the action to be repeated until the key is released.

Note that when moving from page to page (column to column), the window **remains in the same relative position** on each page. For example, on the Rack Setpoint screen, the user can scroll down the page to the area showing relay assignments and view the relay assignments for **each** configured rack by simply changing pages. Further information regarding user interface specifics will be provided in Chapter 3.

CHAPTER 2 - INSTALLATION INSTRUCTIONS

MOUNTING AND POWER CONNECTION

UNPACKING

1. Remove the RC-1000 from its shipping container and verify that it has not been physically damaged. The I/O cards and cables are stored inside the cabinet prior to shipment.
2. You should receive:

RC-1000 Refrigeration Control Unit.
Requested order of I/O module kits.
This instruction manual.
Labels.
Ordered relay boards and cable.
Transformer and supply box assembly (if ordered).
3. Select a mounting area on the compressor rack system (uni-strut or other mounting base) or the compressor room wall. The preferred location would be near eye-level in the middle of the rack for easy viewing of the LCD.
4. Remove cables (shipped in plastic bags) from inside the RC-1000 cabinet. There are four mounting holes inside the cabinet: two between the I/O card cage and the snap track and two below the snap track (see Figure 4). Mount the unit securely with four 1/4-inch mounting screws. For OEM units refer to figure 22 for the mounting diagram. Mount the card cage such that the capacitors are toward the top of the card cage.

I/O WIRING

5. Determine the arrangement of I/O cards in the card cage that is best suited to the I/O wiring requirements. I/O cards can be inserted into any slot in the card cage. However, make sure that I/O cards of the same type have unique switch settings (further information is provided in the section titled "Switch Blocks" found later in this chapter). The I/O section must be de-powered prior to working with I/O cards. All cards should be handled with extreme care to avoid touching circuitry.
6. All sensor wires and analog outputs must be connected to Termination Boards mounted in the snap track below the card cage. Quick-connect cables connect the Termination Boards to the proper I/O cards. The Termination Boards are identical to each other, so it is not essential that they remain paired with a specific I/O Module. See Figures 2, 3, 7, 16 and 23. All connections to termination boards should be done with the interconnecting cables removed from the I/O cards.

RELAY BOARDS

7. RC-1000 Relay Boards are mounted inside the Rack Control Panel and also require a 12 VAC supply (see Figure 14). A TF-5 transformer should be used here.
8. Connect refrigeration and defrost control circuits to relay outputs in accordance with the manufacturer's specifications. Make connections to the terminal block below each relay. Note that each relay provides both normally open (NO) and normally closed (NC) connections along with a common (C-#) which is fused at 3A.
9. The relay boards are connected to the Relay Driver boards in the RC-1000 card cage via four, six-conductor cables matching the labeled socket letters (A to A, B to B, etc.; see Figure 1 & 4). Further information is provided in the section titled "Making Cables" found later in this chapter.

SYSTEM POWER CONNECTION


10. The shield plate (mounted with thumb screws) attaches to the cabinet door to protect the RC-1000 CPU Board. Notice the power switch, fuses, and terminal block in the lower right-hand corner (see Figure 4).
11. The RC-1000 requires one external 12 VAC, 2A (minimum) supply lines which are connected to the CPU Board's terminal block (see Figure 4). The input is fused on the CPU board. A 12 VAC transformer, TF-5, (described in Chap.1, 'Power Source' section) is available from the factory. The TF-5 can be powered from either 115 VAC or 230 VAC (208V) and provides one isolated secondary output (see Figure 5). It is preferred that the RC-1000 have its own circuit, either protected by a breaker or fuse.
12. Power-on the RC-1000 microprocessor by moving the slide switch found on the lower right-hand corner of the CPU Board, to the up position (see Figure 4). The I/O bus board and I/O cards (mounted on the bottom of the card cage) will receive power from the Microprocessor Board through this same switch.

INSTALLING AND INTERFACING TO I/O MODULE KITS

In general, I/O module kits are labelled and installed prior to shipment. Therefore, the following installation instructions are provided primarily as reference information.

TERMINATION BOARDS

Termination Boards are used simply to provide input/output connections between the I/O Modules (not the Relay Driver), dry contacts (digital inputs), sensors, and inverters for the Analog Output Module. The Termination Boards are assigned to one I/O Module and therefore are labelled with the same module number sticker. Connections between the I/O Modules and the Termination Board are made via the six-conductor RJ-11 cables. Each Termination Board has eight input/output connections, eight common connections, and two 12 VDC supply connections (active only on the pressure and 0-10v modules)




Termination Board

SWITCH BLOCK

Each I/O module contains an eight-position switch block. The switch setting distinguishes its card number from other installed cards of the same type. Therefore, you can have up to eight cards of the same type (e.g. eight Relay Driver Modules) inserted in the sixteen-position card cage at one time. **DO NOT SET ANY MORE THAN ONE OF THE SWITCHES TO "ON" ("OFF" is OPEN).** The four card types are Relay Driver, Analog Input, Digital Input, and Analog Output. Note that there are up to four kinds of Analog Input cards for the RC-1000, but because they are all Analog Inputs, they must have different switch settings (e.g. you cannot insert both a Pressure Board and a Temperature Board if they have the same switch setting).

Once the switch settings are selected for the cards, the cards are inserted and the mounting plates secured. Since the switch block will normally be out of view once the card is installed, a number sticker is placed in the white square on the module's mounting plate to identify the module number (switch setting) during normal operation.




NOTE: Only one switch should be ON, the other seven should be set to OPEN.

Switch Block

MAKING CABLES

Many of the required field connections are made using six-conductor cables with modular, quick-connects (RJ-11 style) on each end. They are easily recognizable as "telephone cables". The main difference between these cables and those found on the standard house phone is that the RC-1000 cables have six conductors, while regular telephone cables have only four. This style was chosen for the same reasons used by the telephone industry -- they offer a high quality connection, are easy to use, are durable, and are inexpensive. In most cases, the installation will be completed using cables supplied by EIL. For custom cable lengths or repair, a Cable Termination Kit is available from the factory that contains a crimping tool and simple instructions for making these connections in the field. The standard cable assembly used by EIL is shown below and in Figure 6. A cable tester is available from EIL (p/n CC/60028400).

Note: White on Right rule - Cables manufactured at EIL are assembled with the white wire on right side of connector, as shown. If one end of cable needs to be shortened, make sure the proper orientation is maintained.




Cable Orientation

INSERTING I/O MODULE CARDS INTO CARD CAGE

Slide each I/O module card into the card cage (cage contains guides) until the card-edge seats into the connector on the bus board at the bottom of the cage. The card should be oriented with its components facing the left side of the cabinet. The cards fit correctly only in this orientation.

Caution: When handling an I/O Module, it is important to hold the card by the plastic phone jacks. Do not touch any of the board components or tracks because the boards are static-sensitive. The RC-1000 should always be de-powered before handling any I/O cards. Prior to removing I/O cards, remove adjacent mounting plates in order to prevent hitting static-sensitive components.



COMMUNICATION CONNECTIONS

The RC-1000 CPU board has two RJ-11 phone connectors used for serial communication. One connector is hooked to a modem and the other connector is used for communicating to other RC-1000's.

The necessary adapters are as follows:

For RC-1000s only:

- * RC/Modem Adapter EIL part # CC/01665400
This adaptor is used to connect a 25 pin RS232 port on the back of the modem to a 6 conductor flat phone cable that plugs directly into the CPU Board (see Fig. 9).

For RC-1000s with COM-99:

- * RC/COM-99 Adapter EIL part # CC/01665400
This adapter is used to connect a 25 pin RS232 port on the back of the modem to a 6 conductor flat phone cable that plugs into the COM Interface Board, marked "MODEM", found in the card cage of the #1 RC-1000 (see Fig. 10).

- * COM-99/RJ-11 Adapter EIL part # CC/01665401
This adapter is used to connect a 25 pin RS232 port on the left side of the COM-99 to a 6 conductor flat phone cable that plugs into the COM Interface Board, marked "COM-99" (see Fig. 11).

Misc. Adapters:

- * PC Direct Connect Adapter EIL part # CC/01664400 (25 pin) or CC/01682400 (9 pin)
This adapter is used to connect the RS232 com port on a computer directly to the com port on the RC-1000 using a standard 6 conductor flat phone cable. This adapter can only be used when plugged directly into the RC-1000 CPU.

When direct connection to the COM-99 Interface Board, an interface adapter is required. Use either EIL part # CC/01665400 (male) or EIL part # CC/01665401 (female), depending on the sex of the computer port.

MODEM SWITCH SETTINGS

EIL currently offers a Hayes Smartmodem 1200 and Hayes Optima 2400 baud external modem for each installation. The following modem switch settings should be set on the 1200 baud modem before attempting to communicate via modem:

In Field

Only RC-1000 in store	5,7, and 10 up
Only COM-99 in store	5,7, and 10 up
RC-1000 and Com-99	5,7, and 10 up

For the 2400 baud modem, the modem must be set up using a software package such as Procomm or Xtalk to communicate to the modem before installation. For modems to be installed in the field, the set up is as follows:

AT&K0&Q0S0=1&W

Modems provided by EIL should be set correctly for operation in the field.

Refer to appropriate manufacturer's manuals when using modems other than the Hayes Smartmodem 1200 or Optima 2400 baud external types. Refer to the Communications Connections section in this manual for hook-up and adapter information.

CHAPTER 3 - PROGRAMMING AND INTERROGATING THE RC-1000

INTRODUCTION

The hierarchical organization of the menus and screens throughout the RC-1000 firmware and in this manual is based on frequency of screen usage when the system is in operation (see chart below). However, programming the RC-1000 during installation should be done in the following sequence: 1) configuration screens, 2) setpoint screens, 3) names screens. Note that the RC-1000 is best programmed using CNET terminal software (available from the factory) with a remote PC or laptop computer.

Each menu or screen generally consists of a title line and one or more lines of text and data. For some screens, the title line consists of a page number and either a screen title or a user-defined identifier. If the screen consists of more than three data lines, all subsequent lines can be scrolled into view by pressing the up arrow or down arrow on the keypad. Any screen that can be scrolled is terminated by two rows of double asterisks to separate the first and last data lines.

In general, the position of the cursor, which indicates the current page, menu selection, or data field, is denoted by an "arrow" (">") symbol. If more than one page of information is available for a given screen, the cursor appears to the left of the page number when the screen or a new page is selected.

RC-1000 DATA ACCESS AND DATA ENTRY

Although the user interface of the RC-1000 was designed to be both easy to understand and simple to use, a quick reading of the following items is recommended to all new users of the RC-1000.

- To change menu selections or data fields, use the appropriate arrow keys to move the cursor around the menu or screen and press enter.
- To change menus, press the numeric key that corresponds to the number of the desired menu selection, or press the 'ENTER' key when the cursor is to the left of the number of the desired menu selection.
- To change pages (e.g. from CIRCUIT A01 to CIRCUIT A02), press the right or left arrow keys when the cursor is to the left of the page number.
- To enter the data portion of a programmable screen from the title line, press the 'ENTER' key; the cursor will appear to the left of the first programmable data field on the screen.
- To begin data entry for any selected field, press the 'ENTER' key; the arrow cursor will change to an underline, indicating that new data will be accepted.
- To enter data for numeric fields, press either the appropriate numeric keys or use the up and down arrow keys to advance each digit in the field to the desired value.
- To change position, use the left arrow and right arrow keys. To enter data for alphanumeric fields, press either the appropriate numeric keys or use the up arrow and down arrow keys to advance each character in the field to one of the following:

0 1 2 3 4 5 6 7 8 9 A B C D E F G H I J K L M N O P Q R
S T U V W X Y Z . , : # * ! / &

- To enter data for multiple-choice fields, use the up arrow and down arrow keys to cycle through the available choices.


- To complete your data entry for any field, press the 'ENTER' key; the cursor will reappear either at the next field or to the left of the current field.
- To leave a field without changing its value, press the 'EXIT' key.

Notes:

1. If more than one page of information is available for a particular screen, press the 'EXIT' key to return the cursor to the page number of the screen.
2. To cause a feature or setpoint to be unused on a RACK or CIRCUIT, simply set the input or output designation to channel number 0-0.

RC-1000 MENU FLOW CHART

Version 5.2



RC-1000 MENUS, SCREENS, AND RELATED DATA FIELDS

Presented in the following pages are examples of all the RC-1000 menus and screens, complete with brief explanations of their content and application.

RC-1000 INITIAL TITLE SCREEN

EIL RC-1000 SOFTWARE VERSION X.XX
*** CONTROL NOT CONFIGURED ***
Enter Access Code: _

The RC-1000 Initial Title Screen appears after the RC-1000 is powered-up, either during installation or after a total power failure (loss of both line and battery power). This screen will remain as the access screen until the number of racks or the number of circuits is set to a value greater than '00.' The Rack Configuration and Circuit Configuration screens must be programmed before any Setpoint or Status screens can be viewed (see the Rack Configuration Screen (pg. 49) and the Circuit Configuration Screen (pg. 40)).

You should become familiar with all of the menus, screens, and data fields of the RC-1000 prior to attempting to program your system.

NOTE ON ACCESS CODES

Special access codes are required to program your RC-1000. The factory settings for these access codes are 1234 (level-1) and 9876 (level-2); 'view-only' access (level-0) is granted when you do not enter a level-1 or level-2 access code. Once the RC-1000 has been installed and completely programmed, you should change the level-1 and level-2 access codes and give them only to people who are qualified to program your RC-1000.

Indicated under the individual screens in this manual are the access codes required to change a setpoint. When an access code is not entered, all screens except 'Rack Configuration', 'Circuit Configuration', 'Leak Detect Configuration', 'Logic Configuration' and 'Access Codes' can be viewed.

Entering a level-1 access code will allow the user to view and change the setpoints on all screens except 'Rack Configuration', 'Circuit Configuration', 'Leak Detect Configuration', 'Logic Configuration' and 'Access Codes'.

Entering a level-2 access code will allow the user to view and change the setpoints and I/O assignments on any screen. Once an access code is entered, the Initial Title Screen changes to the RC-1000 Main Menu; programming of the RC-1000 can now begin.

RC-1000 TITLE SCREEN

<p>EIL RC-1000 SOFTWARE VERSION X.XX</p> <p>Enter Access Code: _</p>
--

The RC-1000 Title Screen appears when keypad input to the RC-1000 has ceased for more than fifteen minutes or when the RC-1000 has recovered from a temporary loss of line power. When you enter an access code or press the 'ENTER' key, this screen changes to the RC-1000 Main Menu.

Note the version number of the installed firmware and be sure to reference it when discussing any questions or problems that concern your RC-1000 with an E.I.L. sales representative or engineer.

Once your RC-1000 has been programmed, it will be accessed primarily to review system status and performance information; for 'view-only' access, just press the 'ENTER' key. However, during maintenance or repair of your refrigeration control system, you may need access to certain programmable data fields. Remember to enter the access code that is appropriate for your programming needs. Level-1 access codes are required to changed setpoints only. Level-2 access codes are usually required for maintenance purposes, and should be avoided.

If an alarm condition occurs, this screen will also indicate "NEW ALARMS IN SYSTEM". This message will remain displayed until the alarm log is viewed either at the unit or remotely.

If the battery voltage falls below an acceptable level, this screen will indicate " * RAM BACKUP BATTERY IS LOW * ". The battery should be replaced. This message will be displayed until the battery voltage is returned to an acceptable range.

RC-1000 MAIN MENU

RC-1000 MAIN MENU	
1-Circuit Menu	4-Overrides
2-Rack Menu	5-Emergency Defrost
3-Aux Functions	6-System

Required Access Level: None.

The RC-1000 Main Menu appears after you have entered an access code and/or pressed the 'ENTER' key at either the RC-1000 Initial Title Screen or the RC-1000 Title Screen. This menu is a table of contents to the configuration and control functions of your system.

CIRCUIT MENU

CIRCUIT MENU	
1-Status	4-Defrost Map
2-Setpoints	5-Ckt/Snsr Names
3-Overview	6-Configuration

Required Access Level: None.

The Circuit Menu is selected from the RC-1000 Main Menu. It is a table of contents to the RC-1000's circuit configuration and control functions. If you intend to make any programming changes to screens on this menu, keep in mind that different levels of access are required by different data fields.

Circuit Status Screen

01 CIRCUIT A01				
Refr off	Temp	Term	Hi alarm	Lo alarm
Setpoint	-10F	65F	70F	-30F
Actual	-11F	-15F	-10F	-14F

Sensors:

Temp 3-4	FROZEN FOOD	-11F
Term 3-4	FROZEN FOOD	-11F
Alarm 3-1	-11 FROZEN FOOD	
Term 2-1	FROZEN FOOD DEF TERM	off
Init 2-2	FROZEN FOOD DEF INIT	off
	**	
	**	

Required Access Level: None.

The Circuit Status Screen displays all relevant data concerning the current status of each circuit configured for temperature/defrost control. The screen title line contains the circuit number and the user-defined name of the circuit.

The second line of the Circuit Status Screen consists of a status field and several headings. The status field can display the following descriptions:

Refr ON	= Refrig phase ON
Refr OFF	= Refrig phase OFF
Refr OVR	= Refrig relay override
Relay ON	= Refrig is on due to another circuits action using the same relay
Defr OVR	= Master defrost relay override
DEF XXXm	= Normal defrost, master relay on, XXX min. left
DEFon XXXm	= Normal defrost, master relay off, XXX min. left
EMG XXXm	= Emerg defrost, master relay off, XXX min. left
EMGon XXXm	= Emerg defrost, master relay on, XXX min. left
ECase XXXm	= Case emerg defrost, XXX min. left
Case XXXm	= Case normal defrost, XXX min. left
Rn OFF XXXm	= Runoff phase, XXX min. left
PumpO XXXm	= Pumpout phase, XXX min. left
Equal XXXm	= Equalize phase, XXX min. left
EvpFn XXXm	= Evaporator fan delay, XXX min. left
T ovr XXXm	= Temp override, XXX minutes left
- Ph Loss	= Phase loss of the assigned rack, refrig off

("XXXm" being a timer value in minutes).

The headings are for the circuit setpoint and actual sensor fields that follow on the next two lines. Temperature setpoints and actual sensor readings are displayed in degrees Fahrenheit (Celsius is available as an option - see Miscellaneous Screen under System Menu). Those temperatures read from or programmed for a standard temp card (-30 to 97 degrees) have 'f' as units. Those temperatures read from or programmed for the high temp card (0 to 255 degrees) have 'F' as units. If there are no sensors assigned for a given category (ie:term., alarm) the status will show "n/a". These symbols indicate specific alarm conditions and are defined as follows:

L (reverse video) - low temperature
H (reverse video) - high temperature
O (reverse video) - alarm override

Please note that "reverse video" means the character will appear to be white on a black background as opposed to black on a white background.

When individual case defrost is selected, each case status is displayed. In this case, the actual 'Temp' status above is displayed as '*'. This indicates to look further below for actual case status. The individual case status is displayed as:

Case:	1	2	3	4	5	6
*Act:	22F	25F	29F	25F	23F	25F
Defr:	ON	ON	OFF	n/a	OVR	OFF

The '*ACT' row indicates the current case temperatures. If termination sensors were not assigned to a particular case, the actual value shows as '-30F'. If digital termination of defrost is configured, each field on the '*ACT' row shows '-', and the status of the digital input replaces the '*' within the primary status block.

The 'Defr' row shows the state of the case defrost relays. If a defrost relay was not assigned to a case, the field shows 'n/a'.

Under the heading 'Sensors:', the analog input type, I/O board-channel number, status, and user-defined name are displayed for each assigned temperature, alarm, and defrost termination sensor. Only the sensors being used will have data displayed.

Under the heading 'Inputs:', the digital input type, I/O board-channel number, and status are displayed for the assigned digital defrost termination and initiation inputs.

Note that the types of sensors and inputs associated with the temperature/defrost control circuits are determined by the options selected on the Circuit Configuration Screen.

When 'Defrost Termination' is selected, the termination under 'Sensors' is deleted from the display, and is replaced by assignment/status.

Circuit Setpoints Screen

01 CIRCUIT A01	
Temp setpoint	-10F
Low alarm	-15F
Defr restart	20F
High alarm	13F
Defr term	50F
Evap fan start	30F
Skip Defr @dp	45f
Refrig delay	01m
Pumpout time	05m
Equalize time	05m
Defrost start times:	01:00 05:00 09:00 13:00 17:00 21:00
Max dp skips	2
Alarm delay	15m
Defrost time	30m
Evap fan dly	10m
Def init input	2-1
Def term input	2-2
Temp sensors	3-4 0-0 0-0 0-0 0-0 0-0
Alrm sensors	3-4 0-0 0-0 0-0 0-0 0-0
Term sensors	3-4 0-0 0-0 0-0 0-0 0-0
Suction relay	1-1
Liquid relay	1-2
Case defr rlys	2-1 2-2 2-3 2-4 2-5 2-6
Mastr HGas rly	2-7
Evap fan rly	2-8
Equalize relay	4-1
Alarm relay	4-2
Suct vrfy inpt	1-1
Liq vrfy inpt	1-2
Def vrfy inpts	2-1 2-2 2-3 2-4 2-5 2-6
Defr init inpt	3-7
Defr term inpt	3-8
Alrm ovrd inpt	3-1
Temp compensation priority	01
Rack number	01
	**
	**

Required Access Levels: 1 or 2 (see text)

The Circuit Setpoints Screen provides access to all programmable parameters affecting the temperature/defrost control circuits of the RC-1000. The title line of this screen consists of the circuit number and user-defined circuit name.

The setpoint data fields on the first few lines of the screen are self-explanatory; temperature units are Fahrenheit (Celsius is available as an option - see Miscellaneous Screen under System Menu); time delays are in minutes.

The 'Temp Setpoint' is the desired operating temperature for the circuit. When using low temp probes, the minimum setting is -30° f and the maximum setting is 97° f. When using high temp probes, the minimum setting is 0° f and the maximum setting is 255° f. If 'Temperature Deadband' is configured, this field will be replaced by 'Cut in' and 'Cut out' setpoints.

The 'High alarm' and 'Low alarm' setpoints are for critical temperature monitoring use. If the alarm setpoints are exceeded for the 'Alarm time' period, an alarm will be generated.

'Defr term' is the temperature that all assigned termination sensors must be above before the defrost cycle is terminated.

'Defr restart' is the temperature that the case termination temperatures must all fall below within a current defrost time period, then the case will return to defrost. This is intended to allow cases that are iced up, complete a more complete defrost cycle.

'Evap fan start' is the temperature that after a defrost, the coil must be below before the evaporator will restart. Otherwise, following the evap fan delay time, the fan will restart.

When the 'Dewpoint controlled skip' option is selected on the Circuit Configuration Screen, the data fields 'Skip defr @dp' and 'Max dp skips' are added to the Circuit Setpoint Screen. The 'Skip defr @dp' is the dewpoint temperature at which the defrost cycle will be inhibited or skipped if the dewpoint temperature has been below for the time between one complete defrost cycle. 'Max dp skips' is the maximum number of times that dewpoint will be permitted to skip the defrost cycle before a mandatory defrost. Note that dewpoint-controlled defrost skip and digitally-initiated defrost are mutually exclusive, that is they cannot both be enabled at the same time.

'Refrig delay' is the minimum time period that must pass after the refrigeration relay has been turned off before it can come back on again. Used to prevent short cycling.

The 'Alarm delay' is the time period that an alarm condition must be in before an alarm is logged. Note that the alarm is inactive during defrost and 15 minutes plus the alarm delay after defrost.

The 'Pumpout time' is the amount of time allowed for pumpout if the 'Pumpout phase' option is configured. When a defrost is initiated, the liquid relay will turn off for the programmed time period to allow the circuit to 'pump out'. Following this time, normal defrost will occur.

The 'Runoff time' is the amount of time after defrost that the refrigeration relay will be off. After this time expires, normal circuit refrigeration will begin. This is used to allow for condenser coils to drip off completely before refrigeration. If 'Pumpout phase' is configured, this field will not be shown.

The 'Defrost time' is the maximum amount of time a normal time initiated normal defrost will last unless it is terminated by termination sensor(s) temperature.

'Equalize time' is the amount of time allowed for equalizing pressures if the 'Equalize phase' option is configured. Following a defrost cycle, the equalize relay will be energized for this time period before normal refrigeration control is resumed.

'Evap fan dly' is the maximum amount of time after a defrost that the evaporator fan will stay off. (see 'Evap fan start')

For 'Defrost start times', six separate time fields in hours:minutes (military time) are provided. Program only as many of these as are needed.

NOTE: Up to twelve each of temperature, defrost termination, and alarm sensors can be assigned. For multiple sensor assignments, the following application rules should be noted: temperature control sensors are averaged; both low temperature alarm and defrost termination look at the sensor with the lowest reading; high temperature alarm looks at the sensor with the highest reading.

The 'Suction relay' is the relay used for controlling the suction line solenoid on the circuit. (use N/C contacts)

The 'Liquid relay' is the relay used for controlling the liquid line solenoid on a circuit. (use N/C contacts)

Individual 'Case defr rlys' are assigned for each defrost relay needed. The case relays line up with the corresponding temp/term/alarm sensors entered above them. (use N/O contacts)

'Defrost relay' is the relay used for a defrost load. (use N/O contacts)

'Mstr HGas rly' is the relay controlling the hot gas defrost valve. (use N/O contacts)

The 'Evap fan rly' is the relay controlling the evaporator fan. (use N/C contacts)

The 'Equalize relay' is the relay controlling the equalize valve. (use N/O contacts)

The 'Alarm relay' the relay used for all alarm functions on a circuit. It is normally energized if nothing is in alarm. (use N/C contacts)

The 'Suct vrfy inpt', 'Liq vrfy inpt' and 'Def vrfy inpts' are digital inputs used for proof of run verification. If a system is on, the corresponding digital contact should be closed.

'Alrm ovrd inpt' is a digital input that when closed, overrides all temperature alarms. Normal alarm monitoring will resume when the contacts are opened.

The 'Temp compensation priority' is used to assign priorities to each circuit when using floating setpoints on the rack. This field will only show up if 'Select' is chosen on the rack configuration screen for Temp Controlled Setpoints. The rack setpoints will float (up to the max cut in setpoint on the rack setpoint screen) only if priority 1 circuit is satisfied. If priority 1 circuit is in defrost, then the rack setpoints will float only if priority 2 circuit is satisfied, etc. The rack setpoints will float down to normal when the circuit with priority 1 refrigeration comes on. If 'Default' is selected on the rack configuration for Temp Controlled Setpoints, the circuit with the lowest setpoint must be satisfied for the rack setpoints to float (up to the max cut in setpoint on the rack setpoint screen). If the circuit with the lowest setpoint is in defrost, the associated circuit with the next lowest setpoint must be satisfied for the rack to float. When the circuit with the lowest setpoint goes above the setpoint, the rack setpoints will float back down, but will not go below the standard cut-in and cut-out values.

The 'Rack number' field allows you to specify the rack which this circuit uses. The number should correspond to an actual RC-1000 rack number. This assignment is important as it is a key for the software when using the Defrost Sense and Temperature Controlled Setpoints features described in the Rack Section of this manual. This parameter will affect both hot gas defrosting and temperature controlled setpoints (see Rack Menu section).

NOTE: When floating setpoints are used, all associated circuits will have the setpoints adjusted to 2° below the programmed value. The rack cut-in and cut-out setpoints will float up to but not exceed the 'Max cut-in' value.

Circuit Overview

CIRCUIT OVERVIEW							
01-04	-11F	-R	10F	-R	30F	D-	25F E-
05-08	05F	-R	43F	D-	30F	-R	30F o-
09-12	20F	--	23F	-R	-09F	-R	-30F oo

Required Access Level: None.

The Circuit Overview Screen provides a condensed view of the current status of all circuits configured for temperature/defrost control.

Each data line of the Circuit Overview Screen consists of temperature readings and pairs of status indicators for up to four circuits. A status indicator for defrost and one for refrigeration combine to reveal the current state of each circuit. These status indicators and their meanings are as follows:

- = system off
- o = override
- E = emergency defrost on, master case relay on
- e = emergency defrost on, master case relay off
- D = normal defrost on, master case relay on
- d = normal defrost on, master case relay off
- R = refrig phase, relay on
- r = refrig phase, relay off
- H (reverse video) = high temp alarm
- L (reverse video) = low temp alarm
- P = pumpout cycle
- Q = equalize cycle

DEFROST MAP SCREEN

PROGRAMMED DEFROST TIMES				
ID	Circuit Name	Start	Dur	Rack
01	Ice Cream Case	01:00	035m	01
02	Meat Cases	02:00	020m	02
03	Produce Storage	03:00	030m	02
04	Fish box	04:00	030m	02
05	Frozen Juice	05:00	030m	01
06	Chicken case	06:00	020m	02
07	10' Produce	07:00	020m	02
08	Frozen Fish doors	08:00	040m	01
		**		
		**		

Required Access Level: None.

The defrost map is a display of all configured circuits and their defrost schedules in a time based sorted list. It is used for determining the efficient operation of defrost schedules and for quick reference of defrost times. The circuit number, name, defrost start time, defrost duration and associated rack is displayed. This information can be used to check for overlapping of defrost times which might affect operation of the overall refrigeration operation.

CIRCUIT/SENSOR NAMES MENU

CIRCUIT/SENSOR NAMES	
1-Circuit Names	
2-Sensor Names	

Required Access Level: None.

The Circuit Menu is selected from the RC-1000 Circuit Menu. It is a table of contents to the RC-1000's circuit and sensor names functions. If you intend to make any changes to screens on this menu, keep in mind that different levels of access are required to change data fields.

Circuit Name Screen

NUM	CIRCUIT NAME
01	CIRCUIT A01
02	CIRCUIT A02
03	CIRCUIT A03
04	CIRCUIT A04
05	CIRCUIT A06
06	CIRCUIT A06
07	CIRCUIT A07
08	CIRCUIT A08
09	CIRCUIT A09
10	CIRCUIT A10
11	CIRCUIT A11
12	CIRCUIT A12
13	CIRCUIT A13
14	CIRCUIT A14
15	CIRCUIT A15
16	CIRCUIT A16
	**
	**

Required Access Level: 1 or 2.

The Circuit Name Screen enables you to enter descriptive names for each of the circuits configured for temperature/defrost control. Both numeric and alphabetic data entry are permitted.

To change the description:

- A. Press enter key, and arrow will appear beside '► CIRCUIT A01'
- B. To select the circuit that you wish to change the description of, use the up arrow or down arrow key on the keypad and press enter.
- C. The cursor will now appear under the first character of the description 'CIRCUIT A01'.
- D. Use the up arrow or down arrow key to scroll through the alphabet. When the desired character appears, use the right arrow key to move the cursor to the next character.
- E. If a space is required, it is located after the '9' and before the 'A'.

Circuit Sensor Name Screen

NUM	SENSOR NAME
3-1	FROZEN FD 1 T/A
3-2	FROZEN FD 2 T/A
3-3	FROZEN FD 3 T/A
3-4	FROZEN FD 1 TERM
3-5	FROZEN FD 2 TERM
3-6	FROZEN FD 3 TERM
3-7	ICE CREAM T/A
3-8	ICE CREAM TERM
4-1	SENSOR 4-1
4-2	SENSOR 4-2
4-3	SENSOR 4-3

**
**

Required Access Level: 1 or 2.

The Circuit Sensor Name Screen enables you to enter descriptive names, up to 24 characters long, for each sensor assigned to a configured circuit. Both numeric and alphabetic data entry are permitted. Descriptions can only be entered after the sensor assignment in the 'Circuit Setpoint' screen. The ability to describe a sensor can only be done following the assignment of the sensor in the 'Circuit Setpoint' Screen.

Circuit Configuration Screen

CIRCUIT CONFIGURATION	
Number of circuits (max 32)	10
Number of temp snsrs per ckt ..	6
Refrig relay control	Suction
Temperature dead band	NO
Defrost initiation	TIME
Defrost termination	TIME/TMP
Defrost restart	YES
Multi-case defrost term	YES
Hot gas defrost	YES
Pumpout phase	YES
Equalize phase	YES
Evap fan control	YES
Dewpoint controlled skip	YES
Digital alarm override	YES
Valve verification	YES
**	
**	

Required Access Level: 2

The Circuit Configuration Screen enables you to select the circuit configuration options that apply to your particular refrigeration control system. Note that these options have corresponding data fields on the Circuit Status and Circuit Setpoint screens.

The most critical configuration field on this screen is the first one, which enables you to specify the number of circuits that are to be controlled by the RC-1000. As long as the value of this data field is '00', you will be unable to view the other screens listed on the Circuit Menu.

The "Number of temp sensors per circuit" is selectable from 6 to 12. This allows up to 12 temp sensors and 12 termination sensors and 12 alarm sensors per circuit. The default value is 6 sensors of each type per circuit.

'Refrig relay control' allows three choices. The first is the default of 'Suction' control. This allows one relay to be assigned as control of the suction stop valve. The next choice is 'Liquid'. This allows a relay to be assigned as control of the liquid line solenoid. The final choice is 'Suc/Liq'. This allows two relays to be assigned. One for a suction valve and one for a liquid line solenoid.

If 'Temperature dead band' is selected, there will be areas provided for cut in and cut out temperature setpoints.

'Defrost initiation' offers a choice between system clock 'TIME' and a 'TIME/DIGITAL' input. When the latter is selected, a 'Def init input' field is added to the Circuit Setpoint Screen and an 'Init' input field is added to the Circuit Status Screen under the 'Inputs:' heading. Note that when the 'DIGITAL' defrost initiation option is selected, the dewpoint option is forced to 'NO', they cannot both be active at the same time. To initiate a defrost, the contacts must be closed to the assigned digital input and the defrost time must be active. If the defrost time schedule is not entered, then defrost is initiated only by the digital input closure. If 'TIME' is selected, defrost is initiated only by the defrost time schedule.

'Defrost termination' offers a choice between a 'TIME/TEMP' and 'TIME/DIGITAL'. The first allows the defrost to continue the entire defrost time as long as the termination temperature is below the setpoint. If the termination exceeds the termination setpoint, the defrost will terminate. When the latter is selected, a 'Def term input' field is added to the Circuit Setpoint Screen and a 'Term' input field is added to the Circuit Status Screen under the 'Inputs' heading. To terminate a defrost, the programmed digital input must see a contact closure (Klixon or case thermostat), or defrost will end when the defrost duration has expired.

Actual implementation of the digital defrost options is on a per-circuit basis and is dependent upon input assignment, sensor assignments, and defrost times.

'Defrost restart' is provided to better use the total defrost time programmed for a circuit. The defrost phase will be active for the entire defrost time programmed. Within that duration, any defrost relay (master or case), will turn off when that circuit/case termination condition is satisfied. If temp termination of defrost is specified, any defrost relay can turn back on if the associated temp meets a specified defrost restart setpoint and the defrost time duration has not expired. If digital termination of defrost is configured, all assigned relays will turn back on if the termination input has been for 2 minutes. Defrost relay cycling, based on the above description, will continue for the full defrost duration.

'Multi-case defrost term' allows use of a master defrost relay or individual case defrost relays. When configured each individual case defrost relay is associated with a defrost termination sensor which is displayed vertically above the relay assignment on the setpoints screen. If 12 sensors per circuit is configured, each case defrost relay will have 2 termination sensors associated to it. If temperature termination of defrost is configured, each case turns off its individual defrost relay. Once all the cases have terminated (or the defrost duration has expired), the circuits defrost phase is complete and refrigeration control is returned to normal. If defrost is configured to terminate by digital signal, all case relays are switched simultaneously. (only one digital termination input is provided).

When the 'Hot gas defrost' option is selected, the 'Hot gas relay' field is added to the Circuit Setpoint Screen. It is important to note that the Hot gas relay should be wired to the main liquid line solenoid or head pressure modulating valve. The 'Hot gas defrost' option should be programmed on only those circuits that use hot gas for their defrost.

'Pumpout phase' allows for a time period before actual defrost, that the liquid relay is turned off and the suction relay is turned on. After the pump out time has expired, the normal defrost will occur. This is provided to pump out the evaporator coil before the defrost.

The 'Equalize phase' is used to equalize the pressure across the evaporator coil after a defrost cycle. If this option is configured, the 'Run off' time field will be replaced with 'Equalize time' and a corresponding equalize relay assignment field. After the normal defrost cycle, the equalize relay will energize for the equalize time period before normal refrig control is allowed.

'Evap fan control' is available to separately control the evaporator fan. If this option is configured, three entry fields will be provided. The first is for the evaporator fan temp setpoint. The next is for the evaporator fan delay. The final is for the evaporator fan relay assignment. Following return to refrigeration control after defrost, the evaporator time delay period is started. The evaporator fan will restart once the evaporator coil temperature drops below the evap fan setpoint or the evap fan delay period has expired, whichever comes first. This option requires that at least one defrost termination sensor be assigned. If more than one sensor is assigned, the maximum of all the sensors is used to control the evap fan restart.

When the 'Dewpoint controlled skip' option is selected, the fields 'Skip defr @ dp' and 'Max skips' are added to the Circuit Setpoint Screen. If this option is selected, the defrost cycle will be skipped (up to the max number of skips) when the dewpoint is below the dewpoint skip setpoint. If this option is configured, a dewpoint sensor will need to be installed. Note that this feature cannot be configured at the same time as digital initiated defrost.

The 'Digital Alarm Override' feature allows use of a digital input to override alarms for a circuit. If the contacts are closed, the circuit will not alarm on high or low temperature conditions. Normal operation is resumed when the contacts are opened. This may be useful when servicing a circuit or when stocking a case.

The 'Valve verification' feature allows remote monitoring of the actual refrigeration valve or defrost valve, on a per-circuit basis, by using a digital input. If the RC-1000 calls for refrigeration and the ref valve is not energized, the alarm log will show 'date and time', circuit description, and will also activate the remote alarm. Defrost valve verification works in a similar manner.

RACK MENU

RACK MENU	
1-Status	4-Rack Names
2-Setpoints	5-Sensor Names
3-Overview	6-Configuration

Required Access Level: None.

The Rack Menu is selected from the RC-1000 Main Menu. It is the table of contents to the RC-1000's compressor rack configuration and control functions. If you intend to make any programming changes to screens on this menu, keep in mind that different levels of access are required by different programmable data fields.

Rack Status Screen

01 RACK A		SUCT	HEAD
Units on	1750rpm	1 34	123
Capacity ACT-REQ		060%-060%	050%-050%
Actual reading		010p	175p
Cut in-Cut out		012p-009p	200p-165p
Temperature Diff			0.0F
Desuper Units On		1-	MaxTemp: 82F
Power		0000kw	
Anlg Liquid Level		038%	
Motor data:			
Speed		1750rpm	
Frequency		60hz	
Capacity		100%	
Current		035a	
Oil pres		000	
AI	1-1	Ambient Temp Sensor	27.0F
AI	1-2	Drop Leg Temp Sensor	27.0F
AI	1-1	Rack A Suction Pres	050p
AI	1-2	Rack A Head Pres	175P
DI	1-1	Rack A Aux Enable	off
DI	1-2	Rack A Phase Loss	off
Compr	1	1-2 Rack A Comp 2	off
Compr	2	1-3 Rack A Comp 3	off
Compr	3	1-4 Rack A Comp 4	off
Comprsr speed Rack A VS Comp			0000rpm
**			
**			

Required Access Level: 1 or 2 (see text)

The Rack Status Screen displays all relevant data concerning the current status of each configured compressor rack. The screen title line contains the rack number and the user-defined rack name.

The second line of the Rack Status Screen consists of the rack compressor speed, suction, and head status fields. The status fields contain either a blank (no alarm) or a lowercase 'o'. This symbol indicates that there is an override condition in effect. A reverse video 'O' appearing just to the right of these fields indicates an oil failure alarm condition.

The third line consists of the actual vs. required capacity (shown as percentages) for the suction and head sides of the rack.

The next two data lines consist of the actual readings for suction and head pressures and their cut-in and cut-out setpoints. A reverse video "H" or a reverse video "L" to the right of either of the two pressure fields indicates a high or low pressure condition, respectively. If the condenser fans are being controlled by temperature differential, the cut in and cut out pressure settings will be replaced by the temperature differential settings. A reverse video "A" or a reverse video "F" to the right of either of the two setpoint fields indicates auxiliary or floating setpoints, respectively. A reverse video "T", to the right of the suction reading, indicates low liquid level. A reverse video "O" to the right of the suction and pressure readings indicate an alarm override. This override occurs after any power failure and lasts for a 3 minute period.

If temperature differential control of the condenser fans is configured, the next line will display the actual temperature difference between the actual ambient and drop leg temperatures.

If Desuperheater control is configured, the next line will be the status of the Desuperheater relays and the average (or max temperature) of all the Desuperheater manifold temperature sensors.

The next line will indicate the actual rack KW , if used. Phase loss is indicated by a reverse video "P" beside the power KW line. If neither phase loss or rack KW is used on any rack, this line will not be displayed.

If an analog liquid level input is used, the actual liquid level % is displayed next. A reverse video "L" is displayed if the liquid level is lower than the alarm setpoint and in alarm.

When the 'Variable speed' option is selected on the Rack Configuration Screen, an additional section labeled 'Motor Data' is displayed with the following data fields: compressor speed, compressor motor frequency, percentage capacity, compressor amperage, and net oil pressure reading. If the oil pressure reading is considered low, a reverse video "O" symbol will appear to the right of the oil pressure reading.

During normal operation, the variable speed compressor will ramp between the "Max RPM" setpoint and the "Min RPM" setpoint. If during the course of normal operation the oil pressure goes below the "min oil press" setpoint for five seconds, the RC-1000 will ramp the RPMs of the variable speed compressor to the maximum setpoint in an attempt to regain a safe oil pressure. This also prevents the mechanical oil safety switch from shutting off the compressor unless there is an actual oil problem. The variable

speed compressor will resume normal operation after thirty seconds of good oil pressure.

Note: Oil pressure displayed is the net oil pressure.
Oil pump output - Suction pressure = net oil pressure.

The next lines of data only are displayed if the monitor option is configured. All sensors assigned are displayed along with their descriptions and actual readings.

RACK SETPOINTS MENU

SETPOINTS
1-Rack Setpoints
2-Desuperheater Setpoints
3-Monitoring Setpoints

Required Access Level: None.

The Rack Setpoint Menu is selected from the RC-1000 Rack Menu. It is the table of contents to the Rack setpoints areas. The Rack Setpoint selection is always available. The selections for Desuperheater Setpoint and Monitor Setpoint are only displayed if these functions are configured in the Rack Configuration. If Desuperheater and Monitor setpoints are not configured, this menu will be skipped and you will be directly brought into the Rack Setpoint screen when the setpoints selection is made from the Rack Menu.

Rack Setpoint Screen

01 RACK A	SUCT	HEAD
Cut in	012p	200p
Cut out	009p	165p
Aux cut in	020p	250p

Aux cut out	015p	185p
Max cut in	030p	
High alarm	040p	300p
Low alarm	005p	095p
Shutdown	015p	
Head Override		320p
Alarm delay	15m	20m
Liquid Level Alarm	020%	
HR Override Level	010%	
HR Override Diff	002%	
HR Override Delay	030s	
Min on time	000s	000s
Min off time	060s	060s
Control gain	020	100
Derivative Gain	040	150
Unit combinations	ALT	SEQ
Pres sensor	1-1	1-2
Alarm relay	2-7	2-7
Ambient Temperature Sensor		0-0
Drop Leg Temperature Sensor		0-0
Temp Differential Cut-In		00
Temp Differential Offset		00
Anlg Liq. Lev. Snsr	0-0	
HR Override Relay	0-0	
Aux enable input	1-1	
Phase loss input	1-2	
Oil failure input	1-5	

Compr	1	2	3	4	5	6	7	8
Relay	0-0	1-2	1-3	1-4	1-5	1-6	0-0	0-0
Capacity	000	100	100	100	050	050	000	000
Unloaders	0	0	0	0	1	0	0	0
Run inpt	0-0	2-2	2-3	2-4	2-5	0-0	0-0	0-0

Variable Speed Compressor:

Max rpm	1750	Min rpm	0875
Capacity	100	Min oil pres	015p
Analog output	1-1	Oil pres sensr	1-3
Freq sensor	0-0	Current sensr	0-0
Control relay	1-1	Reset relay	2-5
Switchovr relay	3-2	Fault input	1-2
Run input	2-1		

Fan	1	2	3	4	5	6
Relay	2-1	2-2	2-3	2-4	2-5	2-6
Run Inpt	0-0	0-0	0-0	0-0	0-0	0-0
Power Sensr	0-0	Max Power				1000
Associated medium temperature rack						02
	**					
	**					

Required Access Level: 1 or 2.

The Rack Setpoint Screen provides access to all programmable parameters affecting the control of each configured compressor rack. The screen title line contains the rack number and user-defined rack name. Many areas may not be displayed on all units depending on the rack configuration setup. Pressures are in psi and times are in either minutes ('m') or seconds ('s'). In general, these data fields are self-explanatory.

The 'Cut in' and 'Cut out' fields are for setting the general operating pressures of the rack. The 'Cut in' must be higher than or equal to the 'Cut out' value.

'Aux cut in' and 'Aux cut out' are the setpoints to be used when the auxiliary enable digital input contacts are closed.

The 'Max cut in' value is used to determine a maximum pressure for the system to operate under when floating setpoints are used.

The 'High Alarm' and 'Low Alarm' setpoints are values that when exceeded, will effect an alarm in the RC-1000. These alarms will honor the alarm time delay.

The 'Shutdown' field is provided to allow shutdown of all compressors on the rack if the suction pressure falls below this value. Normal operation will resume when the pressure rises back above the shutdown value. The compressors must honor the min off time before restarting. The minimum value for proper operation is '001'. This feature can be disabled by setting the shutdown value to '000'.

The 'Head Override' setpoint is used to set a high pressure point where, if exceeded, the compressors would begin an orderly shutdown. As this setpoint is exceeded, the suction % required is decreased allowing compressors to shutdown. The farther above this setpoint, the faster the compressors will shutdown. When the head pressure drops below the head override setpoint, the compressors will be allowed to return to normal operation.

'Alarm Delay' is the time period that must pass after an alarm condition has been met, before an alarm will be logged.

'Liquid level alarm' is the value (in %) that when the analog liquid level sensor falls below, an alarm will be generated.

'HR override level' is the value (in %) that the liquid level must be below, for the specified time period, for the HR override relay to open.

'HR override diff' is the level (in %) that the liquid level must exceed (HR override level + HR override diff) before the HR override relay is returned to normal operation.

'HR override delay' is the time period that the liquid level must be below the HR override level before HR override action occurs.

The 'Min on' and 'Min off' times are intended to supply time delays for short cycle protection of the compressors and condenser fans. The default times are 30 seconds.

The most important parameter for correct rack operation is the 'Control gain'. This regulates the response of the RC-1000 to changes in pressures. Typical starting values are 10 for suction and 100 for head. The higher the gain, the faster the RC-1000 will respond and calculate capacities. These values can be tailored to suit the particular compressor installation for optimal performance. There must be a value for control gain in order for the system to operate. The minimum value is '000' and the maximum value is '255'.

The 'Derivative Gain' field allows the RC-1000 to sense the direction and magnitude of pressure changes. This function can help with sharp rises and falls of pressure. It can be thought of as an 'anticipator'. Typical values for this field should start at 4 times the control gain. The higher the derivative gain, the faster the RC-1000 will respond and calculate additional capacities. These values can be tailored to suit the particular compressor installation for optimal performance. This feature is optionally used. If it is not desired to use the derivative gain, set these fields to '000'. The minimum value is '000' and the maximum value is '255'.

The method of sequencing compressors and condenser fans is set by either 'Seq' (sequential) or 'Alt' (alternating). In seq mode, the stages are brought on from left to right, and brought off from right to left. If alt mode is selected, the RC-1000 alternates stages based on run times and capacity required.

The 'Pres Sensor' assignments are made according to which analog input the pressure sensors are connected to on the termination boards. The suction pressure is used with a 100 psi transducer and the head pressure is used with a 500 psi transducer.

The 'Alarm Relay' is the relay assignment which will be activated upon an alarm condition logged by the RC-1000. (use N/C contacts)

The 'Ambient Temperature Sensor' is the analog input temperature sensor that will be used for monitoring the outdoor ambient temperature. It will be used only if Temperature Differential for head pressure control is configured in the Rack setpoints screen. Either high and low temperature sensors can be used. This sensor type must be the same as the drop leg sensor.

The 'Drop Leg Temperature Sensor' is the analog input temperature sensor that will be used to monitor the condenser manifold temperature. It will be used only if Temperature Differential for head pressure control is configured in the Rack setpoints screen. Either high or low temperature sensors can be used. This sensor type must be the same as the ambient sensor.

'Temp Differential cut in' is the value that reflects the maximum difference of the drop leg temperature minus the ambient temperature that is desired. If the difference in temperatures is greater than this setpoint, the condenser fans will begin to calculate percent required and stage on. When the temperature difference is less than this setpoint minus the 'Temp Differential Offset', the condenser fans will begin to stage off. The 'Temp Differential Offset' can be set to '00' to allow a single setpoint control.

The 'Analog Liq. Lev. Snsr' is the analog input that reads the amount of refrigerant liquid level in the receiver. The sensor used is a 0 to 10 k ohm pot, with 0 = 0% and 10 k = 100%.

'Liquid level input' is the digital input used for monitoring a digital liquid level sensor. If the contacts are closed, an alarm will be generated.

'Defrost sense input' is the digital input that identifies that a corresponding circuit is in defrost. If the contacts are closed, the circuit indicates it is in defrost.

'HR Override Relay' is the relay that will be de-energized when the liquid level in the receiver falls below the 'HR Override Level'. The 'HR Override Delay' will be active before the relay is de-energized. The relay will energize when the liquid level returns above the 'HR Override Level' plus the 'HR Override Diff'. (use N/C contacts)

'Aux Enable Input' is the digital input that when closed, will activate the 'Aux cut in' and 'Aux cut out' setpoints. The RC-1000 will immediately react to the new setpoints. When this input is active, an inverse 'A' will appear next to the setpoints field on the Rack Status screen.

The 'Phase loss input' field is the digital input that when opened, will shut down all compressors and associated circuits as defined by the circuit setpoint screen.

The 'Oil failure input' is the digital input used to monitor rack oil pressure. This is a monitor only input, no action will occur on rack components. An alarm will be logged upon opening the contacts. All oil fail contacts should be connected in series such that any failure will open the digital input. When the contacts are closed, the alarm condition will clear.

The 'Capacity' values should be proportional for all the compressors used. Values of HP, BTU or % can be used. For example: assume three compressors at 7.5 hp are used, since 7.5 cannot be entered as capacity, use 75 for all three. If a variable speed compressor was used also at capacity of 10 hp, use 100 as its capacity for compatibility with the fixed compressor capacities. Generally, higher numbers for variable speed capacity, (multiply actual capacity by 10) , provide finer control of the variable speed compressor.

The 'Unloaders' value indicates how many unloaders are provided for the compressor assigned directly above it. The RC-1000 then assumes that the next 'Unloaders' number of compressors are actually unloaders. For example, compressor 1 (10 hp total) has 4 unloaders (each has 1/5 total capacity) relay assignments 1-1 through 1-5, compressors 3 (15 hp) and 4 (15 hp) have no unloaders, relay assignments 1-6 and 1-7. The assignments would be:

Compr	1	2	3	4	5	6	7	8
Relay	1-1	1-2	1-3	1-4	1-5	1-6	1-7	0-0
Capacity	020	020	020	020	020	150	150	000
Unloaders	4	0	0	0	0	0	0	0

The RC-1000 will not allow a programmed unloader to come on without its master compressor on first.

The 'Run Inpt' setpoints are used for digital proof of run contacts for each compressor. The RC-1000 expects closed contacts when the compressor is running and open contacts when the compressor is off. An alarm will be logged if the proof contacts do not agree with the compressor run condition.

When the 'Variable speed' option is selected on the Rack Configuration Screen, additional data fields are displayed under the heading 'Variable speed compressor. Not all of these parameters must be used, depending on the complexity of the inverter installation. Refer to figures 12 and 13 for connection of these features. When using the advanced features of the inverter (ie: fault feedback, reset, switch over, etc) the operation of the system is more complicated. If the inverter sends a fault signal to the RC-1000, the RC-1000 will attempt to reset the inverter three times, if unsuccessful, the RC-1000 will enable the switch over relay and the inverter will run in bypass mode. When the fault condition clears, the inverter control will return to normal.

V.S. Setpoints:

'Max RPM' is the maximum value of RPM for the compressor under V.S. control. This corresponds to the maximum output of the analog out card (10 vdc) The maximum value allowed is 5000 rpm.

'Min RPM' is the lowest value for the V.S. to operate. The compressor will never operate below this RPM. The V.S. compressor will shut down only when the required capacity is at 0%.

The 'Capacity' uses the same capacity setup as for fixed compressors. The higher the capacity, the more defined increments for the V.S. output.

For example:

cap = 10, max RPM = 1750
V.S. steps 175 RPM
cap = 100, max RPM = 1750
V.S. steps 17.5 RPM

'Min oil pres' is the minimum operating pressure desired for the V.S. compressor to operate under. If the oil pressure goes below the min oil pressure, the V.S. compressor will speed to max RPM until the oil pressure is restored for a 30 second period.

The 'Analog output' is the output assignment for the analog output card that is connected to the V.S. inverter.

The 'Oil pres sensor' is the assignment for the pressure sensor used to monitor oil pressure in the compressor. A standard SA-1000 transducer is used and should be 'snubbed' to prevent the 'hammer' effect. The oil pressure is calculated as: Oil pump output- suction pressure = net oil pressure.

The 'Freq sensor' is used for an external monitor of the operating frequency of the inverter. The signal should be 0-10 vdc.

The 'Current sensor' is used for an external monitor of the operating current of the V.S. compressor. The signal should be 0-10 vdc.

The 'Control Relay' is used to control the main power contactor for the inverter. The control relay is energized whenever the analog output is active. (use N/C contacts)

The 'Reset relay' is used to send a reset signal to the inverter. If a fault is detected from the inverter, the reset relay will pulse three times and attempt to get the inverter running properly. If after three resets the inverter is still in a fault condition, the inverter will go into switchover mode.

The 'Switchover relay' is used to bypass the inverter control and run the inverter as an on/off compressor. If the inverter has a fault and does not recover, the switchover relay will energize and the external bypass relay will control the compressor. This relay can be connected either N/O or N/C as configured in the rack configuration.

The 'Fault input' accepts a digital fault signal from the inverter. If the contacts are closed, the RC-1000 will attempt to reset the inverter using the reset relay.

'Run input' is a digital input used for proof of run verification of the V.S. inverter. If the contacts are closed, the compressor is assumed to be running. If the run input does not match the actual run condition of the compressor, an alarm is generated.

Condenser 'Fan Relays' are assigned next along with their respective proof of run digital input assignments (if used).

The 'Power Sensor' is a 0-10 volt analog input from a kw transducer. 'Max Power' is the equivalent to a scale factor for the transducer used. For the EIL watt transducers the max kw is determined as follows:(refer to figures 7, 27 and 28)

<u>TRANSDUCER</u>	<u>RATING</u>	<u>MAX KW</u>
A12080	208v,3 phase,3 wire	.36 x (ct size)
A12081	480v,3 phase,3 wire	.83 x (ct size)

The 'Associated low temperature rack' interlocks the rack to another for lock out purposes. Intended for two stage systems. If the med temp rack compressors are not running, the low temp rack will be locked out (all compressors off) This number should be set on the medium temp rack. On the associated low tem rack, this field will show 'N/A".

Rack Desuperheater Setpoint Screen

01-RACK A					
		Unit: #1		#2	
Cut in setpoints		70F		90F	
Dead bands (cut out)...		05F		05F	
Desuperheater relays..		8-1		8-2	
Temperature control on.		Average temp			
Manifold Sensors					
7-1	7-2	7-3	7-4	7-5	7-6
**					

Required Access Level: 1 or 2.

The Desuperheater Setpoint screen allows setpoints for Desuperheater relay control and two stage rack control interlock. Up to six manifold temperature sensors can be assigned. The control will operate on the average of these sensors or on the Highest Temperature (user selectable). Up to two relays can be assigned with individual cut in setpoints and deadband offsets. The relay will come on when the temperature goes above the setpoint and will go off when the temperature goes below the setpoint minus the deadband.

Rack Monitor Setpoint Screen

01- RACK A					
Type	Assignments				
Temp snsr:	1-1	0-0	0-0	0-0	
Low Press:	3-1	3-2	0-0	0-0	
High Press:	3-3	3-4	0-0	0-0	
Other snsr:	7-1	7-2	0-0	0-0	
Dig Inputs:	2-1	2-2	0-0	0-0	
Relay Outp:	4-1	4-2	4-3	4-4	
Analog Out:	0-0				
**					

Required Access Level: 1 or 2.

The monitor setpoints allows for monitoring in a convenient group, a variety of inputs and outputs. There is no control action from these setpoints. The inputs and outputs can be either independent assignments or duplicate assignments from any other area of the RC-1000.

Rack Overview Screen

RACK OVERVIEW					
	SUCT			HEAD	
01	030p	123----	1750rpm	248p	12---
02	012p	--34---		260p	1234-
03	000p			000p	
**					

Required Access Level: 1 or 2.

The Rack Overview Screen shows a condensed status of the racks. The data includes the rack number, the suction pressure, the variable speed rpm, compressor stages on, head pressure and condensor fan stages. High and low alarms are indicated on this screen.

Rack Name Screen

NUM	RACK NAME
01	RACK A LOW TEMP
02	RACK B MED TEMP
03	A/C COMPRESSOR
04	SATELLITE
**	
**	

Required Access Level: 1 or 2.

The Rack Name Screen enables you to enter descriptive names, up to 16 characters long, for each of the configured refrigeration racks. Both numeric and alphanumeric data entry are permitted. Descriptions can only be entered after the racks have been configured in the 'Rack Configuration' screen.

Rack Sensor Names Menu

<p style="text-align: center;">Sensor Names</p> <p>1-Rack Sensor Names</p> <p>2-Monitor Sensor Names</p>
--

Required Access Level: 1 or 2.

The Rack Sensor Names Menu is selected from the Rack Menu. It allows access to assign sensor name description to standard Rack sensors and to the Monitor sensors. Both numeric and alphanumeric data entry are permitted. Descriptions can only be entered after the racks have been configured in the 'Rack Configuration' screen.

RACK Sensor Names Screen

01-Rack A		
3-1 Suct Pr	RACK A SUCTION PRESSURE	
3-2 Head Pr	RACK A HEAD PRESSURE	
4-1 Liq Lev	RACK A LIQUID LEVEL	
4-1 Ambient	OUTDOOR AMBIENT TEMPERATURE	
4-2 Drop Lg	CONDENSER DROP LEG TEMP	
2-7 Phase	RACK A PHASE LOSS MONITOR	
2-8 Oil Inp	RACK A OIL FAIL INPUT	
	**	
	**	

Required Access Level: 1 or 2.

The Rack Sensor Name Screen enables you to enter descriptive names, up to 24 characters long, for each sensor assigned to a configured compressor rack. Both numeric and alphabetic data entry are permitted. The ability to describe a sensor can only be done following the assignment of the sensor in the 'Rack Setpoint' Screen.

RACK Monitor Names Screen

01-Rack A		
3-1	Suct Pr	RACK A SUCTION PRESSURE
3-2	Head Pr	RACK A HEAD PRESSURE
4-1	Liq Lev	RACK A LIQUID LEVEL
4-1	Ambient	OUTDOOR AMBIENT TEMPERATURE
4-2	Drop Lg	CONDENSER DROP LEG TEMP
2-7	Phase	RACK A PHASE LOSS MONITOR
2-8	Oil Inp	RACK A OIL FAIL INPUT
**		
**		

Required Access Level: 1 or 2.

The Rack Monitor Names Screen enables you to enter descriptive names, up to 24 characters long, for each sensor assigned to a configured monitor group. Both numeric and alphabetic data entry are permitted. The ability to describe a sensor can only be done following the assignment of the sensor in the 'Monitor Setpoint' Screen.

Rack Configuration Screen

RACK CONFIGURATION	
Number of racks (Max:4)	4
Variable speed	YES
Run verification	YES
Aux setpoints	YES
Temp controlled setpoints	YES
Phase loss input	YES
Refrigerant liquid level	YES
Defrost sense input	INTERNAL
Oil failure input	YES
Compr relay Energized on	YES
Desuperheater control	YES
Additional Monitoring	YES
TD head pressure control	YES
Two stage rack control	YES
Head Pressure Override	YES
Polarity of switchover relay ..	EOFF
**	
**	

Required Access Level: 1 or 2.

The Rack Configuration Screen enables you to select the compressor rack configuration options that apply to your particular refrigeration control system.

The most critical configuration field on this screen is the first one, which enables you to specify the number of racks that are to be controlled by the RC-1000. Remember, as long as the value of this data field is '00', you will be unable to view the other screens listed on the Rack Menu.

The next configuration option, 'Variable speed', provides the capability to control one compressor speed for each configured refrigeration rack. When this option is selected (YES or NO), additional data fields appear on the status and setpoint screens (see the Rack Status and Rack Setpoint screens for details).

The 'Run verification' option offers the capability to sense the actual state of individual compressors ('ON' or 'OFF'), via digital inputs (i.e. when the compressor turns on, the digital input will close to indicate a run condition). When this option is selected, eight 'Run inpt' fields (digital input assignments) are added to the Rack Setpoints Screen. A suction alarm will occur when the state of any of these inputs does not match the desired output state of the associated compressor. Also, a 'v' will appear in the Rack Status Screen in place of the compressor number.

The 'Auxiliary setpoints' option offers the capability to control the rack suction and head pressures according to an additional set of setpoints when a special digital input is 'ON' (closed). 'Aux cut in' and 'Aux cut out' setpoint fields and an 'Aux enable input' field are added to the Rack Setpoint Screen when this option is selected.

The 'Temperature controlled setpoints' option allows the user to "float" the suction pressure CI and CO upward based on critical case temperatures. By assigning a max CI value in the 'Rack setpoints' screen, and referencing the appropriate rack number at the bottom of each 'Circuit setpoints' screen, a control algorithm will be initiated.

When floating setpoints are used, all associated circuits will have the setpoints adjusted to 2° below the programmed value. The rack cut-in and cut-out setpoints will float up to but not exceed the 'Max cut-in' value. When any associated circuit goes above the setpoint, the rack setpoints will float back down, but will not go below the standard cut-in and cut-out values.

During the algorithm, the rack side of the RC-1000 will look at the setpoints of all assigned circuits. One circuit will be used to "float" the suction CI and CO. There are two configurations for deciding which circuit to use - 'default' and 'select'. 'Default' uses the circuit with the lowest setpoint. 'Select' uses the circuit with the lowest 'Temperature Compensation Priority' (TCP), which is entered in the Circuit Setpoint screen. A priority of zero indicates that circuit is not to be used for temperature compensation. If that circuit temp is at or below setpoint, the CI and CO will float up.

The rate of floating is 1 psi/(degree x minute). The differential between CI and CO will remain constant. The CI will never float above the max CI or below its original value. In a case where the controlling circuit goes into defrost, the rack side of the RC-1000 will use either the circuit with the next lowest setpoint if 'default' is chosen, or the circuit with the next higher TCP if 'select' is chosen. While a circuit is being used for floating, it will remain in 'refrigeration ON' mode unless the temperature falls to two degrees below setpoint. This allows the temperature to be controlled by the rack side via "floating".

The 'Phase loss input' option offers the capability to sense an AC power line failure via a phase protect relay into a digital input and shut down all configured rack compressors and assigned circuits immediately. Selection of this option adds the 'Phase loss input' field to the Rack Setpoint Screen. Note that the 'open' state signals an alarm condition for this input. During normal operation, the contacts need to be closed (digital input light - ON).

The 'Refrigerant liquid level' option offers the capability to sense the liquid refrigerant level via a digital or analog input and shut down the rack system when the level falls below some minimum. Selection of this option adds the 'Liquid level input' field to the Rack Setpoint Screen. For 'Digital', note that the 'closed' state signals an alarm condition for this input. During normal operation, the contacts need to be open (digital input light - OFF). Using 'Analog' allows the use of a liquid level float to be incorporated into the RC-1000. The scaling for this sensor 0-100%. If the percent of liquid goes below Liquid Level alarm setpoint, an alarm is generated, and the rack system is shut down. The liquid level input is connected to a '10k ohm potentiometer' style float available on many OEM racks (see Fig. 17).

When using refrigerant liquid level monitoring, a Heat Reclaim override setpoint and a Heat Reclaim override relay are also available. This allows the RC-1000 to bypass heat reclaim if the receiver level falls below a given point.

The 'Defrost sense input' option has three possible choices, 'Internal', 'External', and 'No'. It offers the capability to sense either a circuit's hot gas defrost cycle (internal--from the defrost initiate times under the Circuit Setpoints Screen) or a digital input (external--closed input initiates defrost). In both cases, the smallest possible compressor capacity will, at minimum, be maintained to supply sufficient hot gas during the defrost cycle. Selection of the external option adds the 'Defrost sense input' field to the Rack Setpoint Screen. To monitor external defrost initiation, the contacts need to be closed during defrost.

The 'Oil failure input' option offers the capability to sense an oil failure (digital input is open) and generate an alarm. Selection of this option adds the 'Oil failure input' field to the Rack Setpoint Screen. Note that the digital input be closed under normal conditions. During 'Run Verification', 'Phase Loss', 'Liquid Level', and 'Oil Failure', the external alarm relay will be activated, and date and time will be stored in the Alarm Log by the unit.

The 'Compr relay energized on' option offers the capability to have compressor output relays energized either on or off. If 'no' is selected, the compressors will be energized off. If 'yes' is selected, the compressors relay will be energized on. Use the 'ENTER' key to toggle from 'yes' to 'no'.

'Desuperheater control' allows access to the Desuperheater setpoint menu. This allows control of up to two relays based on manifold temperature, a rise in temperature will bring on the loads. Up to 6 manifold temperature can be assigned and control will be based on the average temperature or the maximum temperature (user selectable).

'Additional monitoring points' allows access to the Monitor setpoint screen. This area is provided to allow up to 4 temperature sensors, 4 suction pressure sensors, 4 head pressure sensors, 4 general sensors, 4 digital inputs, 4 digital outputs and 1 analog output per rack for monitoring purposes. There is no control functions from this function.

'TD head pressure control' is provided to allow control of condenser fans based on the temperature difference of a drop leg temperature and the ambient temperature. These setpoints are on the rack setpoint screen. It is intended that maximum and minimum pressures are assigned as backup parameters. If the head pressure exceeds the pressure setpoints the pressure setpoints will override the temperature function and control the condenser fans. Temperature control will return when the head pressure is between the head pressure cut in and cut out setpoints.

The 'Two stage rack control' selection allows you to link a low temp rack to a med temp rack for lockout purposes. If the med temp rack is not running, the low temp rack will be 'locked out' (ie: all compressors off) Normal control of the low temp rack will be returned when at least one compressor is running on the medium temp rack.

The 'Head Pressure Override' is a feature which allows a high head pressure setpoint which if exceeded, will start an orderly shutdown of compressors.

The 'Polarity of Switchover relay' assigns the variable speed switchover relay to either energized on (EON) or energized off (EOFF).

AUX FUNCTIONS MENU

AUXILIARY MENU

- 1-Leak Detect
- 2-Logic Statements
- 3-Override Menu

Required Access Level: None.

The Aux Outputs Menu is selected from the RC-1000 Main Menu. This menu provides selection for the Leak Detect Systems, Logic Statements and Overrides.

Leak Detect Menu

LEAK DETECT MENU

- | | |
|-------------|-----------------|
| 1-Status | 4-Group Names |
| 2-Setpoints | 5-Sensor Names |
| 3-Overview | 6-Configuration |

Required Access Level: None.

The Leak Detect Menu is selected from the RC-1000 Aux Outputs Menu. This menu provides selection for the Leak Detect setpoints, descriptions and status.

Leak Detect Status

```
>01 LEAK DETECT Group #01
Status: Normal
Leak Sensors:      Setpt      Actual
Sensor 1-1        400 ppm    20 ppm
```

Required Access Level: None.

The Leak Detect Status screen provides an interpretation of the refrigeration leak detectors. With an analog sensor, the display will show leaks in units of ppm. Using a digital sensor, the display will indicate 'Leaking' or 'Normal'.

Leak Detect Setpoints

```
>01 LEAK DETECT GROUP #01
Leak Sensors:
  Sensor 1-1      Alarm Stpt: 00400 ppm
  Sensor 1-2      Alarm Stpt: 00400 ppm

  Sensor 1-3      Alarm Stpt: 00400 ppm
Scale Factor: 01250 ppm
Alarm Relay: 0-0
Alarm Delay: 000 secs
          **
```

Required Access Level: 2.

The Leak Detect setpoints screen allows the refrigerant leak detector to be assigned and alarm parameters programmed. The alarm value for the analog type sensors is typically set to 400 ppm. The scale factor for EIL supplied analog leak detectors is 1250. The Alarm time delay (max 300 secs) is the delay from when the leak is sensed above the alarm setpoint to when the alarm is generated.

Leak Detect Overview

LEAK DETECT OVERVIEW				
Num	Status	ppm	ppm	ppm
01	Normal	0	0	0
02	Normal	0	10	0

Required Access Level: None.

The Leak Detect Overview screen shows a complete overview of all configured systems. If analog sensors are used, all leak detector values (ppm) are shown along with a 'Normal' or 'Alarm' status. If digital sensors are used, a 'Normal' or 'Alarm' status is indicated along with a 'No Leaks' or a 'Leaking' indicator for the individual digital sensor.

Leak Detect Group Names

```
Leak Detect Group Names
01 LEAK DETECT GROUP #01
02 LEAK DETECT GROUP #02
03 LEAK DETECT GROUP #03
```

Required Access Level: None.

The Group Names area is used to assign a description for each system used. This should indicate the general areas where the sensors are located.

Leak Detect Sensor Names

```
>01 LEAK DETECT GROUP #01
1-1 Lk Snr Sensor 1-1
1-2 Lk Snr Sensor 1-2
1-3 Lk Snr Sensor 1-3
```

Required Access Level: None.

This area is used to assign descriptions and names for each individual sensor in a system. This should indicate precise locations for faster location of leaks when alarms occur.

Leak Detect Configuration

LEAK DETECT CONFIGURATION	
Number of groups (Max:4)	4
Leak sensor type	ANALOG

Required Access Level: 2.

The Leak Detect configuration enables you to select the number of refrigerant sensing systems and type of sensors used.

The most critical configuration field on this screen is the first one, which enables you to specify the number of systems used. As long as this number is '00', you will be unable to view the other screens listed on the Leak Detect menu.

Leak sensor type 'Analog' is used if the leak sensors are providing a 0-10 volt dc analog signal proportional to the ppm of refrigerant in a given area. If 'Digital' sensors are chosen, a contact closure indicates a refrigerant leak.

Logic Statement Menu

LOGIC STATEMENT MENU	
1-Status Names	4-Logic Statement
2-Setpoints	5-Sensor Names

Required Access Level: None.

The Logic Statement Menu is selected from the Aux Output Menu. It is the table of contents to the RC-1000's logic control statements, output configuration and control functions. If you intend to make any programming changes to screens on this menu, keep in mind that different levels of access code are required by the programmable data fields.

Logic Statement Status Screen

01 -BOL HOT WATER HEATER	
STATUS: FALSE	
OUTPUTS 1-1 OFF	
(AIGR1 0 F [>] AIGR2 0 F >=FALSE	
[OR] (Digital Inp Group <or >)=FALSE	
[OR] (Refer Input Group <or >)=FALSE	
#	Group Val. Eval. Name
1-1	AI-GR1 -30F (min) SENSOR 1-1

Required Access Level: None.

The Logic Statement Status screen title line consists of the logic statement number and user defined description. The data lines the this screen consist of status fields for all associated inputs and outputs assigned to the logic statement, including true/false conditions indicating whether the conditions of the statement are true or false. The STATUS line shows the overall status of the ENTIRE logic statement, either true or false depending on the condition of all logic lines contained in the statement. The true/false conditions further in the status screen only indicate the condition of the specific logic line associated next to the true/false condition. If the count operator is chosen to be used, an indication of the count will be displayed when active.

Logic Statements Setpoints Screen

01 -BOL		HOT WATER HEATER		
IF Analog [0-0	0-0	0-0	(min)]
> Analog [0-0	0-0	0-0	(avg)]
OR Digital[0-0	0-0	0-0	(or)]
	ON	ON	ON	
OR Ref Out[0-0	0-0	0-0	(or)]
	ON	ON	ON	
THEN Dig Out[0-0	0-0	0-0	(nrm)]
	ON	ON	ON	
Energized is	ON	ON	ON	
True if count equals (Min 2) 000				
Sensor Type	Lo-T	Setpoint	N/A	
Time Delay	010 Sec	Min on	000 Sec	
Log Alarm	No	Log Event	No	
Message (10 chars)	N/A			
Scale factor	N/A			
Clear latch input	N/A			
Logic is on from	00:00	to	00:00	
	* *			
	* *			

Required Access Level: 1+2

The Logic Statement Setpoint screen provides access to all programmable parameters affecting the control of outputs assigned to the logic statement. The title line of this screen consists of the logic statement number and the user defined description.

Logic statements are used to design a custom control system based on a variety of input and output configurations. The logic statement will over-ride the normal operating mode of an output if a logic statement output is assigned to an output being used elsewhere.

The fundamental logic statement, IF... THEN..., is the basis of these control statements. For example:

IF temp. sensor 1-1 is greater than (>) a setpoint of 50° THEN turn output outputs relays 1-1,1-2 and 1-3 ON. For clarity purposes this statement can be reduced as follows:

IF 1-1 > 50° THEN 1-1 + 1-2 + 1-3 ON

This is how the RC-1000 interprets and controls logic statements. A true result is when all conditions for a logic line or statement are met, otherwise a false result is returned. For example:

IF 1-1 > 50°

If the actual temp. from sensor 1-1 was 40° the statement would be false. Had the actual temp. been 65° the statement would be true.

Multiple analog inputs can have the following interaction on the logic control as follows:

AVG- Take the average of all sensors assigned.

MIN- Use the minimum value of any individual sensor assigned.

MAX- Use the maximum value of any individual sensor assigned.

STP-User defined setpoint value. No sensor used.

For example:

IF temp. sensor 1-1, 1-2, 1-3 averaged together is greater then (>) the setpoint of 50° THEN output relay 1-1 goes off

Can be reduced to:

IF 1-1 1-2 1-3 (AVG) > 50° THEN 1-1 off

In this statement the control would compare the setpoint of 50° to the AVERAGE of the three sensors 1-1, 1-2, and 1-3 and if that average was greater than the 50° setpoint then the output 1-1 would go off.

Digital inputs can be used as control points for logic statements. For example:

IF digital input 1-1 is on THEN turn outputs 1-1 and 1-2 on. This can be reduced to:

IF 1-1 on THEN 1-1 + 1-2 off

Multiple digital inputs can be combined in a single statement as follows:

AND- All digital inputs assigned must be true at the same time for the entire statement to be true.

OR- One or more digital inputs must be true for the entire statement to be true. As long as any one digital input is true the statement will be true.

XOR- Only one input at a time can be true for the entire statement to be true. If more than one input is true the statement will become false.

The condition of how the digital input reacts is set to either on or off. This depends on what type of signal is being used. For example: if assigned to ON, the condition will be true if the digital input is ON.

Analog inputs and digital inputs can be combined in a statement for a mixed logic statement. The individual analog input and digital inputs are set up the same but they can be combined as follows:

- AND- The analog input statement AND the digital input statement must both be true for the entire logic statement to be true.
- OR- Either the analog input statement OR the digital input statement OR both can be true for the entire logic statement to be true.
- XOR- Either the analog input statement OR the digital input statement must be true but NOT BOTH for the entire logic statement to be true.

One more element can be entered into the logic statement: Reference outputs. This allows the statement to react based on what the condition of a relay status that is assigned elsewhere in the unit for example: Circuit relay or a Rack output relay. This is labeled as REF OUT on the setpoint screen.

The logic is similar to that of digital inputs. An on/off status can be set indicating which way the reference relay is expected to be in for a true condition to exist. A choice is available to allow the logic statement to be true on any CHANGE for the relay state. For example: either on-to-off or off-to-on. This is abbreviated as CHG.

An example might be:

IF analog input temp. 1-2 is less than (<) setpoint of 100°
AND ref out (Circuit load) 1-1 is ON THEN output 1-2 comes on.

Let analog input 1-2 be water temp.

Let ref out be compressor 1-1.

Let output relay 1-2 be the water heater load.

This might be saying: IF the water heater temperature (1-2) is less than 100° AND compressor load (1-1) is on, THEN the water heater output load (1-2) stays on. IF the temp goes above 100° THEN the water heater load (1-2) goes off. Also, IF the reference relay is off indicating an off condition, THEN the water load (1-2) goes off.

As illustrated, the logic statements can be simple or complicated depending on the conditions required to react on. Care must be taken that each statement is thought out completely to insure correct operation.

Outputs from the logic statements can be set on/off and the energized state can be set on/off. The only restriction is when using an output assigned elsewhere, the energized on/ energized off state must be the same.

The way the outputs react can be programmed for several conditions, depending on the needs of the user and equipment being controlled:

- NRM- Normal on to off change of state when a true condition occurs in the logic statement.
- CHG- Changes the output on-to-off or off-to-on depending on the last state of the relay, when a true condition occurs.
- SHD- Normal change of state with more than one assignment to a relay. This is for sharing control of a relay. This selection can turn a load off but cannot turn it back on.
- MTY- Momentarily energizes the output for approx. 5 seconds when a true condition occurs for the logic statement.
- LCH- Normally changes and latches the output relay when a true condition occurs for the logic statement. This condition must be cleared from the 'Clear Latch Menu', or via the digital input clear latch input.

The ability of the logic statement to count true occurrences is set by the 'True if count equals' setpoint. Enter the number desired for the logic statement to operate on. When the evaluation of the statement sees that number of true occurrences the entire statement will be true.

Sensor types are set from the following list:

- Lo-T Low Temperature ranges: -30' to 97'
- Hi-T High Temperature ranges: 0' to 255'
- Lo-P Low Pressure ranges: 0 to 100 lbs.
- Hi-P High Pressure ranges: 0 to 500 lbs.
- KW Kilo-watt input: 0 to 10 vdc
- 10V 0 to 10 vdc
- Lite Analog light level sensor: 2.55 to 3.09 vdc
- Leak Analog refrigerant leak sensor: 0 to 10 vdc

These settings must agree with the type of board installed and the sensor assignments used.

The setpoint value is programmed when SPT is selected for analog comparison in the logic statement. If SPT is not used in the logic statement, no entry is permitted and the display will show 'N/A'

'Time delay' allows a programmable time delay to be set before an output reaction occurs. This can be used for anti-short cycling or to prevent transient changes in output.

The 'Min on' time is the minimum time that the outputs will be on regardless of the evaluation of the statement.

'Log alarm' and 'Log event' yes/no settings allow logging to be enabled or disabled for the logic statement. When the logic statement changes state a log is recorded which identifies the description, time, date, and a user defined message.

'Message' is the user defined identification for the logic statement. (max 10 characters) If the alarm and event logs are set to NO, this area will display N/A.

The 'Scale fact' setpoint is used when a KW or LEAK type of input is being used. This value scales the kw reading for 0 to the maximum (Scale Fact) value.

'Clear latch input' provides for a digital input to be used for clearing a logic statement once it has been latched. This is useful for a remote switch or button to reset the logic statement.

Each logic statement can be operational based on a time of day schedule. The times that the logic statement is desired to be active is set by the 'Logic is on from' setpoint area. Enter a starting and ending time in 24 hour format. If the logic statement is not active based on the TOD schedule, the status field will indicate: 'STATUS: False on time'. Since the statement is not being evaluated, the status screen will not update the data in the 'OUTPUTS' area.

Logic Statement Names

LOGIC STATEMENT NAMES	
01	HOT WATER HEATER
02	SUB COOLER TEMP
03	LIQUID LEVEL

Required Access Level: 1

The logic statement names screen allows you to enter descriptive names for each of the logic statements configured. Both numeric and alphabetic data entry is permitted.

Logic Statement Clear Latch

CLEAR LATCH	
01	HOT WATER HEATER OFF
02	SUB COOLER TEMP OFF
03	LIQUID LEVEL OFF

Required Access Level: 1

If the digital output is set up to latch (lch) when a logic statement is true, this screen allows the user to clear the latching and reset the output to normal condition through the keypad.

The cursor is moved to the appropriate statement number latched condition. Press 'ENTER' and use the up and down arrows to toggle the condition on-to-off.

Logic Statement Sensor Names

01 -BOL	HOT WATER HEATER	
1-1 Sensor	HEATER TEMP	
1-2 Sensor	OUTPUT TEMP	
1-3 Sensor	INPUT TEMP	
0-0 Sensor	*** unused ***	
0-0 Sensor	*** unused ***	
0-0 Sensor	*** unused ***	
0-0 Dig-In	*** unused ***	
0-0 Dig-In	*** unused ***	
0-0 Dig-In	*** unused ***	

Required Access Level: 1

The sensor names screen allows you to enter descriptive names for each sensor and input assigned to a logic statement. Both numeric and alphabetic data entry is permitted.

Logic Statement Configuration

LOGIC STATEMENT CONFIGURATION	
Number of Logic Stms.....	03 (max: 32)

Required Access Level: 1

The logic statement output configuration screen allows you to specify the number of logic statements that the RC-1000 is to control. As long as the value of this field is '00', you cannot view the other screens listed on the logic statement menu.

OVERRIDE MENU

OVERRIDE MENU	
1-Temp Control	4-Digital Outputs
2-Alarm	5-Digital Inputs
3-Override Log	6-Sensor Offset

Required Access Level: None.

The Override Menu is selected from the RC-1000 Main Menu. It is the table of contents to the RC-1000's I/O control override functions. Level-1 access is required to override any output or input controlled by the RC-1000.

Temp Control Override Screen

01 CIRCUIT A01
Temp control override time 050m

Required Access Level: 1.

The Temp Control Override Screen enables you to set the duration of a temperature control override, i.e. turn refrigeration on for a specified length of time. (Valid range is 0 to 999 minutes) Entering a value of '999' results in a permanent override condition that can only be cleared from this screen. Note that defrost functions normally (time/time) during this override condition.

Alarm Override

01 CIRCUIT A01

Alarm override time 050m

Required Access Level: 1.

The Alarm Override Screen enables you to initiate and set the duration of a CIRCUIT alarm override. (Valid range is 0 to 9999 minutes) Entering a value of '9999' results in a permanent override condition.

Override Log

Override Log

01-01	05:43	Bd:1	Ch:1	Rly Ovr	Clr
01-01	05:30	Bd:1	Ch:1	Rly Ovr	Off
01-01	02:30	Bd:4	Ch:2	Rly Hrd	Ovr

Required Access Level: 1.

The Override Log Screen enables you to view a list of any hard or soft overrides that have occurred. The date and time the override was initiated and when it was cleared.

Digital Output Override Screen

Board>1 DIGITAL OUTPUT OVERRIDES			
1-1 none	1-2 none	1-3 none	1-4 none
1-5 none	1-6 none	1-7 none	1-8 none

Required Access Level: 1.

The Digital Output Override Screen provides the capability to override individual digital outputs on a board-by-board basis. Note that for any given relay, the override switch supersedes an active software override (see Fig. 1 - Relay Interface Diagram).

Digital output overrides are performed in the following manner:

- a) select desired board by using left arrow and right arrow keys.
- b) press 'enter' and select desired output/input by using arrow keys.
- c) press 'enter' and use up arrow or down arrow key to select 'on', 'off', or 'none'.
- d) when correct override is selected, press 'enter' followed by the 'exit' key.

Important: All overrides will remain in override unless removed by the same process used to program the override. Override conditions on/off will depend on the assignment of the load, and does not indicate the relay being energized or de-energized.

Digital Input Override Screen

Board>1	DIGITAL INPUT OVERRIDES							
1-1	none	1-2	none	1-3	none	1-4	none	
1-5	none	1-6	none	1-7	none	1-8	none	

Required Access Level: 1.

The Digital Input Override Screen provides the capability to override the status of individual digital inputs on a board-by-board basis.

Digital input overrides are performed in the following manner:

- a) select desired board by using left arrow and right arrow keys.
- b) press 'enter' and select desired output/input by using arrow keys.
- c) press 'enter' and use up arrow or down arrow key to select 'on', 'off', or 'none'.
- d) when correct override is selected, press 'enter' followed by the 'exit' key.

Important: All overrides will remain in override unless removed by the same process used to program the override. Override conditions on/off will depend on the assignment of the load, and does not indicate the relay being energized or de-energized.

Sensor Input Offset Screen

Board>1		SENSOR INPUT OFFSET					
SNSR 1:	0	2:	0	3:	0	4:	0
5:	0	6:	0	7:	0	8:	0
Type: Temp Units: F							

Required Access Level: 1.

The Sensor Input Offset Screen provides the capability to add or subtract from data from any sensor. The addition or subtraction is done, board by board, in the temperature units (indicated at bottom of screen) corresponding to the type of board. To access, select the board that contains the sensor. Then, using the arrow keys, select the specific input number. Press 'ENTER' and program the value of offset desired. To return a sensor to normal operation, enter '00' as offset. The bottom line of this screen indicates the type of board configured (e.g. temp, pressure, etc.) and the units being used by that board.

LOG MENU

LOG MENU	
1-Run Time Log	4-Event Log
2-Note Log	5-Power Log
3-Alarm Log	6-I/O Logs

Required Access Level: None.

The Log Menu is selected from the RC-1000 Main Menu. It is the table of contents to the RC-1000's system status and performance logs.

Run Time Log Menu

RUN TIME LOG MENU	
1-Circuit Log	
2-Rack Log	

Required Access Level: None.

The Log Menu is selected from the RC-1000 Main Menu. It is the table of contents to the RC-1000's system status and performance logs.

Circuit Log Screen

01 CIRCUIT A01	
Total refrigeration cycles	345
Refrigeration cycles today	10
Refrigeration cycles yesterday	27

Required Access Level: None.

The Circuit Log Screen displays the number of refrigeration cycles recorded for the following time periods: since system start-up; since 00:00:01 a.m. of the current day; over the previous 24-hour day (00:00:01 to 23:59:59). These values can be reset with level-2 access by choosing the desired field and pressing 'ENTER'.

Rack Log Screen

01 RACK A				
Unit		Today	Yesterday	Total
Compr	1	01:23h	03:17h	000429h
Compr	2	00:47h	02:41h	000356h
Compr	3	00:33h	02:08h	000311h
Compr	4	00:30h	02:14h	000309h
Compr	5	00:00h	00:00h	000000h
Compr	6	00:00h	00:00h	000000h
Compr	7	00:00h	00:00h	000000h
Compr	8	00:00h	00:00h	000000h
Compr	VS	00:00h	00:00h	000000h
Fan	1	05:13h	15:34h	001023h
Fan	2	04:48h	13:56h	000998h
Fan	3	04:23h	13:01h	000897h
Fan	4	04:07h	12:79h	000874h
Fan	5	00:00h	00:00h	000000h
Fan	6	00:00h	00:00h	000000h
			**	
			**	

Required Access Level: None.

The Rack Log Screen displays the recorded run-times of refrigeration rack compressors and fans for the following time periods: since 00:00:01 a.m. of the current day; over the previous 24-hour day (00:00:01 to 23:59:59); since system start-up. These values can be reset with level-2 access by choosing the desired field and pressing 'ENTER'.

Note Log

Note Logs:	
Enter Modifications (max 36 char):	
1)	
2)	
3)	
4)	
5)	
6)	
7)	
8)	
9)	
10)	
	**
	**

Required Access Level: 1.

The Note Log Screen enables you to enter up to 10 descriptive lines of information relating to the RC-1000. This can be used for changes, or more descriptive information about equipment hooked to the unit. This can be used for remotely monitoring any changes made or to send messages from the remote terminal to a service mechanic at the RC-1000.

Alarm Log Screen

ALARM LOG		
01-03 08:45	RACK A	Power fail ok
01-03 08:40	RACK A	Power fail
**		
**		

Required Access Level: None.

The Alarm Log Screen displays a list of up to fifty recorded system alarms of the following types: 'Hi temp', 'Lo temp', 'Hi suct p', 'Lo suct p', 'Phase loss', 'Run verify', 'Liq level', 'Oil fail', 'Dial Fail', 'Oil pres', 'Hi head p', 'Lo head p', 'Power fail', and 'Power up'.

Each line of the Alarm Log Screen consists of the date and time of the occurrence, the name of the affected rack or circuit, and the type of alarm. When an alarm condition is rectified, an updated alarm log entry is displayed with the word 'ok' following the alarm type.

Event Log Screen

EVENT LOG		
01-03 08:11	CIRCUIT A01	Temp term
01-03 08:00	CIRCUIT A01	Emrg defr
**		
**		

Required Access Level: None.

The Event Log Screen displays a list of up to fifty recorded system events of the following types: emergency defrost, defrost skip (dewpoint), clear log (indicates that the I/O logging has been cleared) and miscellaneous other non-alarm events.

Each line of the Event Log Screen consists of the date and time of the occurrence, the name of the affected rack or circuit, and the type of event.

POWER LOG MENU

POWER LOG MENU	
1- Power: Hourly	
2- Power: Daily	

Required Access Level: None

The Power Log Menu is selected from the RC-1000 Log Menu. It is the table of contents for the power logs.

Hourly Power Log Screen

>1 RACK A	KWH	Peak KW
Fri Time: 10:00	221	183 KW @ 10:12
Fri Time: 09:00	243	190 KW @ 09:23
Fri Time: 08:00	225	175 KW @ 08:57

Required Access Level: None.

The Hourly Power Log Screen displays up to twenty-five hours of power consumption data for each configured refrigeration rack.

Each line of the Hourly Power Log Screen consists of the starting time of the logging period, the total power consumption for that period, the peak power consumption level for that period, and the time at which the peak occurred.

Daily Power Log Screen

>1 RACK A	KWH	Peak KW
Date: 01-22	3478	532 KW @ 09:12
Date: 01-21	3404	519 KW @ 09:47
Date: 01-20	3463	529 KW @ 09:23
Date: 01-19	3396	515 KW @ 10:37
Date: 01-18	3141	473 KW @ 11:09
	**	
	**	

Required Access Level: None.

The Daily Power Log Screen displays up to forty-eight days of power consumption data for each configured refrigeration rack.

Each line of the Daily Power Log Screen consists of the log entry date, the total power consumption for that day, the peak power consumption level for that day, and the time at which the peak occurred.

I/O LOG MENU

I/O LOG MENU

1- ANALOG INPUTS	3- DIGITAL INPUTS
2- ANALOG OUTPUTS	
3- DIGITAL OUTPUTS	

Required Access Level: None

The Interval Log Menu is selected from the RC-1000 Log Menu. It is the table of contents for the interval logs.

I/O Log-Analog Input; Analog Output; Digital Output; Digital Input

INTERVAL LOG

1- SELECT BOARD & CHANNEL
2- DISPLAY DATA

Required Access Level: None

The Interval Log selection allows the user to display a historical record of the analog inputs, analog outputs, and digital outputs. To access, select '1' from the menu and select the appropriate channel for the desired input/output. Exit '1', and select '2' from the menu to display the data, which is set up in page format. Times on the left-hand side correspond to the current time and previous times based on the logging interval chosen. Each line contains four data records. The total number of data records is dependent upon the logging interval and the total number of inputs/outputs assigned.

EMERGENCY DEFROST SCREEN

01 CIRCUIT A01	
1 Normal	
2 Time only	State: Refr off
3 End defrost	

Required Access Level: None.

The Emergency Defrost Screen enables you to initiate or return to the programmed defrost control by placing the cursor next to the desired action and pressing the 'ENTER' key. The status of the particular circuit will be displayed beside the state. The circuit status and event log will show emergency defrost as "EMG _ _ _m" and the number of minutes left in the defrost. The case temperature must be below the termination temperature before initiating a normal defrost, or it will immediately terminate.

SYSTEM MENU

SYSTEM	
1-Date / Time	4-I/O List
2-Dlite Savings	5-Access codes
3-Alarm Dial Out	6-System Config

Required Access Level: none.

The System menu is selected from the RC-1000 Main Menu. It is a table of contents to the RC-1000's miscellaneous system configuration and status screens. Note that level-1 access is required to program the screens on this menu. A level-2 access code is required to change or view the access codes screen.

Date & Time Screen

DATE & TIME
Date 08-24-88 Mon
Time 11:05:04 DT

Required Access Level: 1.

The Date & Time Screen enables you to set the RC-1000 system clock. Note that changes to the RC-1000 system clock may have an immediate effect on any time-driven events. A "DT" or "ST" to the right of the time reflects whether the time is in Daylight Savings Time or Standard Time. Remember, the time must be in military time. Press 'enter' to bring arrow on to display and enter data.

Daylight Savings Screen

DAYLIGHT SAVINGS
Spring forward on first Sun after 04-01
Fall back on first Sun after 10-25

Required Access Level: 1.

The Daylight Savings Screen enables you to specify the dates on which daylight savings time starts and ends. The system clock is adjusted accordingly on those dates. Press 'enter' to bring arrow on to display and enter data.

Alarm Dial Out Menu

Alarm Dial Out	
1-Phone Numbers	3-Dial Log
2-Alarm Setup	4-Miscellaneous

Required Access Level: None.

The Alarm Dial Out menu is selected from the RC-1000 System Menu. It is a table of contents to the RC-1000's alarm dial out and selectable alarm dial out screens. Note that level-1 access is required to program the sub-screens on this menu.

Alarm Phone Numbers Screen

```
1 Grp 1
Unoccupied Phone #s  Occupied Phone #s
>1-800-555-1234      >1-800-555-4321
>555-1212            >555-2000
```

>555-0101

>555-2525

Occupied Schedule

Sun From: 00:00	To: 00:00
Mon From: 08:00	To: 05:00
Tue From: 08:00	To: 05:00
Wed From: 08:00	To: 05:00
Thu From: 08:00	To: 05:00
Fri From: 08:00	To: 05:00
Sat From: 08:00	To: 12:00

**

**

```
1 Grp 2
Unoccupied Phone #s  Occupied Phone #s
>1-800-555-1234      >1-800-555-4321
>555-2468            > 555-2000
```

>555-0101

>555-2525

Occupied Schedule

Sun From: 00:00	To: 00:00
Mon From: 08:00	To: 05:00
Tue From: 08:00	To: 05:00
Wed From: 08:00	To: 05:00
Thu From: 08:00	To: 05:00
Fri From: 08:00	To: 05:00
Sat From: 08:00	To: 12:00

**

**

Required Access Level: 1.

The Alarm Phone Numbers Screens enables you to specify several phone numbers to be used for alarm dial-out by the RC-1000. Two groups are provided for maximum flexibility in setting up a dial out system. Each system on the RC-1000 can be configured to dial to one or both groups. During an alarm state, the RC-1000 will attempt to dial out to either a remote serial printer or a dumb terminal. In addition to sending the alarm information, a device ID, up to 30 characters long, is transmitted. If the phone number is local, it is not necessary to enter an area code. Press 'enter' to bring the arrow to the desired display area and enter data.

Dialout dials the 'Occupied Phone #s' during the occupied schedule times. 'Unoccupied Phone #s' are dialed at all other times or if the occupied scheduled stop time for the current day is 00:00. All numbers are dialed regardless of whether or not the modem picked up on the previous number. If an alarm occurs and Dialout has not completed before the time changes from occupied to unoccupied, Dialout will stop trying to call the unoccupied numbers and start calling the first occupied number. If a new alarm occurs during a dialout sequence, the RC-1000 will add the new alarm to the numbers left to be dialed out and then redial any numbers which did not receive the new alarm.

If a local printer is connected for alarm printouts use a phone number of "LO". This feature is only available with a special communications interface card and special wiring hookup. Consult the factory for more information.

Dialout is effectively disabled if there is not a valid phone number in the list for the specified time of day. Phone numbers must be entered in order starting at the top of each list. All numbers must be left justified.

24 hours is the maximum amount of 'on' time in any given day. Keep in mind that the RC-1000 uses military time (e.g., 04:00 = 4:00 a.m., 16:00 = 4 p.m.). If a start time equals a stop time, nothing will happen. 00:00 is a valid start time, but not a valid stop time.

Alarm Setup Menu

Alarm Setup	
1- Circuit Menu	4- Logic Statements
2- Rack Menu	5- System
3- Leak Detect	

Required Access Level: None.

This menu allows access to selection of the types of alarms that will initiate an alarm dial out sequence. Enter the desired field and proceed to set up each system on the RC-1000.

Circuit Alarm Setup

>1 24' Ice Cream Doors				
Alarm type	Local	Grp1	Grp2	Delay

High Temperature	NO	YES	YES	001m
Low Temperature	NO	YES	NO	001 m
Valve Verify	NO	YES	NO	001 m
OK (Cleared)	NO	YES	NO	001 m
	**			
	**			

Required Access Level: 1.

This screen allows setup of the dial out parameters by each individual circuit. The first line shows the circuit name as described in the circuit names screen. There are as many pages of dial out screens as there configured circuits. To go to other circuits use the right and left arrows. The categories for dial out are 'Local' which enables a locally connected dumb terminal or printer, 'Grp 1' enables or disables the phone numbers and time of day schedule for group 1, 'Grp 2' enables or disables the phone numbers and time of day schedule for group 2, and 'Delay' is the delay between dialouts of each phone number. If grp 1 and grp 2 are not being used, the 'Delay' fields will show 'N/A'. This delay does not apply to local.

'High Temperature' is the circuit high temp alarms
'Low Temperature' is the circuit low temp alarms
'Valve Verify' is the circuit valve verification alarm
'OK (Cleared)' is the OK indication the an alarm is cleared

Rack Alarm Setup

>01 Medium Temp Rack				
Alarm Type	Local	Grp1	Grp2	Delay
-----	----	----	----	-----
High Pressure	NO	YES	NO	001 m
Low Pressure	NO	NO	YES	010 m
Run Verify	NO	YES	NO	010 m
Miscellaneous	YES	YES	YES	010 m
OK (Cleared)	NO	NO	NO	
	**			
	**			

Required Access Level: 1.

This screen allows setup of the dial out parameters by each individual rack. The first line shows the rack name as described in the rack names screen. There are as many pages of dial out screens as there are configured racks. To go to other racks use the right and left arrows. The categories for dial out are 'Local' which enables a locally connected dumb terminal or printer, 'Grp 1' enables or disables the phone numbers and time of day schedule for group 1, 'Grp 2' enables or disables the phone numbers and time of day schedule for group 2, and 'Delay' is the delay between dialouts of each phone number. If grp 1 and grp 2 are not being used, the 'Delay' fields will show 'N/A'. This delay does not apply to local.

'High Pressure' is the rack high pressure alarms.

'Low Pressure' is the rack low pressure alarms.

'Run Verify' is the compressor and condenser fan run verification alarms.

'Miscellaneous' alarms are phase loss, low liquid level and oil pressure.

'OK (Cleared)' is the OK indication that an alarm is cleared.

Leak Detect Alarm Setup

Name	Leak Detect				Delay
	Local	Grp1	Grp2		
Compressor Room	NO	YES	NO		000 m
Leak Group #2	NO	YES	NO		001m
OK (Cleared)	NO	NO	NO		
	**				
	**				

Required Access Level: 1.

This screen allows setup of the dial out parameters by each individual leak detect group. The description under 'Name' shows the leak detect name as described in the leak detect names screen. There is only one page of this dial out screen. The categories for dial out are 'Local' which enables a locally connected dumb terminal or printer, 'Grp 1' enables or disables the phone numbers and time of day schedule for group 1, 'Grp 2' enables or disables the phone numbers and time of day schedule for group 2, and 'Delay' is the delay between dialouts of each phone number. If grp 1 and grp 2 are not being used, the 'Delay' fields will show 'N/A'. This delay does not apply to local.

Since there is only one type of alarm generated by the leak detect groups, each group is only configurable for the local and phone number groups.

'OK (Cleared)' is the OK indication that an alarm is cleared.

Logic Statements Alarm Setup

Logic Statements				
Name	Local	Grp1	Grp2	Delay
-----	-----	-----	-----	-----
Logic Rung #1	No	Yes	Yes	010 m
Logic Rung #2	NO	YES	NO	010m
High Comp Shtdwn	YES	YES	YES	010m
-----	-----	-----	-----	-----
OK (Cleared)	NO	NO	NO	
	**			
	**			

Required Access Level: 1.

This screen allows setup of the dial out parameters by each individual logic statement group. The description under 'Name' shows the logic statement name as described in the logic statement names screen. There is only one page of this dial out screen. The categories for dial out are 'Local' which enables a locally connected dumb terminal or printer, 'Grp 1' enables or disables the phone numbers and time of day schedule for group 1, 'Grp 2' enables or disables the phone numbers and time of day schedule for group 2, and 'Delay' is the delay between dialouts of each phone number. If grp 1 and grp 2 are not being used, the 'Delay' fields will show 'N/A'. This delay does not apply to local. If the logic statement is not configured for alarming from the setpoint screen, all these fields will show 'N/A'.

Since there is only one type of alarm generated by the logic statement groups, each group is only configurable for the local and phone number groups.

'OK (Cleared)' is the OK indication that an alarm is cleared.

System Alarm Setup

Select System Alarms			
Alarm Type	Local	Grp1	Grp2
-----	-----	-----	-----
Override	NO	YES	NO
Miscellaneous	NO	YES	YES
OK (Cleared)	NO	NO	NO
	**		
	**		

Required Access Level: 1.

This screen allows set up of system related alarms for dial out. Each category can be set up for local and dial out phone number groups.

'Override' is any override condition (either hard or soft)

'Miscellaneous' alarms are power up, power fail, low battery and master clear.

'OK (Cleared)' is the OK indication that an alarm is cleared.

Dial Log

Dial Log		
10-02 12:05	Ice Cream Case	Unocc1 #1
10-02 04:30	Rack B	Occup2 #1
10-01 23:50	Rack B	Modem Fail OK
10-01 23:30	Rack B	Modem Fail
**		
**		

Required Access Level: None.

This screen shows a list of all dial out attempts, whether they are successful or not. This should provide a check that alarms have been sent and to which numbers. If there are failures the source of the problem can be tracked by this log.

Each line of the log will indicate the date and time the dial out occurred, the alarm source (rack, circuit, logic statement, etc.), the phone number associated with that alarm type and which group it was set up under.

'Unocc1 #1' is the 1st unoccupied number in group #1.
'Unocc2 #1' is the 2nd unoccupied number in group #1.
'Unocc3 #1' is the 3rd unoccupied number in group #1.
'Unocc1 #2' is the 1st unoccupied number in group #2.
'Unocc2 #2' is the 2nd unoccupied number in group #2.
'Unocc3 #2' is the 3rd unoccupied number in group #2.
'Occup1 #1' is the 1st occupied number in group #1.
'Occup2 #1' is the 2nd occupied number in group #1.
'Occup3 #1' is the 3rd occupied number in group #1.
'Occup1 #2' is the 1st occupied number in group #2.
'Occup2 #2' is the 2nd occupied number in group #2.
'Occup3 #2' is the 3rd occupied number in group #2.

'Modem Fail' means the modem at the RC-1000 failed to call out. (ie: phone line bad or modem problem)

'Dial Fail' means the modem dialed out but did not get a correct answer. (ie: busy signal or remote printer modem failure)

Miscellaneous

Miscellaneous	
Device ID:	Store 189 RC-1000
Dial Test Choice:	None
Retry Dialing in (0-24):	01 hrs
Time Between Dialing	60 min
Modem Cmd:	EOVOX1
Daily Dialout Grp1:	1: 01:00 2: 13:00
Daily Dialout Grp2:	1: 01:15 2: 13:15
Gr 1 Name:	Grp1
Gr 2 Name:	Grp2
	**
	**

Required Access Level: None.

This screen allows data entry of miscellaneous alarm related parameters. The first line is the user defined 'User ID'. This can be up to 30 characters. The next line selects the 'Dial Test Choice'. This is either: None, All, Local, Grp1, or Grp2. This selects which numbers will be used for an immediate, one time dial out test. The dial out test includes the RC-1000 unit number ID, then the user defined store identification, the current date and time, the date and time of the dial out test, and a tally of alarms recorded that day. 'Retry Dialing in' selects the time allowed before the RC-1000 will retry dialing out alarm data after a modem failure. If 'Retry Dialing' time is set to '00', the RC-1000 will not retry dial out until a new alarm is received. The 'Time Between Dialing' is used to set a time delay between dialing alarms when a modem error is encountered. The unit will wait this time period before attempting to redial an alarm. 'Modem Cmd' sets a user defined modem command string. This is useful when using modems that do not have dip switches to set parameters. 'Daily Dialout' is the times each day that the groups will perform a dial out test. 'Grp x Names' are the user defined dial out group names (up to 24 characters)

The RC-1000 will try each number five times before noting a failure. If a number fails, the RC-1000 will continue to the next number. This will continue until five failures occur on any number. This failure is then logged.

Remote alarm printer setup:

Serial Interface

7 data bits

(8 bits may be required in some applications)

1 stop bit

No parity

Baud rate set the same as the RC-1000

Remote modem settings are the same as the RC-1000 modem except the Optima 2400 setup string should be:

AT&K0&Q0V0S0=1&W

(refer to the section on 'Modem Switch Settings')

I/O List Menu

```

                                I/O LIST MENU
1-Analog Inputs      4-Digital Outputs
2-Analog Outputs
3-Digital Inputs
```

Required Access Level: None.

The I/O List menu is selected from the System Menu. It is a table of contents to the RC-1000's I/O list screens. These screens provide a board-by-board I/O map detailing all current RC-1000 relay, analog output, sensor, and input assignments.

Analog Input List Screen

```

Board>1      ANALOG INPUTS
1-1  1 Lo T  SENSOR 1-1
1-2  1 Hi T  SENSOR 1-2
1-3  1 Lo T  SENSOR 1-3

1-4  1 Lo T  SENSOR 1-4
1-5  1 Hi T  SENSOR 1-5
1-6  1 Lo T  SENSOR 1-6
1-7  1 Lo T  SENSOR 1-7
1-8  1 Lo T  SENSOR 1-8
      **
      **
```

Required Access Level: None.

The Analog Input List Screen is a board-by-board view of the current RC-1000 temperature and pressure sensor assignments. The title line consists of the board number and the screen title.

Each data line describes a sensor as follows: its board-channel number; the number of logical inputs to which the sensor is assigned; the sensor type; the user-defined sensor name.

Analog Outputs List Screen

```
Board>1      ANALOG OUTPUTS
1-1 Comprsr speed  VARUNIT RACK A
1-2 Comprsr speed  VARUNIT RACK B
1-3 Comprsr speed  VARUNIT RACK C
1-4 Comprsr speed  VARUNIT RACK D
1-5 unused
1-6 unused
1-7 unused
1-8 unused
```

```
**
**
```

Required Access Level: None.

The Analog Output List Screen is a board-by-board view of the current RC-1000 variable-speed compressor control assignments. The title line consists of the board number and the screen title.

Each data line describes a control output as follows: its board-channel number; the output type; the user-defined name of the associated compressor rack.

Digital Input List Screen

```
Board>1          DIGITAL INPUTS
1-1 Defrost init  CIRCUIT A01
1-2 Defrost term  CIRCUIT A01
1-3 Aux setpoints  RACK A

1-4 Phase ok      RACK A
1-5 Liquid level  RACK A
1-6 Defrost input  RACK A
1-7 Oil pressure  RACK A
1-8 Comprsr 1     RACK A
                  **
                  **
```

Required Access Level: None.

The Digital Input List Screen is a board-by-board view of the current RC-1000 digital input assignments. The title line consists of the board number and screen title.

Each data line describes a digital input as follows: its board-channel number; the input type; the user-defined name of the associated circuit or rack.

Digital Output List Screen

Board>1			DIGITAL OUTPUTS		
1-1	1	Compr 1	RACK A		EON
1-2	1	Compr 2	RACK A		EON
1-3	1	Compr 3	RACK A		EON
1-4	1	Compr 4	RACK A		EON
1-5	1	Compr 5	RACK A		EON
1-6	1	Compr 6	RACK A		EON
1-7	1	Compr 7	RACK A		EON
1-8	1	Compr 8	RACK A		EON
			**		
			**		

Required Access Level: None.

The Digital Output List Screen is a board-by-board view of the current RC-1000 relay assignments. The title line consists of the board number and screen title.

Each line describes a relay as follows: its channel number; the number of logical outputs to which the relay is assigned; the type of output to which the relay is assigned; the output number; and the user-defined name of the rack or circuit associated with the relay.

The field shown along the right side of the screen indicates whether a relay is programmed for energized-on or energized-off use.

Access Codes Screen

ACCESS CODES	
Level 1	1234
Level 2	9876

Required Access Level: 2.

The Access Codes Screen enables you to redefine the level-1 and level-2 access codes of your RC-1000. Level-2 access is required to view and change these data fields.

The security of the RC-1000 refrigeration control system depends on the proper use and discretionary distribution of these access codes. If at any time you think that the security of your system has been compromised and is at risk of malicious tampering, immediately change these codes. Press 'enter' to bring arrow on to display and enter data.

System Configuration Menu

```
System Configuration Menu
1- Miscellaneous
2- Temp Board Config
3- Master Clear
```

Required Access Level: None

The System Configuration Menu is selected from the System Menu. It is the table of contents for system related functions.

Miscellaneous Parameters Screen

```
MISCELLANEOUS PARAMETERS
Communication ID  001
Temp units  F      Line Freq 60H
Logging interval 180  Size 64k
Baud 1200
Maximum logging period 130 hrs
**
**
```

Required Access Level: 2.

The Miscellaneous Parameters Screen enables you to view the view and change the miscellaneous parameters of the RC-1000.

The 'Communications ID' must be set by a dip switch on the cpu board (see figure 24 and page 3). The first unit in the communications loop should have ID number 1. If more than one series 1000 unit is present, each unit must have a different communications ID for successful remote communications.

You can select the temperature units to be displayed by the RC-1000: C = Celsius; F = Fahrenheit. (default is F). Press 'ENTER' to toggle this field.

For those locations that have power at 50 hz, the Line Freq option can be changed to allow correct operation of time variable tasks. (default is 60hz). Press 'ENTER' to toggle this field.

The 'Logging interval' field sets the interval in seconds between recording all logs. The minimum setting is 15 seconds and the maximum setting is 9000 seconds. Typical logging intervals would be between 180 and 300 seconds. (default is 0180s) To change parameters, bring arrow on to the desired field, press 'enter' and enter data.

The 'Size' parameter indicates the amount of logging memory available. It will either be the standard 64K or if an expanded RAM chip is installed it will be 192K. This is not changeable from this screen.

The 'Baud' indicates the baud rate the RC-1000 is operating with. It is set by DIP switch. (see figure 24 and page 3). This is not changeable from this field. Be sure this setting matches the modem installed.

'Maximum logging period' indicates the maximum amount of time that data will be logged in the RC-1000 memory. It is dependent on three factors: the size of the logging memory, the logging interval and the number of I/O points entered. This number will change based on any change of the above three factors. The easiest way to obtain longer logging time is to add an additional memory chip to allow the maximum 192k memory. (refer to the parts list)

Temperature Board Configuration

Temp Board Config			
Brds 1:Lo-T	2:Lo-P	3: 10v	4:Lo-T
5:Lo-T	6:Lo-T	7:Lo-T	8:Lo-T

Required Access Level: 2

The Temperature Board Configuration screen allows the user to change the low temperature board configuration (-30° to 97°) to high temperature (0° to 255°). Select the desired board and press 'ENTER' to toggle from Lo-T to Hi-T. A specially calibrated high temperature input card must be used for Hi-T operation. Use of an incorrect input card will result in invalid readings.

If a board is configured for a function other than temperature, (ie: pressure or 0-10v) the function type will be displayed on the bottom line. This is for information only and are not changeable.

Master Clear Screen

Master Clear
Select the Reset Function: No Action

Required Access Level: 2

This screen allows either a soft reset or master clear from the keypad. To use either function, press enter and use the up and down arrows to select 'Reset', 'Master Clear' or 'No Action', then press enter to accept. When this screen is exited, the desired function will occur within a few seconds. The reset is the same as if the power was turned off and back on again. A master clear will clear ALL the memory and restore default parameters.

**CAUTION: A MASTER CLEAR WILL DESTROY ALL DATA.
USE THIS FEATURE AS A LAST RESORT.**

CHAPTER 4 - TROUBLESHOOTING

EIL RC-1000 SOFTWARE VERSION X.XX
*** CONTROL NOT CONFIGURED ***
Enter Access Code: _

If the above screen appears in the display, it is an indication that the RC-1000 unit has one of the following conditions:

1. The unit is new and has never been configured or programmed.
2. The internal 'Watchdog' circuit has received non-conforming internal data and has initiated a complete reset (master clear).

MASTER CLEAR PROCEDURES

IMPORTANT: Invoking the Master Clear function destroys all existing data. Therefore, Master Clear should be used as a last resort.

Hardware method:

1. Remove metal plate from RC-1000 door.
2. Place non-conductive material between battery and retaining clip on top of battery.
3. Turn switch OFF (see figure 4).
4. Leave unit de-powered for a minimum of three minutes.
5. Turn switch ON and remove material from under the battery clip.
6. The above screen should then appear in the display.

Software Method:

1. Go to the master clear screen.
2. Toggle the field to 'Master Clear'.
3. Exit from this screen.
4. Within seconds, the RC-1000 will master clear.

RC-1000 POWER

Transformer connection terminals, fuses, and ON/OFF switch are located on the CPU Board, which is behind the metal plate on the door of the unit (see figure 4).

Checkpoints:

Plug terminals - 12 VAC supplies the CPU Board and is fused with an on board 2 AMP slow-blow fuse.

Procedure:

1. Make sure that the power switch on CPU Board is turned on.
2. Check voltage through the fuses:
 - a) Set meter for AC voltage.
 - b) Read power terminal #1 (from top) to top part of fuse; voltage should read 12 VAC.

TEMPERATURE SENSORS

Procedure:

1. Without a sensor attached: Measure voltage between sensor # and common terminals on termination board; voltage should read 5 VDC.
2. With a sensor attached: Measure voltage between sensor # and common terminals on termination board. Using the equation below, determine if the sensor reading in the display agrees with the measured reading.

$$\text{Temperature} = (\text{V measured} - 2.554) \times 180$$

3. If calculated temperature does not agree, the RC-1000 is at fault. If other circuits are reading correctly, the I/O Board may be bad.

PRESSURE TRANSDUCERS

Procedure:

1. Measure voltage between +12 V terminal and the common terminals on termination board; voltage should read 13-15 VDC.
2. With transducer attached: Measure voltage between sensor # and common terminals on termination board. Using the equation below, determine if the pressure reading in the display agrees with the measured reading.

$$\text{Suction Pressure} = (\text{V measured} - 1) \times 20$$

$$\text{Head Pressure} = (\text{V measured} - 1) \times 100$$

For Variable Speed operation only:

$$\text{Oil Pump Output Pressure} = (\text{V measured} - 1) \times 20$$

$$\text{Displayed Oil Pressure} = \text{Oil Pump Output Pressure} - \text{Suction Pressure}$$

3. If calculated pressure does not agree, the RC-1000 is at fault. If other circuits are reading correctly, the I/O Board may be bad.

RELAY BOARD

Procedure:

1. Output:
 - a) Verify correct connection of N.O. and N.C.
 - b) Check 3 AMP 240 VAC fuse on common leg of each relay.
2. Power:
 - a) Check 12 VAC supplied to Relay Board on terminals (see Figure 13).
 - b) Check 1 AMP 12 VAC fuse on Relay Board.
3. Connections:
 - a) Check connection from I/O Board to Relay Board.
 - b) Check connections of interconnection cables RJ-11). Red LEDs on Relay Driver and Relay Board should correspond.
4. Override Operation:
 - a) Red LEDs indicate relay is energized. Green(yellow) Leds indicate relay is in an override state of energized or de-energized.

NOTE: A combination of lit green(yellow) and lit red LEDs indicates the relay has been overridden to the energized state.

Note: The override led is designated as green(yellow), this led may be either color depending on version of relay board.

RC-1000 TROUBLESHOOTING GUIDE

SYMPTOM	POSSIBLE CAUSE	CORRECTIVE PROCEDURE
Cases are too hot	a) Sensor wiring	1) Place Refrig relay in override. If cases get colder, check circuit status for temp. If status = -30°, sensor is shorted or wired backwards.
	b) Circuit programming	<p>1) Place Refrig relay in override. If cases get colder, return override switch to "AUTO", check circuit status for refrig status.</p> <p>-IF "ON":</p> <ul style="list-style-type: none"> a) Make sure override switch is in "AUTO". b) Make sure relay code is programmed correctly under "Setpoints". c) Make sure digital output is not in override in the override menu. <p>-IF "OFF":</p> <ul style="list-style-type: none"> a) Check circuit setpoints. b) Make sure digital output is not in override in the override menu. <p>-IF "DEF":</p> <ul style="list-style-type: none"> a) Check defrost schedule. <p>-IF Cases do not get colder</p> <ul style="list-style-type: none"> a) Make sure rack circuit switch is on. b) Check control power to relay terms. c) Check relay 5A fuse. d) Check refrig valve.
Cases are too cold	a) Sensor	<p>1) Check circuit status</p> <p>-IF "97":</p> <ul style="list-style-type: none"> a) Check sensor program in circuit setpoints. <p>-IF "94/95":</p> <ul style="list-style-type: none"> a) Check for open sensor wiring.

Cases are too cold (con't)	b) Circuit Status	1) Check circuit status for refig status. -IF "ON": a) Make sure relay override switch is in "AUTO". b) Make sure relay code is programmed correctly under "Setpoints". c) Make sure digital output is not in override.
	c) Cables	1) Make sure the relay LED matches relay driver board. 2) Check cable orientation.
If compressors not being called for, but should be running.	a) Rack Status	1) Check pressure reading; do a transducer check. 2) Check for phase loss alarm (if configured). 3) Check "not off" on shutdown setpoint. 4) Check "not off" by soft override in override menu.
If compressors are being called for, but not running	a) Cables	1) I/O board LED and relay LED should be off. If not, check cable and connections.
	b) Relay Code	1) Make sure relay code is programmed correctly under "Setpoints".
	c) Relay Override Switches	1) Make sure circuit relay override switches are in "AUTO".
	d) Software Override	1) Check for "OFF" in Digital Output of override menu.
	e) Compressor Switch	1) Make sure compressor switches are on.
	f) Control Voltage	1) Check control voltage at relay terminals.
	g) Fuses	1) Check fuses on relay boards.
	h) Compressor Safeties	1) Check all compressor circuit safeties (oil pressure, high head, low suction, phase loss).
If compressor is not being called for, but still running	a) Rack Status	1) Check pressure reading; -IF "100": a) Do a Transducer check.
	b) Cables	1) I/O LED and relay LED should be on. If not, check cables and connections.

If compressor is not called for, but still running (con't)	c) Relay Override Switches	1) Make sure circuit relay override switches are in "AUTO".
	d) Override Menu	1) Check for "On" in Digital Output of override menu.
	e) Relay Code	1) Make sure relay code is programmed correctly under "Setpoints".
If condenser fans are not called for, but should be running.	a) Fan Relay	<p>1) Turn condenser fan relay LED off by override switch.</p> <p>-IF fan comes on:</p> <ul style="list-style-type: none"> a) Check pressure; do transducer check. b) Check rack head setpoints and relay programming. c) Check phase loss alarm (if configured). d) Check "Not Off" in override menu. <p>-IF condenser fan still not on:</p> <ul style="list-style-type: none"> a) Check control voltage to relay terminals. b) Check condenser fan contactor.
If condenser fans are called for, but not running.	a) Cable	1) I/O and relay LED should be off. If not, check cable and connections.
	b) Relay Code	1) Make sure relay assignment programmed correctly under "Setpoints".
	c) Override Switches	1) Make sure condenser relay override switches are in AUTO.
	d) Control Voltage	1) Check control voltage at relay terminals.
	e) Fuses	1) Check fuses on relay boards.
Cannot enter setpoints in circuits or racks.	a) Incorrect Access Code	1) Use correct access code - level 2.
Cannot change rack or circuit configuration	a) Incorrect Access Code	1) Use correct access code - level 1 or 2.
Cannot initiate emergency defrost	a) No Defrost Time programmed - temperature above termination setpoint.	1) Check setpoint screen for correct entries, and check case temperature.

Unit does not hold on #1 compressor during hot gas defrost.	a) Circuit not assigned to a Rack.	1) Check that circuit is assigned to proper rack.
	b) Defrost Initiate not set to Internal	1) Check that defrost initiate is set to internal on rack configuration.
Cannot communicate remotely	a) Incorrect COM ID	1) Verify COM ID on System Miscellaneous Parameters, and COM ID dip switch.
	b) Bad Phone Cables or Adaptors.	1) Check phone cables and adapters.
	c) Blown I/O Fuse	1) Check fuse on CPU Board.
No logging data	a) No Logging Interval programmed	1) Set logging interval.
Defrost operates at incorrect times.	a) Incorrect Date/Time programmed	1) Set date/time correctly.
Alarm does not dial out	a) No Phone Number programmed	1) Program phone number.
Sensors assigned, but no pressure readings.	a) No power to Transducer	1) Check fuse on CPU Board. 2) Check connections to transducer and termination board.
	b) No Gain programmed on Setpoint screen	1) Program gain.
Variable speed operates incorrectly	a) Oil Pressure setpoints	1) Check oil pressure. 2) Check oil pressure setpoints.
	b) H.P. rating much higher than other compressors on the rack.	1) Check H.P. ratings for all compressors.

CIRCUIT SETPOINTS DEFINITIONS

- SETPOINT:** Degree F or C - Temperature control - 2 digits (3 digits for High Temp application). Use the up/down arrow keys to toggle the +/- signs. Low temp range is from -30 F to +97 F. High temp range is from +00 F to +255 F. When temp goes one degree above setpoint the Refrigeration Relay will turn on and turn back off at the setpoint. Up to 12 sensors can be used for Circuit control. All sensors will average the Temp for control.
- CUT-IN/CUT-OUT:** Same as Setpoint except a Deadband is
SETPT programmable for Temp Control.
- HIGH ALARM :** Degree F or C - 2 digits (3 digits for High Temp application)
& LOW ALARM: Programmed values to Alarm if the Temp sensors exceed these values. Up to 12 Alarm Sensors can be assigned and the Highest and Lowest value will be displayed.
- DEFROST TERM:** Degree F or C - 2 digits (3 digits for High Temp application). Programmed value to Terminate the Defrost. Up to 12 sensors can be assigned. All Termination Sensors must reach the setpoint prior to completing the Defrost. Lowest value will be displayed.
- DEFR RESTART:** Degree F or C - 2 digits - Several items are monitored and required for proper operation:
1. Defrost will be initiated.
 2. Termination Sensor(s) will be monitored and if all reach the Termination Setpoint the defrosting will stop.
 3. The Circuit will remain idle (Ref. & Def Off) for the duration of the Defrost Time.
 4. If the Termination Sensor(s) go below the Defrost Restart Temp. then the Defrost will restart.
 5. This can happen as often as necessary but the Termination Temp and Defrost duration will be honored.

OR - using DIGITAL ASSIGNMENT for Defrost Restart.
Several items are monitored and required for proper operation:

1. Defrost will be initiated.
2. Digital Input will be monitored and when closed the defrosting will stop.
3. The circuit will remain idle (Ref. & Def Off) for the duration of the Defrost Time.
4. A minimum of two (2) minutes must elapse and then if the Digital opens again the Defrost can restart.
5. Repeat the process

SKIP DEFR @DP: Degree F or C - 2 digits. For a Circuit to skip a Defrost the Dewpoint being monitored must remain below the programmed setpoint for the entire time between scheduled Defrost.

MAX DP SKIPS: One (1) digit - Works in conjunction with Skip Defrost. Number of Defrost that can be skipped in a row before a mandatory Defrost must occur.

EVP FAN START: Degree F or C - 2 digits - If Termination Sensor(s) go below the Evaporation Fan Restart Setpoint then the fan will turn on. Otherwise, following the programmed time delay the Fans will start.

REFRIG DELAY: Minutes - 2 digits - Amount of time the Refrigeration must remain off to prevent short cycling.

ALARM DELAY: Minutes - 2 digits - Amount of time Alarm goes into a pending mode, this takes place after the temp has reached the Alarm Setpoints. Alarm is inactive during Defrost and 15 minutes plus the Delay time following a Defrost at which time the Delay becomes active.

PUMPOUT TIME: Minutes - 2 digits - Liquid Relay Assignment required. When a Defrost is initiated the Liquid Relay will turn off for the time programmed to allow for the Circuit to Pump Out. Following this time period the Defrost will begin.

DEF DURATION/: Minutes - 3 digits - Failsafe value. If the Defrost Temp does not reach

DEFROST TIME The programmed Termination Temp the Defrost will and when the Duration Time has elapsed.

EQUALIZE TIME: Minutes - 2 digits - Equalize Relay Assignment required. Following the termination of a Defrost a Circuit can be equalized by a Bleed Line. This would be active for the programmed time.

EVAP FAN DLY: Minutes - 2 digits - (See Evap Fan Start) Time required prior to starting Fans.

RUN OFF TIME: Minutes - 2 digits - Following a defrost the Circuit will not permit Defrost or Refrigeration to be active. This allows for water drainage and equalization of the Refrigerant.

DEFROST TIMES/: 4 digits - Can program up to 6 Defrost using a 2400 hour clock.

DEFROST START TIME 2400 hours is legitimate.

DEF INIT INPUT: Digital Assignment - Upon a contact closure on the Digital Input the Defrost will begin. It will honor the duration and termination. If Def Start times are programmed, the Defrost will honor both the programmed time and the Digital before activating the Defrost cycle.

DEF TERM INPUT: Digital Assignment - Upon a contact closure on the Digital Input the Defrost will end. Termination Sensor cannot work in conjunction. If there is no contact closure, the Defrost will terminate at the end of the duration.

TEMP SENSORS: Sensor Assignment up to 12 sensors. All sensors will be averaged. The computer will cycle the Refrigeration based on this Temperature. The average will be displayed on the Status Screen as the Temperature. (See Setpoint)

ALARM SENSORS: Sensor Assignment up to 12 sensors. All sensors are monitored. If any sensor exceeds the High or Low programmed value, the Alarm will activate an Alarm Pending State. This will be displayed on the Status Screen showing the Highest and Lowest Temp values. (See High and Low Alarms)

TERM SENSORS: Sensor Assignment up to 12 sensors. All sensors must reach the Termination temperature. The computer will look for the lowest temp and display this value in the Status Screen. (See Defrost Term)

REFRIG RELAY/: Relay Assignment connected to N.C. contacts - Will cycle Refrigeration on and off due to Temperature Setpoint. Also works in conjunction with Defrost, Pumpout, and Equalize.

SUCTION RELAY

LIQUID RELAY: Relay Assignment - Connected to N.C. contacts. Will cycle Refrigeration on and off due to Temperature Setpoints, also works in conjunction with Defrost, Pumpout, and Equalization.

CASE DEFR RLYS: Relay Assignments - Connected to N.O. contacts. Requires each case to have it's own value to control Defrost. Each case will have it's own Termination Sensor to control the Defrosting of that case. Each case can have independent Restart and Termination.

DEFROST RELAY: Relay Assignment connected to N.O. contacts - Will cycle Defrost on and off when required by program

HOT GAS RELAY/: Relay Assignment connected to N.O. contacts - Can be common relay to all

MASTR HGAS RLY Hot Gas Circuits. The relay will activate the Modulating or Differential Valve to allow for Hot Gas operation.

EVAP FAN RLY: Relay Assignment - Connects to N.C. contacts. (See Evp Fan Start) Starts Evaporator Fan when conditions are correct.

EQUALIZE RELAY: Relay Assignment - Connected to N.O. contacts. (See Equalize Time) Activates Bleed Line into Circuit following Defrost.

ALARM RELAY: Relay Assignment - Connected to N.C. contacts - Can be common relay for all Alarms being monitored for Racks and Circuits.

REFRIG INPUT/:

SUCT VRFY INPT Digital Assignment - Gives proof that a Refrigeration valve is working in conjunction with the computer. Any variation from the computer will cause a "V" to show in the Status and Log the failure.

LIQ VRFY INPT: Digital Assignment - Gives proof that a Refrigeration valve is working in conjunction with the computer. Any variation from the computer will cause a "V" to show in the Status and Log the failure.

DEFROST INPUT/:

DEF VRFY INPTS Digital Assignment - Gives proof that a Master/Case Defrost valve is working in conjunction with the computer. Any variation from the computer will cause a "V" to show in the Status and Log the failure.

TEMP COMPENSATION

SELECT: 2 digits - This is used in conjunction with Racks for Temp controlling of the Rack Setpoints (Floating of Pressure). With a Priority of "1" assigned to a Circuit the temp will be monitored and if the temp reaches the Setpoint then:

1. A 2° Deadband below Setpoint will become automatic for that circuit.
2. The Cut-in and Cut-out pressure will begin to float upward but not to exceed the max Cut-in programmed (Rack).
3. When temp of the circuit goes above the programmed Setpoint the Rack Cut-in and Cut-out will return to the original setpoints.

NOTE: This process works on a Degree Minute Scale

During Defrost the Priority 1 will become inactive and the Priority 2 will take over until completion of Defrost. Rack Number must be programmed in order to assure correct Rack is floating its pressure.

DEFAULT: See Rack Number below, item #2.

ALRM OVRD INPUT: Digital Assignment - Upon contact closure of the Digital Input the computer will disallow any Alarming on the Circuit from the temperatures.

RACK NUMBER: 2 digits - This will serve 2 purposes:

1. Assures the proper Rack acknowledges the circuit that is in Hot Gas Defrost. This will assure a compressor continues to run during Defrost on that Rack.
2. Assures the proper Rack acknowledges the circuit is assigned and allows it to float the Cut-in and Cut-out Setpoints of that Rack. This method will look for all circuits with the same Rack number and automatically assign the circuit with the lowest temp setpoint for floating of the Rack. While this circuit is defrosting, the next circuit with the lowest temp setpoint will take over. (Select Mode)

RACK SETPOINTS DEFINITIONS

CUT IN/CUT OUT:	Pounds - Target values for maintaining the Suction and Head Pressure, "IN" on Rise; "OUT" on Drop.
AUX CUT IN/CUT OUT:	Pounds - Suction and Head target values will operate by the programmed parameters of the Auxiliary Setpoints when Aux Input enable (Digital In) is closed.
MAX CUT IN:	Pounds - Maximum allowable upward movement of the Suction "Cut In" Setpoint when in the Floating Mode.
HIGH/LOW ALARM:	Pounds - When the Suction and Head programmed parameters are exceeded and the Alarm Time Delay has elapsed then the Alarm Relay will close, Alarm Log will log the alarm and Dial Out (if selected).
HEAD OVERRIDE:	Pounds - If the head pressure exceeds this setpoint, the compressors will begin an orderly shutdown.
SHUTDOWN:	Pounds - If the Suction pressure exceeds (goes below) programmed parameter all the compressors will Shut Down immediately. The compressors now must honor the required capacity and the Minimum Off Time Delay before restarting. With "00" programmed, the Shutdown is deactivated.
ALARM DELAY:	Minutes - All Alarm Parameters will activate when Alarm Delay value is exceeded. All Digital Alarms honor same time delay
LIQUID LEVEL ALARM:	Percent - Value at which the Liquid Level must exceed (go below) and honor Alarm Time Delay. This will activate Alarm Relay, log Alarm in the Alarm Log, and Dial Out (if selected).
HR OVERRIDE ALRM:	Percent - Works in conjunction with the Liquid Level Alarm. Value at which the Heat Reclaim Override Relay will open only after the Override Time Delay is honored.
HR OVERRIDE DIFF:	Percent - Value at which the Liquid Level must return to (HR Override Level plus HR Override Diff) in order to close the HR Relay again.

HR OVERRIDE DELAY: Seconds - Time that must be honored prior to opening the Heat Reclaim Relay when in an Alarm condition.

FREON SCALE FACTOR: PPM - Maximum value of Refrigerant Leak Detector when inputing 10
Ver 2 volts to the RC-1000.

FREON ALARM SPT: PPM - The value at which the Leak Detector must exceed (go above)
Ver 2 and honor Alarm Time Delay.

MIN ON TIME: Seconds - Requires each individual compressors or unloaders to honor this time prior to turning off.

MIN OFF TIME: Seconds - Requires each individual compressors or unloaders to honor this time prior to turning on.

CONTROL GAIN: 001 to 255 - Acts as a Throttle for the calculating speed when trying to maintain Suction and Head Pressures. By raising the Control Gain the calculating process will increase. Lowering the Gain will cause it to decrease.

CONTROL DERIVATIVE: 001 to 255 - Acts as an Anticipator for the Suction and Head Pressures. As the pressure makes sharp changes the calculating process will anticipate and adjust accordingly. Raising the Derivative will increase the reaction. Lowering will decrease it.

UNIT COMBINATIONS: ALT or SEQ - SEQ = Sequence - compressors and unloaders must turn on as 1,2,3,4, etc and back off as 4,3,2,1. ALT = Alternating - compressors and unloaders will cycle as the computer requires by looking at the following:

- Amount of capacity required (see Capacity)
- Minimum steps required to get to needed capacity
- Honor minimum on and off times
- Equalize run times

PRES SENSOR: Sensor Assignment - Suction = must be an SA-100 Transducer. Head = must be an SA-500 Transducer. Connection will be to a Pressure (AIP) card.

ALARM RELAY: Relay Assignment - Connected to N.C. contacts. Common Relay for all Alarms in Rack Section.

ANLG LIQ LEV SENSR: Sensor Assignment - Monitors others Liq Level Sensor. Must be 10K load at 100% and must be connected to a 0-10V card.

HR OVERRIDE RELAY: Relay Assignment - Connected to N.C. contacts. Wired to interrupt Heat Reclaim valve on rack.

AUX ENABLE INPUT: Digital Assignment - Digital must close contacts to enable, reverts operation to Aux Cut in and Cut out.

PHASE LOSS INPUT: Digital Assignment - Digital must close contacts to signal correct operation. Failure (open contact) shuts down all racks and circuits.

FREON SENSOR: Sensor Assignment - Monitors Freon Sensor and connects to a 0-10v card.
Ver 2 Only

LIQUID LEVEL INPUT: Digital Assignment - Monitors others Liquid Level Sensor. Must close contacts for purpose of Alarming.

DEFROST SENSE INPUT: Digital Assignment - Monitors others Defrost Clock. Must close contacts for purpose of indicating Defrost condition. This is used to force a compressor to run during Defrost.

OIL FAILURE INPUT: Digital Assignment - Digital Oil Inputs must be in series and any oil failure must open Digital contact for Alarm.

FREON INPUT: Digital Assignment - Monitors Freon Control by others. Must close contact for purpose of Alarming.
Ver 2 Only

COMPRESSOR RELAY: Relay Assignment - Must be connected to N.C. unless Rack Configuration was programmed for "Comp Energize On" which would require connection to N.O.

CAPACITY: 3 Digits - The computer will compare all capacities and assign each compressor a certain percent of the total. This value can be in Horse Power, BTU's, or Percent (%). The computer will determine what to cycle by looking at the requirements and the capacity of each compressor.

SLAVES: Single Digit - Unloaders - Standard hook-up is N.O. at the relay. The number entered under a compressor determines how many unloaders for that compressor. The following positions next to the compressor (equal to the Slave number) will be the Unloaders and they must share the capacity of the main compressor, ie: if the compressor is a 15 HP and there are 2 Unloaders then - place a 2 under the main compressor at position #1. Positions 1,2,3 will be the total capacity and each positions capacity will be 5 HP. NOTE: The computer will require the Unloaders to be unloaded prior to turning on compressors and unload prior to turning off the main compressor.

RUN INPT: Digital Assignment - Input gives proof that a compressor is working in conjunction with the computer (Digital closes when on). Any variation from what the computer is calling for will put a "V" in place of the compressor number on the status screen and log the failure.

VARIABLE SPEED COMPRESSOR:

MAX RPM: Maximum value allowed for the variable operation.

MIN RPM: Minimum value allowed for operation. Compressor will maintain Minimum RPM and only Shutdown when Req Capacity on Status screen is at 0%.

CAPACITY: See Capacity above, directly related to compressor capacity. The higher the capacity value, the more defined increments for the variable speed, ie: $1750 \div 10$ (capacity) = 175 (lg increment change)
 $1750 \div 100$ (capacity) = 17.5 (sm increment chg)

This would be the RPM Staging of the Variable Speed

Gain		RPM	RPM	RPM	RPM	
10	--	175	350	525	700	etc.
100	--	17.5	35	52.5	70	etc.

MIN OIL PRES: Pounds - 3 digits - If net Oil Pressure exceeds (goes below) the programmed value, the Variable Speed will speed up until corrected and will resume variable speed operation only after correction of Oil Pressure.

ANALOG OUTPUT: Analog Output Assignment - Output signal to the Variable Speed that operates from 0-10 VDC.

0 VDC = 0 RPM 10 VDC = MAX RPM

OIL PRESS SENSR: Sensor Assignment - SA-100 Pressure Transducer connected to output of Oil Pump. Should be snubbed to prevent hammer effect. Oil Pressure will be calculated as: Oil Pump Output -Less- Suction Press = Net Oil

FREQ SENSR: Sensor Assignment - Monitors Invertor giving actual Frequency of the Invertor into 0-10v card.

CURRENT SENSR: Sensor Assignment - Monitors Invertor giving actual Current of the Invertor into 0-10v card.

CONTROL RELAY: Relay Assignment - Connected to N.C. - Required to open Control Circuit of Variable Speed when compressor shuts off. The Control signal will drop to 0 VDC to shut down the Compressor and the Control Circuit will open to prevent tripping of the Oil Failure Switch.

RESET RELAY: Relay Assignment - Used to keep Invertor in the Run Mode but will pulse to restart Invertor if the RC-1000 receives a fault signal from the Invertor.

SWITCHOVR RELAY: Relay Assignment - Connected to ?? - Will remain in the normal Run Mode (Invertor) unless the Fault Input and Reset Relay have tried 3 times to restart the Variable Speed without success. At this time the Relay will switch to the By-pass Contactor.

FAULT INPUT: Digital Assignment - Input signal from Invertor must close Digital Contact to indicate a problem with the Variable Speed. This works in conjunction with the Reset Relay mentioned above.

RUN INPUT: Digital Assignment - Input gives proof the Variable Speed is working in conjunction with computer (see Run Input for Compressors).

FAN RELAY: Relay Assignment - Connected to N.C. Contacts - All Fans work in conjunction with Head Setpoints. The number of Relays assigned will determine the percentage of the Load, ie:

2 Assignments 50% & 50%

4 Assignments 25%, 25%, 25% & 25%

RUN INPT: Digital Assignment - Input gives proof the Fans are working in conjunction with the computer (see Run Input for Compressor).

POWER SENSR: Sensor Assignment - Monitor a K.W. Transducer to indicate the amount of power consumed into a 0-10v card.

MAX POWER: Programmable variable that works in conjunction with the size of Current Transformers installed.

TABLE 1, % RH TO VOLTAGE CONVERSION

% RH	Voltage	% RH	Voltage	% RH	Voltage
0	2.554	34	2.743	68	2.932
1	2.560	35	2.748	69	2.937
2	2.565	36	2.754	70	2.943
3	2.571	37	2.760	71	2.948
4	2.576	38	2.765	72	2.954
5	2.582	39	2.771	73	2.960
6	2.587	40	2.776	74	2.965
7	2.593	41	2.782	75	2.971
8	2.598	42	2.787	76	2.976
9	2.604	43	2.793	77	2.982
10	2.610	44	2.798	78	2.987
11	2.615	45	2.804	79	2.993
12	2.621	46	2.810	80	2.998
13	2.626	47	2.815	81	3.004
14	2.632	48	2.821	82	3.010
15	2.637	49	2.826	83	3.015
16	2.643	50	2.832	84	3.021
17	2.648	51	2.837	85	3.026
18	2.654	52	2.843	86	3.032
19	2.660	53	2.848	87	3.037
20	2.665	54	2.854	88	3.043
21	2.671	55	2.860	89	3.048
22	2.676	56	2.865	90	3.054
23	2.682	57	2.871	91	3.060
24	2.687	58	2.876	92	3.065
25	2.693	59	2.882	93	3.071
26	2.698	60	2.887	94	3.076
27	2.704	61	2.893	95	3.082
28	2.710	62	2.898	96	3.087
29	2.715	63	2.904	97	3.093
30	2.721	64	2.910	98	3.098
31	2.726	65	2.915	99	3.104
32	2.732	66	2.921	100	3.110
33	2.737	67	2.926		

TABLE 2, FOOT CANDLES TO VOLTAGE CONVERSION

FTC	Voltage	FTC	Voltage	FTC	Voltage
0	2.554	34	2.743	68	2.932
1	2.560	35	2.748	69	2.937
2	2.565	36	2.754	70	2.943
3	2.571	37	2.760	71	2.948
4	2.576	38	2.765	72	2.954
5	2.582	39	2.771	73	2.960
6	2.587	40	2.776	74	2.965
7	2.593	41	2.782	75	2.971
8	2.598	42	2.787	76	2.976
9	2.604	43	2.793	77	2.982
10	2.610	44	2.798	78	2.987
11	2.615	45	2.804	79	2.993
12	2.621	46	2.810	80	2.998
13	2.626	47	2.815	81	3.004
14	2.632	48	2.821	82	3.010
15	2.637	49	2.826	83	3.015
16	2.643	50	2.832	84	3.021
17	2.648	51	2.837	85	3.026
18	2.654	52	2.843	86	3.032
19	2.660	53	2.848	87	3.037
20	2.665	54	2.854	88	3.043
21	2.671	55	2.860	89	3.048
22	2.676	56	2.865	90	3.054
23	2.682	57	2.871	91	3.060
24	2.687	58	2.876	92	3.065
25	2.693	59	2.882	93	3.071
26	2.698	60	2.887	94	3.076
27	2.704	61	2.893	95	3.082
28	2.710	62	2.898	96	3.087
29	2.715	63	2.904	97	3.093
30	2.721	64	2.910	98	3.098
31	2.726	65	2.915	99	3.104
32	2.732	66	2.921	100	3.110
33	2.737	67	2.926		

TABLE 3. PRESSURE TO VOLTAGE CONVERSION: SA-100

Pres	Voltage	Pres	Voltage	Pres	Voltage
0	1.000	34	2.70	68	4.40
1	1.05	35	2.75	69	4.45
2	1.10	36	2.80	70	4.50
3	1.15	37	2.85	71	4.55
4	1.20	38	2.90	72	4.60
5	1.25	39	2.95	73	4.65
6	1.30	40	3.00	74	4.70
7	1.35	41	3.05	75	4.75
8	1.40	42	3.10	76	4.80
9	1.45	43	3.15	77	4.85
10	1.50	44	3.20	78	4.90
11	1.55	45	3.25	79	4.95
12	1.60	46	3.30	80	5.00
13	1.65	47	3.35	81	5.05
14	1.70	48	3.40	82	5.10
15	1.75	49	3.45	83	5.15
16	1.80	50	3.50	84	5.20
17	1.85	51	3.55	85	5.25
18	1.90	52	3.60	86	5.30
19	1.95	53	3.65	87	5.35
20	2.00	54	3.70	88	5.40
21	2.05	55	3.75	89	5.45
22	2.10	56	3.80	90	5.50
23	2.15	57	3.85	91	5.55
24	2.20	58	3.90	92	5.60
25	2.25	59	3.95	93	5.65
26	2.30	60	4.00	94	5.70
27	2.35	61	4.05	95	5.75
28	2.40	62	4.10	96	5.80
29	2.45	63	4.15	97	5.85
30	2.50	64	4.20	98	5.90
31	2.55	65	4.25	99	5.95
32	2.60	66	4.30	100	6.00
33	2.65	67	4.35		

TABLE 4, PRESSURE TO VOLTAGE CONVERSION: SA-500

Pres	Voltage	Pres	Voltage	Pres	Voltage
0	1.00	34	1.34	68	1.68
1	1.01	35	1.35	69	1.69
2	1.02	36	1.36	70	1.70
3	1.03	37	1.37	71	1.71
4	1.04	38	1.38	72	1.72
5	1.05	39	1.39	73	1.73
6	1.06	40	1.40	74	1.74
7	1.07	41	1.41	75	1.75
8	1.08	42	1.42	76	1.76
9	1.09	43	1.43	77	1.77
10	1.10	44	1.44	78	1.78
11	1.11	45	1.45	79	1.79
12	1.12	46	1.46	80	1.80
13	1.13	47	1.47	81	1.81
14	1.14	48	1.48	82	1.82
15	1.15	49	1.49	83	1.83
16	1.16	50	1.50	84	1.84
17	1.17	51	1.51	85	1.85
18	1.18	52	1.52	86	1.86
19	1.19	53	1.53	87	1.87
20	1.20	54	1.54	88	1.88
21	1.21	55	1.55	89	1.89
22	1.22	56	1.56	90	1.90
23	1.23	57	1.57	91	1.91
24	1.24	58	1.58	92	1.92
25	1.25	59	1.59	93	1.93
26	1.26	60	1.60	94	1.94
27	1.27	61	1.61	95	1.95
28	1.28	62	1.62	96	1.96
29	1.29	63	1.63	97	1.97
30	1.30	64	1.64	98	1.98
31	1.31	65	1.65	99	1.99
32	1.32	66	1.66	100	2.00
33	1.33	67	1.67	101	2.01

TABLE 4, PRESSURE TO VOLTAGE CONVERSION: SA-500

Pres	Voltage	Pres	Voltage	Pres	Voltage
102	2.02	136	2.36	170	2.70
103	2.03	137	2.37	171	2.71
104	2.04	138	2.38	172	2.72
105	2.05	139	2.39	173	2.73
106	2.06	140	2.40	174	2.74
107	2.07	141	2.41	175	2.75
108	2.08	142	2.42	176	2.76
109	2.09	143	2.43	177	2.77
110	2.10	144	2.44	178	2.78
111	2.11	145	2.45	179	2.79
112	2.12	146	2.46	180	2.80
113	2.13	147	2.47	181	2.81
114	2.14	148	2.48	182	2.82
115	2.15	149	2.49	183	2.83
116	2.16	150	2.50	184	2.84
117	2.17	151	2.51	185	2.85
118	2.18	152	2.52	186	2.86
119	2.19	153	2.53	187	2.87
120	2.20	154	2.54	188	2.88
121	2.21	155	2.55	189	2.89
122	2.22	156	2.56	190	2.90
123	2.23	157	2.57	191	2.91
124	2.24	158	2.58	192	2.92
125	2.25	159	2.59	193	2.93
126	2.26	160	2.60	194	2.94
127	2.27	161	2.61	195	2.95
128	2.28	162	2.62	196	2.96
129	2.29	163	2.63	197	2.97
130	2.30	164	2.64	198	2.98
131	2.31	165	2.65	199	2.99
132	2.32	166	2.66	200	3.00
133	2.33	167	2.67	201	3.01
134	2.34	168	2.68	202	3.02
135	2.35	169	2.69	203	3.03

TABLE 4, PRESSURE TO VOLTAGE CONVERSION: SA-500

Pres	Voltage	Pres	Voltage	Pres	Voltage
204	3.04	238	3.38	272	3.72
205	3.05	239	3.39	273	3.73
206	3.06	240	3.40	274	3.74
207	3.07	241	3.41	275	3.75
208	3.08	242	3.42	276	3.76
209	3.09	243	3.43	277	3.77
210	3.10	244	3.44	278	3.78
211	3.11	245	3.45	279	3.79
212	3.12	246	3.46	280	3.80
213	3.13	247	3.47	281	3.81
214	3.14	248	3.48	282	3.82
215	3.15	249	3.49	283	3.83
216	3.16	250	3.50	284	3.84
217	3.17	251	3.51	285	3.85
218	3.18	252	3.52	286	3.86
219	3.19	253	3.53	287	3.87
220	3.20	254	3.54	288	3.88
221	3.21	255	3.55	289	3.89
222	3.22	256	3.56	290	3.90
223	3.23	257	3.57	291	3.91
224	3.24	258	3.58	292	3.92
225	3.25	259	3.59	293	3.93
226	3.26	260	3.60	294	3.94
227	3.27	261	3.61	295	3.95
228	3.28	262	3.62	296	3.96
229	3.29	263	3.63	297	3.97
230	3.30	264	3.64	298	3.98
231	3.31	265	3.65	299	3.99
232	3.32	266	3.66	300	4.00
233	3.33	267	3.67	301	4.01
234	3.34	268	3.68	302	4.02
235	3.35	269	3.69	303	4.03
236	3.36	270	3.70	304	4.04
237	3.37	271	3.71	305	4.05

TABLE 4, PRESSURE TO VOLTAGE CONVERSION: SA-500

Pres	Voltage	Pres	Voltage	Pres	Voltage
306	4.06	340	4.40	374	4.74
307	4.07	341	4.41	375	4.75
308	4.08	342	4.42	376	4.76
309	4.09	343	4.43	377	4.77
310	4.10	344	4.44	378	4.78
311	4.11	345	4.45	379	4.79
312	4.12	346	4.46	380	4.80
313	4.13	347	4.47	381	4.81
314	4.14	348	4.48	382	4.82
315	4.15	349	4.49	383	4.83
316	4.16	350	4.50	384	4.84
317	4.17	351	4.51	385	4.85
318	4.18	352	4.52	386	4.86
319	4.19	353	4.53	387	4.87
320	4.20	354	4.54	388	4.88
321	4.21	355	4.55	389	4.89
322	4.22	356	4.56	390	4.90
323	4.23	357	4.57	391	4.91
324	4.24	358	4.58	392	4.92
325	4.25	359	4.59	393	4.93
326	4.26	360	4.60	394	4.94
327	4.27	361	4.61	395	4.95
328	4.28	362	4.62	396	4.96
329	4.29	363	4.63	397	4.97
330	4.30	364	4.64	398	4.98
331	4.31	365	4.65	399	4.99
332	4.32	366	4.66	400	5.00
333	4.33	367	4.67	401	5.01
334	4.34	368	4.68	402	5.02
335	4.35	369	4.69	403	5.03
336	4.36	370	4.70	404	5.04
337	4.37	371	4.71	405	5.05
338	4.38	372	4.72	406	5.06
339	4.39	373	4.73	407	5.07

TABLE 4, PRESSURE TO VOLTAGE CONVERSION: SA-500

Pres	Voltage	Pres	Voltage	Pres	Voltage
408	5.08	442	5.42	476	5.76
409	5.09	443	5.43	477	5.77
410	5.10	444	5.44	478	5.78
411	5.11	445	5.45	479	5.79
412	5.12	446	5.46	480	5.80
413	5.13	447	5.47	481	5.81
414	5.14	448	5.48	482	5.82
415	5.15	449	5.49	483	5.83
416	5.16	450	5.50	484	5.84
417	5.17	451	5.51	485	5.85
418	5.18	452	5.52	486	5.86
419	5.19	453	5.53	487	5.87
420	5.20	454	5.54	488	5.88
421	5.21	455	5.55	489	5.89
422	5.22	456	5.56	490	5.90
423	5.23	457	5.57	491	5.91
424	5.24	458	5.58	492	5.92
425	5.25	459	5.59	493	5.93
426	5.26	460	5.60	494	5.94
427	5.27	461	5.61	495	5.95
428	5.28	462	5.62	496	5.96
429	5.29	463	5.63	497	5.97
430	5.30	464	5.64	498	5.98
431	5.31	465	5.65	499	5.99
432	5.32	466	5.66	500	6.00
433	5.33	467	5.67		
434	5.34	468	5.68		
435	5.35	469	5.69		
436	5.36	470	5.70		
437	5.37	471	5.71		
438	5.38	472	5.72		
439	5.39	473	5.73		
440	5.40	474	5.74		
441	5.41	475	5.75		

TABLE 5. DEWPOINT TO VOLTAGE CONVERSION: DPS-1
At DPI Board, DR(+) to W(-)

DP	Voltage	DP	Voltage	DP	Voltage
0	2.694	34	2.959	68	3.224
1	2.701	35	2.967	69	3.232
2	2.709	36	2.974	70	3.240
3	2.717	37	2.982	71	3.247
4	2.725	38	2.990	72	3.255
5	2.733	39	2.998	73	3.263
6	2.740	40	3.006	74	3.271
7	2.748	41	3.013	75	3.279
8	2.756	42	3.021	76	3.286
9	2.764	43	3.029	77	3.294
10	2.772	44	3.037	78	3.302
11	2.779	45	3.045	79	3.310
12	2.787	46	3.052	80	3.318
13	2.795	47	3.060	81	3.325
14	2.803	48	3.068	82	3.333
15	2.811	49	3.076	83	3.341
16	2.818	50	3.084	84	3.349
17	2.826	51	3.091	85	3.357
18	2.834	52	3.099	86	3.364
19	2.842	53	3.107	87	3.372
20	2.850	54	3.115	88	3.380
21	2.857	55	3.123	89	3.388
22	2.865	56	3.130	90	3.396
23	2.873	57	3.138	91	3.403
24	2.881	58	3.146	92	3.411
25	2.889	59	3.154	93	3.419
26	2.896	60	3.162	94	3.427
27	2.904	61	3.169	95	3.435
28	2.912	62	3.177	96	3.442
29	2.920	63	3.185	97	3.450
30	2.928	64	3.193	98	3.458
31	2.935	65	3.201	99	3.466
32	2.943	66	3.208	100	3.474
33	2.951	67	3.216		

TABLE 6, DEWPOINT TO VOLTAGE CONVERSION: DPS-1
At DPI Board, DP(+) to W(-)

DP	Voltage	DP	Voltage	DP	Voltage
0	2.554	34	2.743	68	2.932
1	2.560	35	2.748	69	2.937
2	2.565	36	2.754	70	2.943
3	2.571	37	2.760	71	2.948
4	2.576	38	2.765	72	2.954
5	2.582	39	2.771	73	2.960
6	2.587	40	2.776	74	2.965
7	2.593	41	2.782	75	2.971
8	2.598	42	2.787	76	2.976
9	2.604	43	2.793	77	2.982
10	2.610	44	2.798	78	2.987
11	2.615	45	2.804	79	2.993
12	2.621	46	2.810	80	2.998
13	2.626	47	2.815	81	3.004
14	2.632	48	2.821	82	3.010
15	2.637	49	2.826	83	3.015
16	2.643	50	2.832	84	3.021
17	2.648	51	2.837	85	3.026
18	2.654	52	2.843	86	3.032
19	2.660	53	2.848	87	3.037
20	2.665	54	2.854	88	3.043
21	2.671	55	2.860	89	3.048
22	2.676	56	2.865	90	3.054
23	2.682	57	2.871	91	3.060
24	2.687	58	2.876	92	3.065
25	2.693	59	2.882	93	3.071
26	2.698	60	2.887	94	3.076
27	2.704	61	2.893	95	3.082
28	2.710	62	2.898	96	3.087
29	2.715	63	2.904	97	3.093
30	2.721	64	2.910	98	3.098
31	2.726	65	2.915	99	3.104
32	2.732	66	2.921	100	3.110
33	2.737	67	2.926		

TABLE 7, TEMPERATURE TO VOLTAGE CONVERSION: TP-1

Temp		Voltage	Temp		Voltage	Temp		Voltage
°F	°C		°F	°C		°F	°C	
-30	-34.4	2.387	2	-16.7	2.565	34	1.1	2.743
-29	-33.9	2.393	3	-16.1	2.571	35	1.7	2.748
-28	-33.3	2.398	4	-15.6	2.576	36	2.2	2.754
-27	-32.8	2.404	5	-15.0	2.582	37	2.8	2.760
-26	-32.2	2.410	6	-14.4	2.587	38	3.3	2.765
-25	-31.7	2.415	7	-13.9	2.593	39	3.9	2.771
-24	-31.1	2.421	8	-13.3	2.598	40	4.4	2.776
-23	-30.6	2.426	9	-12.8	2.604	41	5.0	2.782
-22	-30.0	2.432	10	-12.2	2.610	42	5.6	2.787
-21	-29.4	2.437	11	-11.7	2.615	43	6.1	2.793
-20	-28.9	2.443	12	-11.1	2.621	44	6.7	2.798
-19	-28.3	2.448	13	-10.6	2.626	45	7.2	2.804
-18	-27.8	2.454	14	-10.0	2.632	46	7.8	2.810
-17	-27.2	2.460	15	-9.4	2.637	47	8.3	2.815
-16	-26.7	2.465	16	-8.9	2.643	48	8.9	2.821
-15	-26.1	2.471	17	-8.3	2.648	49	9.4	2.826
-14	-25.6	2.476	18	-7.8	2.654	50	10.0	2.832
-13	-25.0	2.482	19	-7.2	2.660	51	10.6	2.837
-12	-24.4	2.487	20	-6.7	2.665	52	11.1	2.843
-11	-23.9	2.493	21	-6.1	2.671	53	11.7	2.848
-10	-23.3	2.498	22	-5.6	2.676	54	12.2	2.854
-9	-22.8	2.504	23	-5.0	2.682	55	12.8	2.860
-8	-22.2	2.510	24	-4.4	2.687	56	13.3	2.865
-7	-21.7	2.515	25	-3.9	2.693	57	13.9	2.871
-6	-21.1	2.521	26	-3.3	2.698	58	14.4	2.876
-5	-20.6	2.526	27	-2.8	2.704	59	15.0	2.882
-4	-20.0	2.532	28	-2.2	2.710	60	15.6	2.887
-3	-19.4	2.537	29	-1.7	2.715	61	16.1	2.893
-2	-18.9	2.543	30	-1.1	2.721	62	16.7	2.898
-1	-18.3	2.548	31	-0.6	2.726	63	17.2	2.904
0	-17.8	2.554	32	0.0	2.732	64	17.8	2.910
1	-17.2	2.560	33	0.6	2.737	65	18.3	2.915

TABLE 7, TEMPERATURE TO VOLTAGE CONVERSION: TP-1

Temp			Temp			Temp		
°F	°C	Voltage	°F	°C	Voltage	°F	°C	Voltage
66	18.9	2.921	98	36.7	3.098	130	54.4	3.276
67	19.4	2.926	99	37.2	3.104	131	55.0	3.282
68	20.0	2.932	100	37.8	3.110	132	55.6	3.287
69	20.6	2.937	101	38.3	3.115	133	56.1	3.293
70	21.1	2.943	102	38.9	3.121	134	56.7	3.298
71	21.7	2.948	103	39.4	3.126	135	57.2	3.304
72	22.2	2.954	104	40.0	3.132	136	57.8	3.310
73	22.8	2.960	105	40.6	3.137	137	58.3	3.315
74	23.3	2.965	106	41.1	3.143	138	58.9	3.321
75	23.9	2.971	107	41.7	3.148	139	59.4	3.326
76	24.4	2.976	108	42.2	3.154	140	60.0	3.332
77	25.0	2.982	109	42.8	3.160	141	60.6	3.337
78	25.6	2.987	110	43.3	3.165	142	61.1	3.343
79	26.1	2.993	111	43.9	3.171	143	61.7	3.348
80	26.7	2.998	112	44.4	3.176	144	62.2	3.354
81	27.2	3.004	113	45.0	3.182	145	62.8	3.360
82	27.8	3.010	114	45.6	3.187	146	63.3	3.365
83	28.3	3.015	115	46.1	3.193	147	63.9	3.371
84	28.9	3.021	116	46.7	3.198	148	64.4	3.376
85	29.4	3.026	117	47.2	3.204	149	65.0	3.382
86	30.0	3.032	118	47.8	3.210	150	65.6	3.387
87	30.6	3.037	119	48.3	3.215	151	66.1	3.393
88	31.1	3.043	120	48.9	3.221	152	66.7	3.398
89	31.7	3.048	121	49.4	3.226	153	67.2	3.404
90	32.2	3.054	122	50.0	3.232	154	67.8	3.410
91	32.8	3.060	123	50.6	3.237	155	68.3	3.415
92	33.3	3.065	124	51.1	3.243	156	68.9	3.421
93	33.9	3.071	125	51.7	3.248	157	69.5	3.426
94	34.4	3.076	126	52.2	3.254	158	70.0	3.432
95	35.0	3.082	127	52.8	3.260	159	70.6	3.437
96	35.6	3.087	128	53.3	3.265	160	71.1	3.443
97	36.1	3.093	129	53.9	3.271	161	71.7	3.448

TABLE 7, TEMPERATURE TO VOLTAGE CONVERSION: TP-1

Temp			Temp			Temp		
°F	°C	Voltage	°F	°C	Voltage	°F	°C	Voltage
162	72.2	3.454	194	90.0	3.632	226	107.8	3.810
163	72.8	3.460	195	90.6	3.637	227	108.3	3.815
164	73.3	3.465	196	91.1	3.643	228	108.9	3.821
165	73.9	3.471	197	91.7	3.648	229	109.5	3.826
166	74.5	3.476	198	92.2	3.654	230	110.0	3.832
167	75.0	3.482	199	92.8	3.660	231	110.6	3.837
168	75.6	3.487	200	93.3	3.665	232	111.1	3.843
169	76.1	3.493	201	93.9	3.671	233	111.7	3.848
170	76.7	3.498	202	94.5	3.676	234	112.2	3.854
171	77.2	3.504	203	95.0	3.682	235	112.8	3.860
172	77.8	3.510	204	95.6	3.687	236	113.3	3.865
173	78.3	3.515	205	96.1	3.693	237	113.9	3.871
174	78.9	3.521	206	96.7	3.698	238	114.5	3.876
175	79.5	3.526	207	97.2	3.704	239	115.0	3.882
176	80.0	3.532	208	97.8	3.710	240	115.6	3.887
177	80.6	3.537	209	98.3	3.715	241	116.1	3.893
178	81.1	3.543	210	98.9	3.721	242	116.7	3.898
179	81.7	3.548	211	99.5	3.726	243	117.2	3.904
180	82.2	3.554	212	100.0	3.732	244	117.8	3.910
181	82.8	3.560	213	100.6	3.737	245	118.3	3.915
182	83.3	3.565	214	101.1	3.743	246	118.9	3.921
183	83.9	3.571	215	101.7	3.748	247	119.5	3.926
184	84.5	3.576	216	102.2	3.754	248	120.0	3.932
185	85.0	3.582	217	102.8	3.760	249	120.6	3.937
186	85.6	3.587	218	103.3	3.765	250	121.1	3.943
187	86.1	3.593	219	103.9	3.771	251	121.7	3.948
188	86.7	3.598	220	104.5	3.776	252	122.2	3.954
189	87.2	3.604	221	105.0	3.782	253	122.8	3.960
190	87.8	3.610	222	105.6	3.787	254	123.3	3.965
191	88.3	3.615	223	106.1	3.793	255	123.9	3.971
192	88.9	3.621	224	106.7	3.798			
193	89.5	3.626	225	107.2	3.804			

APPENDIX

A

WARRANTY
AND
REPLACEMENT PARTS

WARRANTY

EIL Instruments Inc., will for one year after date of purchase of any EIL product, correct any defect in workmanship or material. Such corrective measures will be limited to repairing or replacing the unit, at EIL's option. This limited warranty shall not apply to equipment which has been subjected to negligence, accident, or damage by operation, maintenance or storage, or to other than normal use or service. This limited warranty does not cover reimbursements for transportation, removal, installation, or repair or replacement, except as may otherwise be specifically agreed to in writing by EIL Instruments.

THE FOREGOING IS IN LIEU OF ALL OTHER WARRANTIES EXPRESSED OR IMPLIED, AND ALL OTHER OBLIGATIONS OR LIABILITIES WHETHER ARISING UNDER CONTRACT, NEGLIGENCE OR OTHERWISE, ON THE PART OF EIL. IN NO EVENT SHALL EIL BE LIABLE FOR CONSEQUENTIAL OR SPECIAL DAMAGES, INCLUDING BUT NOT LIMITED TO LOSS OF USE, LOSS OF INCOME, LOSS OF PROFIT OR COST OF REPLACEMENT.

RC-1000 REPLACEMENT PARTS LIST

<u>PART NUMBER</u>	<u>DESCRIPTION</u>
5101612400	DISPLAY ASSEMBLY
5401695400	DISPLAY ASSEMBLY (BACKLIT)
5401623400	KEYPAD ASSEMBLY
5101690400	CPU BOARD
1761706800	2A FUSE, CPU BOARD
4464401202	INSTRUCTION MANUAL (VER 5)
CC/01625400	AI-8 TEMPERATURE KIT
CC/01639400	AI-4 PRESSURE KIT
CC/01626400	AI-8 PRESSURE KIT
CC/01654400	AI-4 KW/0-10V KIT
CC/01653400	AI-8 KW/0-10V KIT
CC/01629400	DI-8 DIGITAL IN KIT
CC/01627400	RELAY DRIVER KIT
CC/01650401	RELAY BOARD KIT
CC/01681400	AI-8 HI-TEMP KIT
CC/01687400	9 PIN PC DIRECT ADAPTER
CC/01665400	MODEM ADAPTER
CC/PCONN	PHONE CONNECTOR
CC/CRIMP-1	PHONE CONNECTOR CRIMPER
CC/60028400	PHONE CABLE TESTER
CC/01666401	COMM INTERFACE MODULE
2662600300	EXPANDED RAM
MOD-2	1200 BAUD MODEM
MOD-6	2400 BAUD MODEM

REPAIR PROCEDURE

If repair of a part is required, please use the following procedure:

1. Call EIL Instruments - (410) 584-7400 ext 289 for a Repair Order (R.O.) number.
2. At that time, the following is required:
 - a. Purchase Order # for each unit to be repaired
 - b. As much information as possible regarding the nature of the equipment problem
 - c. Serial number of unit / date of purchase
 - d. Previous repair history, if applicable
3. Send item to be repaired to:

EIL Instruments, Inc.
Energy Controls Group
10946A Golden West Drive
Hunt Valley, MD 21031
4. The R.O. number should be clearly marked on the outside of the shipping carton and all applicable paperwork should be included with the shipment INSIDE the carton.
5. Warranty on repaired units will be 90 days from the date of shipment from EIL Instruments.

ADVANCE SHIPMENTS

- 6A. If "Advance Shipment" of replacement component or parts is required, under certain circumstances EIL will do so, provided that a Purchase Order # is issued for such AND with the understanding that the customer will bear responsibility for excess freight charges and further agrees to return the defective component or parts within 15 days of receiving the "Advance Shipment".
- B. After the defective component / system / parts are received back at EIL, they will be repaired and upgraded to current operational standards, ie: restored to "Like New" condition and the customer will be billed for this restoration work at the Standard Repair Charge rate.

APPENDIX

B

INSTALLATION DRAWINGS

Field Wiring Reference Guide

Wire Types:

Phone Cable: RC-1000 to RC-1000, Relay modules to Relay boards;
6 conductor flat phone cable; G-C Thorson 30-9965 or equiv.

Sensor Wiring: Temp, Thermistor, KW, Digital inputs, pulse inputs:
2 wire, 18 awg, shielded cable; Beldon #8760 or equiv.

Pressure transducer wiring:
3 wire, 18 awg, shielded cable; Beldon # 8760 or equiv.

0-10 volt input wiring:
3 wire, 18 awg, shielded cable; Beldon # 8760 or equiv.

Maximum Wire Lengths:

Communications signals with phone line cable:
@ 1200 baud: 500 feet
(longest known operational distance: 500 feet)

Relay driver to Relay board: 200 feet

Sensors (all types): 200 feet

If lengths are exceeded for the signal wires or noisy environments are encountered, slight sensor offsets may be necessary at the appropriate control units.

CIRCUIT WORKSHEET

Store #: _____ Location: _____

Configuration:

Number of circuits (max 32) ... _____ (0-32)
Number of temp snsrs per ckt .. 6/12
Refrig relay control Suction/Liquid
Temperature dead band YES/NO
Defrost initiation TIME TIME/DIG
Defrost termination TIME/TMP TIME/DIG
Defrost restart YES/NO
Multi-case defrost term YES/NO
Hot gas defrost YES/NO
Pumpout phase YES/NO
Equalize phase YES/NO
Evap fan control YES/NO
Dewpoint controlled skip YES/NO
Digital alarm override YES/NO
Valve verification YES/NO

CIRCUIT WORKSHEET

Store #: _____ Location: _____

Setpoints:

Ckt #: _____ Description: _____

Cut-in setpt	___f	Cut-out setpt	___f
High alarm	___f	Low alarm	___f
Defr term	___f	Defr restart	___f
Evp fan start	___f		
Skip defr @dp	___f	Max dp skips	___

Refrig delay	___m	Alarm delay	___m
Pumpout time	___m	Defrost time	___m
Equalize time	___m	Evap fan dly	___m
Defrost start times:	___:___:___	___:___:___	___:___:___

Temp sensors	___	___	___	___	___	___
Alrm sensors	___	___	___	___	___	___
Term sensors	___	___	___	___	___	___

Case defr rlys	___	___	___	___	___
Suction relay	___	___	Liquid relay	___	___
Mastr HGas rly	___	___	Evap fan rly	___	___
Equalize relay	___	___	Alarm relay	___	___

Def vrfy inpts	___	___	___	___	___
Suct vrfy inpt	___	___	Liq vrfy inpt	___	___
Defr init inpt	___	___	Defr term inpt	___	___
Alrm ovrd inpt	___	___			
Rack number	___				

RACK WORKSHEET

Store #: _____ Location: _____

Configuration:

Number of racks (Max: 4) (0-4)
Variable speed YES/NO
Run verification YES/NO
Aux setpoints YES/NO
Temp controlled setpoints NO/SELECT/DEFAULT
Phase loss input YES/NO
Refrigerant liquid level NOT USED/ANALOG/DIGITAL
Defrost sense input NO/INTERNAL/EXTERNAL
Oil failure input YES/NO
Compr relay energized on YES/NO
Desuperheater Control YES/NO
Additional monitoring points .. YES/NO
TD head pressure control YES/NO
Two stage rack control YES/NO
Head Pressure Override YES/NO
Polarity of switchover relay .. EON/EOFF

RACK WORKSHEET

Store #: _____ Location: _____

Rack Setpoints:

Rack #: ____ Description: _____

Cut in	____p	____p
Cut out	____p	____p
Aux cut in	____p	____p
Aux cut out	____p	____p
Max cut in	____p	
High alarm	____p	____p
Low alarm	____p	____p
Head Override		____p
Shutdown	____p	
Alarm delay	____m	____m
Liquid Level Alrm	____%	
HR Override Level	____%	
HR Override Diff	____%	
HR Override Delay	____s	
Min on time	____s	____s
Min off time	____s	____s
Control gain	____	____
Derivative gain	____	____
Unit combinations	ALT/SEQ	SEQ/ALT
Pres sensor	____	____
Alarm relay	____	____
Ambient sensor	____	____
Drop leg sensor		____
Temp diff. cut in		____
Temp diff. offset		____
Anlg Liq. Lev. Snsr	____	
HR Override Relay	____	
Aux enable input	____	
Phase loss input	____	
Defrost sense input	____	
Oil failure input	____	

Compr	1	2	3	4	5	6	7	8
Relay	____	____	____	____	____	____	____	____
Capacity	____	____	____	____	____	____	____	____
Unloaders	____	____	____	____	____	____	____	____
Run inpt	____	____	____	____	____	____	____	____

Variable Speed Compressor:

Max rpm	_____	Min rpm	_____
Capacity	_____	Min oil pres	_____p
Analog output	__	Oil pres sensr	__
Freq sensr	__	Current sensr	__
Control relay	__	Reset relay	__
Switchovr relay	__	Fault input	__
Run input	__		

Fan	1	2	3	4	5	6
Relay	-	-	-	-	-	-
Run inpt	-	-	-	-	-	-

Power sensr	-	Max power	_____
Associated medium temperature rack			_____

RACK WORKSHEET

Store #: _____ Location: _____

Desuperheater Setpoints:

	Unit:	#1	#2
Cut-in setpoints	f	f	f
Dead bands (cut out)...	f	f	f
Desuperheater relays..	-	-	-
Temperature control on.	Highest temp/Average temp		
Manifold Sensors			
-	-	-	-
-	-	-	-
-	-	-	-
-	-	-	-
-	-	-	-
-	-	-	-

Monitor Only Setpoints:

Type	Assignments			
Temp snsr:	-	-	-	-
Low Press:	-	-	-	-
High Press:	-	-	-	-
Other snsr:	-	-	-	-
Dig Inputs:	-	-	-	-
Relay outp:	-	-	-	-
Analog out:	-	-	-	-

LEAK DETECT WORKSHEET

Store #: _____ Location: _____

Configuration:

Number of groups (Max: 4) _ (0-4)
Leak sensor type ANALOG/DIGITAL

Analog Setpoints:

Leak Sensors:	Alarm Setpt:
Sensor 1 - -	_____ ppm
Sensor 2 - -	_____ ppm
Sensor 3 - -	_____ ppm
Scale Factor: _____	ppm
Alarm Relay : - -	
Alarm Delay : _____	secs

Digital Input

Leak Input	: - -
Alarm Relay	: - -
Alarm Delay	: _____ secs

LOGIC STATEMENT WORKSHEET

Store #: _____ Location: _____

Unit: RC-1000

Statement # _____ Description: _____

IF Analog [____-____-____-____] (avg, max, min, any)
<,<=,==, Analog [____-____-____-____] (avg, max, min, spt)
>,>=,<>

OR,AND,XOR Digital [____-____-____-____] (or, xor, and, chg)
ON/OFF ON/OFF ON/OFF

OR,AND,XOR Ref Out [____-____-____-____] (or, xor, and, chg)
ON/OFF ON/OFF ON/OFF

THEN Dig Out [____-____-____-____] (nrm,lch,mty,chg,shd)
ON/OFF ON/OFF ON/OFF

Energized Is ON/OFF ON/OFF ON/OFF

True if count equals (min 2) _____

Sensor Type: Lo-T, Hi-T, 0-10v, Leak Setpoint _____
Lite, Lo-P, Hi-P, KW

Time Delay _____ Sec Min On _____ Sec

Log Alarm YES/NO Log Event YES/NO

Message (10 chars) _____

Scale Fact: _____

Clear Latch Input ____-____

Logic is on from ____:____ to ____:____

ALARM DIAL OUT WORKSHEET

Store #: _____ Location: _____

Dial Out Phone Numbers:

Group 1

Unoccupied Phone #s	Occupied Phone #s
> _____	> _____
> _____	> _____
> _____	> _____

Occupied Schedule

Sun From: __: __	To: __: __
Mon From: __: __	To: __: __
Tue From: __: __	To: __: __
Wed From: __: __	To: __: __
Thu From: __: __	To: __: __
Fri From: __: __	To: __: __
Sat From: __: __	To: __: __

Group 2

Unoccupied Phone #s	Occupied Phone #s
> _____	> _____
> _____	> _____
> _____	> _____

Occupied Schedule

Sun From: __: __	To: __: __
Mon From: __: __	To: __: __
Tue From: __: __	To: __: __
Wed From: __: __	To: __: __
Thu From: __: __	To: __: __
Fri From: __: __	To: __: __
Sat From: __: __	To: __: __

Miscellaneous Dial Out Parameters


Device ID: _____
Dial Test Choice: _____
Modem Cmd: _____
Retry Dialing in (0-24): ____ Hrs
Daily Dialout Grp1 1: ____:____ 2: ____:____
Daily Dialout Grp2 1: ____:____ 2: ____:____
Group 1 Name: _____
Group 2 Name: _____

SYSTEM MISCELLANEOUS CONFIGURATION

Communication ID _____
Temp units F/C _____ Line Freq 50/60H
Logging interval ____s
Baud 1200/2400

MANUAL OVERRIDE SWITCH

SW POS		TEMP	DEFROST	ALARM	COMP	COND	FANS
DE-ENGZ	ON	ON	OFF	IN ALARM	ON	ON	ON
ENRGZ	OFF	ON	ON	NO ALARM	OFF	OFF	OFF




RED COIL LIGHT
-LIT WHEN ENERGIZED.

YELLOW OVERRIDE LIGHT
-LIT WHEN NOT IN "AUTO".

MODULAR QUICK-CONNECT RJ-11 STYLE
CABLES SUPPLIED BY EIL.
(PN 5001637400)

LIT LED INDICATES
RELAY ENERGIZED


COMMON FUSED ON EACH RELAY.
3A @ 240VAC STANDARD



RELAY DRIVER BOARDS

- A = RELAYS 1 thru 4
- B = RELAYS 5 thru 8
- C = OVERRIDE FEEDBACK 1 thru 4
- D = OVERRIDE FEEDBACK 5 thru 8

TYPICAL COMPRESSOR INTERFACE



RATINGS:

RELAY COIL 12VDC

CONTACTS 10A @ 120VAC

5A @ 240VAC

BOARD POWER: 1A @ 12VAC
UL APPROVED FOR 480VA PILOT DUTY

RC-1000 RELAY INTERFACE DIAGRAM

FIGURE 1




FIGURE 2




FIGURE 3

RC-1000 ANALOG INPUT INTERFACE DIAGRAM





FIGURE 4

RC-1000 MTG. & PWR. HOOKUP DIAGRAM




TF-5 TRANSFORMER

NOTE:

1. THE TF-5 TRANSFORMER IS NOW APPROVED FOR CPU POWER WHICH REQUIRES ONLY ONE 12VAC POWER SOURCE.
2. THE SAME TRANSFORMER SHOULD NOT BE USED TO POWER BOTH CPU AND RELAY BOARDS.
3. FUSE TRANSFORMER PER ELECTRICAL CODE REQUIREMENTS.

240/208 VAC CONFIGURATION:



120 VAC CONFIGURATION





FIGURE 5

RC-1000 CPU AND I/O POWER HOOKUP (TF-5)




ITEM	DES	DESCRIPTION	EIL PART NO.	QTY.
2		WIRE, 6 COND. FLAT PHONE CABLE	6201600100	A/R
1		CONN. MODULAR TYPE RJ-11	0960905900	2
		ASSY. RELAY INTERCONN CABLE	CC/01637400	
PARTS LIST				

1. WITH TAB FACING TOWARDS YOU, INSTALL CABLE WITH "WHITE" CONDUCTOR ON RIGHT, FOR BOTH ENDS.
2. P/N CC/016374-02 IS PER FOOT, DETERMINED BY CUSTOMERS SPECIFICATIONS.

PHONE CABLE ASSEMBLY

FIGURE 6




CC/A12080 FOR 208V APPLICATION
CC/A12081 FOR 480V APPLICATION
WATT TRANSDUCER

NOTE: WHEN USING EIL SUPPLIED CT'S, ORIENT HI TOWARD THE LINE SIDE OF THE CIRCUIT.

WARNING: NEVER OPEN C.T. SECONDARIES WHILE THE C.T. PRIMARY IS CARRYING LOAD. THIS MAY RESULT IN EXPLOSION.

RC-1000 RACK POWER MONITORING


FIGURE 7



RC-1000 SAMPLE LAYOUT CONFIGURATION

TYPICAL COMMUNICATIONS HOOKUP

HAYES MODEM




NOTE: THE MAXIMUM LENGTH FOR ALL CABLES IS 200 FEET, CONSULT FACTORY IF LONGER CABLE LENGTH IS NEEDED.

FIGURE 9

STORE COMMUNICATIONS TO RC-1000

DESKTOP OR LAPTOP COMPUTER



HAYES MODEM




25 PIN ADAPTOR CC/01686400
OR
9 PIN ADAPTOR CC/01687400

TO SERIAL
PORT ON P.C.


DISCONNECT MODEM FROM CPU DURING PC DIRECT COMMUNICATIONS

INCOMING PHONE LINE


CC/01665400 MODEM
ADAPTOR (VER 2.0+)



RC-1000
#1



RC-1000
#2



RC-1000 CPU BOARD
TYPICAL P.C. DIRECT COMMUNICATIONS HOOKUP


CC/01637400 (10FT) OR
CC/01637401 (20 FT) OR
CC/01637402 (PER FT)

TO OTHER
RC-1000'S

P.C. DIRECT STORE COMMUNICATIONS TO RC-1000

VERSION 2.0+

FIGURE 10



NOTE: THE MAXIMUM LENGTH FOR ALL CABLES IS 200 FEET, CONSULT FACTORY IF LONGER CABLE LENGTH IS NEEDED.

ALL UNMARKED CABLES ARE EITHER
CC/01637400 (10 FT.) OR
CC/01637401 (20 FT.) OR
CC/01637402 (PER FT.)

FIGURE 11

STORE COMMUNICATIONS WHEN COM-99 IS PRESENT




FIGURE 12


NOTE:
CONSULT INVERTER USER'S
MANUAL FOR ADDITIONAL
INFORMATION.

INVERTER INTERFACE DIAGRAM

MODULAR QUICK-CONNECT RJ-11 STYLE
CABLES SUPPLIED BY EIL.
(PN 5001637400)

LIT LED INDICATES
RELAY ENERGIZED

COMMON FUSED ON EACH RELAY.
3A @ 240VAC STANDARD




1A
12VAC
FUSE

12 VAC
FROM EIL TF-5
OR OTHER 12 VAC,
1 AMP SOURCE.

UP TO 200 FEET

RELAY DRIVER BOARDS

- A = RELAYS 1 thru 4
- B = RELAYS 5 thru 8
- C = OVERRIDE FEEDBACK 1 thru 4
- D = OVERRIDE FEEDBACK 5 thru 8



RATINGS: RELAY COIL 12VDC


CONTACTS 10A @ 120VAC

5A @ 240VAC


BOARD POWER: 1A @ 12VAC

UL APPROVED FOR 480VA PILOT DUTY

120 VAC CONFIGURATION



240/208 VAC CONFIGURATION:



NOTE:
1. FUSE TRANSFORMER PER ELECTRICAL CODE REQUIREMENTS.

RC-1000 RELAY BOARD POWER HOOKUP (TF-5)

FIGURE 14



RECOMMENDED POWER HOOKUP

P/N CC/60030400




FIGURE 16

COM INTERFACE

P/N #CC/01666400 (PRE VER. 2.0)
P/N #CC/01666401 (VER 2.0+)

TYPICAL P.C. DIRECT COMMUNICATIONS HOOKUP



HAYES MODEM

(HAYES SWITCHES
5,7,10 UP)
(SMARTMODEM 1200 ONLY)

INCOMING PHONE
LINE

CC/01665400
INTERFACE ADAPTOR
(MALE)

MODEM (SEE NOTE)

TO SERIAL PORT ON P.C.
CC/01665400 OR CC/01683400
INTERFACE ADAPTOR (MALE)

CC/01665401
INTERFACE ADAPTOR
(FEMALE)

THIS WIRE IS RUN INTERNAL
TO RC-1000 AT FACTORY.

COM-99

RC-1000 #1

ALL UNMARKED CABLES ARE EITHER
CC/01637400 (10 FT.) OR
CC/01637401 (20 FT.) OR
CC/01637402 (PER FT.)

NOTE:
DISCONNECT MODEM CABLE DURING
P.C. DIRECT COMMUNICATIONS.

P.C. DIRECT STORE COMMUNICATIONS WHEN COM-99 IS PRESENT
VERSION 3

FIGURE 17

2/C #18 GA. SHIELDED
CONTROL CABLE


SUPPLY & RETURN AIR
SENSOR MOUNTING

USE CLAMP TO MOUNT
SENSOR ON CHASSIS

EVAPORATOR SENSOR MOUNTING

USE THERMOCONDUCTIVE
SEALANT & CLAMP TO MOUNT
SENSOR ON EVAPORATOR PIPING.

REFRIGERATION CASE




NOTES:

- 1.) NEVER RUN TEMPERATURE SENSOR WIRING
IN THE SAME RACEWAY WITH POWER WIRING.
- 2.) SENSOR MUST BE LOCATED IN AIRSTREAM.

RC-1000 CASE SENSOR INSTALLATION

FIGURE 18



NOTES:

- 1.) RELAY IS CONTROL TYPE, STEVECO 90-292 OR SIMILAR.
- 2.) IF LOAD IS ON, RELAY WILL ENERGIZE & PROVIDE CONTACT CLOSURE FOR DIGITAL INPUT ON EC/RC-1000
- 3.) COIL RATING TO MATCH LOAD VOLTAGE BEING MONITORED.

EC/RC-1000 HIGH VOLTAGE TO DRY
CONTACT INTERFACE FOR PROOFING

FIGURE 19




FIGURE 20

TYPICAL BLOCK DIAGRAM ENERGY MGMT. SYSTEM




FIGURE 21

NOTES:

- 1.) RA-2 MOUNTED IN STORE FRONT OFFICE.

RA-2 ALARM PANEL WIRING DIAGRAM






FIGURE 22

RC-1000 PANEL MOUNTING DIAGRAM (OEM UNITS)




LIQUID LEVEL INTERFACE HOOKUP DIAGRAM

FIGURE 23




CPU IDENTIFICATION DIAGRAM

FIGURE 24



REFRIGERANT LEAK TRANSDUCER WIRING DIAGRAM (FOR EIL PART NUMBER CC/01680401 "0-10V INPUT")

FIGURE 25




EIL PART # CC/01679400

NOTE:

1. THE TF-5 TRANSFORMER IS NOW APPROVED FOR CPU POWER WHICH REQUIRES ONLY ONE 12VAC POWER SOURCE.
2. THE SAME TRANSFORMER SHOULD NOT BE USED TO POWER BOTH CPU AND RELAY BOARDS.

120 VAC CONFIGURATION



RC-1000 CPU AND I/O POWER HOOKUP

12VAC POWER SUPPLY

FIGURE 26




FIGURE 27

WATT TRANSDUCER 2 ELEMENT CONNECTION FOR A12080 AND A12081





FIGURE 28

WATT TRANSDUCER 2 1/2 ELEMENT CONNECTION FOR A12083 AND A12084



0-5V LIQUID LEVEL CAPACITANCE TRANSDUCER TO RC-1000 ANALOG PRESSURE WIRING DIAGRAM

FIGURE 29

