

- . Liquid Return Lines must be free draining with no Traps
- Install Solenoid Valves inside Equipment Room
- . Pump down Line should not enter the Suction Manifold over a Compressor Inlet
- Install Ball Valves to isolate condenser
- · All Inter-connecting Valving to be Field Supplied and Installed