

GENERAL

DRAWING INDEX	1-1
INSTALLATION GUIDELINES	1-2
MCS-4000 CONTROLLER	1-3
COM-5002 COMMUNICATION INTERFACE	1-4
ADV-6000 COMMUNICATION INTERFACE	1-5
4K2e CONTROLLER	1-6

MOUNTING INFORMATION

MCS-4000, 4K2e & COM-5002 DEEP BOX	2-1
MCS-4000, 4K2e & COM-5002 SHALLOW BOX	2-1
MCS-4000, 4K2e & COM-5002 SURFACE MOUNT FRAME	2-2
I/O CARD HOLDER	2-3
2-I/O CARD ENCLOSURE	2-4
ADV-6000 COMMUNICATION INTERFACE	2-5

POWER WIRING

24VAC TRANSFORMER FOR (1) I/O CARD	3-1a
24VAC TRANSFORMER FOR (5) I/O CARDS	3-1b
24VAC TRANSFORMER FOR (8) I/O CARDS	3-1c
24VAC TRANSFORMER FOR (10) I/O CARDS	3-1d
480V/240V PRIMARY TRANSFORMER	3-1e
MCS-4000, 4K2e & COM-5002 DEEP BOX	3-2
MCS-4000, 4K2e & COM-5002 SHALLOW BOX	3-3
MCS-4000, 4K2e & COM-5002 SURFACE MOUNT FRAME	3-3
I/O CARDS	3-4
2-I/O CARD ENCLOSURE	3-5
OPEN	3-6
OPEN	3-7
ADV-6000 UPS / SURGE PROTECTOR	3-8
COM-5002 BATTERY BACKUP UNIT	3-9

COMMUNICATION WIRING

GLOBAL BUS : MCS-4000 & 4K2e CONTROLLER	4-1
GLOBAL BUS : COM-5002 INTERFACE	4-2
GLOBAL BUS : ADV-6000 INTERFACE	4-3
OPEN	4-4
LOCAL BUS : I/O CARDS	4-5
LOCAL BUS : MCS-4000 & 4K2e CONTROLLER	4-6
LOCAL BUS : 2-I/O ENCLOSURE	4-7
OPEN	4-8
OPEN	4-9
OPEN	4-10
OPEN	4-11
DIRECT CONNECT (OLD STYLE) FROM PC TO 4K & 4K2e	4-12
DIRECT CONNECT FROM PC TO COM-5002	4-13
DIRECT CONNECT FROM PC TO ADV-6000	4-14
SELF POWERED RS232/RS485 KIT	4-15
4K2e "DATABASE" UPLOAD INTERCONNECT	4-16
4K2e "PROGRAM" UPLOAD INTERCONNECT	4-17

ALARM WIRING

MCS-4000 & 4K2e DEEP BOX/REMOTE AUDIBLE	5-1
MCS-4000 & 4K2e SHALLOW BOX/REMOTE AUDIBLE	5-2
MCS-4000 & 4K2e SURFACE MOUNT/REMOTE AUDIBLE	5-2
COM-5002 DEEP BOX/REMOTE AUDIBLE	5-3
COM-5002 SHALLOW BOX/REMOTE AUDIBLE	5-4
COM-5002 SURFACE MOUNT/REMOTE AUDIBLE	5-4
OPEN	5-5
ADV-6000/REMOTE AUDIBLE	5-6
COM-5002 DEEP BOX/ALARM PRINTER	5-7
COM-5002 SHALLOW BOX/ALARM PRINTER	5-8
COM-5002 SURFACE MOUNT/ALARM PRINTER	5-8
ADV-6000/ALARM PRINTER	5-9
MCS-4500 ALARM RECEIVER	5-10

ADDRESSING

I/O CARD ADDRESS SWITCH	6-1
MCS-4000 CONTROLLER SETTINGS	6-2
OPEN	6-3
I/O CARD SWITCH SETTINGS FOR SENSOR INPUTS	6-4
4K2e CONTROLLER SETTINGS	6-5

I/O CARD TERMINATIONS

TECHNICAL INFORMATION FOR DIGITAL INPUTS	7-1
RELAY OUTPUT CARD 8-CHANNEL	7-2
DIGITAL INPUT CARD 8-CHANNEL	7-3
ANALOG INPUT CARD 8-CHANNEL	7-4
ANALOG INPUT CARD 16-CHANNEL	7-5
ANALOG OUTPUT CARD 4-CHANNEL	7-6
RTU I/O CARD	7-7
CIO CARD	7-8
SOLID STATE RELAY OUTPUT CARD	7-9
PULSEMETER ADAPTER INPUT CARD	7-10

CASE/SENSOR MOUNTING

SINGLE DECK CASES	8-1
MULTI DECK CASES	8-2
CASE TEMPERATURE SENSOR MOUNTING DISK	8-3

SENSOR INSTALLATION AND WIRING

DIGITAL INPUT MODULES	9-1
PRESSURE TRANSDUCERS	
ECLIPSE (0-5V SIGNAL)	9-2
SENSYM (1-6V SIGNAL)	9-3
OPEN	9-4
FREON SENSOR	9-5
INDOOR (ZONE) TEMP SENSOR (HANDY BOX MOUNT STYLE)	9-6
OUTDOOR TEMPERATURE SENSOR	9-7
CASE TEMPERATURE SENSORS	9-8
HVAC SUPPLY AIR AND RETURN AIR TEMP SENSORS	9-9
LIGHT SENSORS	9-10
DEW POINT SENSOR	9-11
HVAC DIFFERENTIAL PRESSURE SWITCH	9-12
OUTDOOR TEMP/LIGHT SENSOR MODULE WIRING	9-13
OUTDOOR TEMP/LIGHT SENSOR MODULE MOUNTING	9-14
COOLER BOX TEMPERATURE SENSOR	9-15
COOLER BOX TEMP SENSOR - TWO WAY BLOWER	9-16
INDOOR RELATIVE HUMIDITY/TEMP SENSOR (COM-TROL)	9-17
OUTDOOR RELATIVE HUMIDITY/TEMP SENSOR (COM-TROL)	9-18
INDOOR RELATIVE HUMIDITY/TEMP SENSOR (INVENSYNS)	9-19
INDOOR TEMP SENSOR WITH SETPOINT ADJUSTMENT	9-20
INDOOR (ZONE) TEMP SENSOR (ENCLOSED BOX STYLE)	9-21

MISCELLANEOUS EQUIPMENT

ANTISWEAT INTERFACE PANEL - RISER DIAGRAM	10-1
ANTISWEAT INTERFACE PANEL - TERMINATIONS	10-2
MCS-4500 RACK CONTROLLER - MOUNTING & WIRING	10-3
MCS-4500 HVAC INTERFACE (TRANE VOYAGER) - MOUNTING	10-4
MCS-4500 HVAC INTERFACE (TRANE VOYAGER) - WIRING	10-5
REFRIGERANT MANAGEMENT SCALE	10-6
10-I/O CARD ENCLOSURE (WITHOUT CONTROLLER)	10-7
10-I/O CARD ENCLOSURE (WITH 4K & 4K2e CONTROLLERS)	10-8
10-I/O CARD ENCLOSURE (WITH MCS-4500 CONTROLLER)	10-9
5-I/O CARD ENCLOSURE (WITHOUT CONTROLLER)	10-10
5-I/O CARD ENCLOSURE (WITH 4K & 4K2e CONTROLLERS)	10-11
5-I/O CARD ENCLOSURE (WITH MCS-4500 CONTROLLER)	10-12
MCS-4500 LIGHTING INTERFACE (SQUARE-D GEN-3)	10-13
MCS-4500 HVAC INTERFACE (CARRIER PREMIER/CENTURION)	10-14
IR-4500 REFRIGERANT LEAK DETECTION PANEL (RISER VIEW)	10-15
IR-4500 REFRIGERANT LEAK DETECTION PANEL (TERMINATIONS)	10-16

CONFIDENTIAL, PROPRIETARY

MATERIAL AND INFORMATION THAT IS THE SOLE PROPERTY OF COM-TROL.
UNAUTHORIZED USE OR DISCLOSURE OF THE CONTENTS IS STRICTLY FORBIDDEN.
COPYRIGHT © 2004 Com-Trol, All Rights Reserved



MCS-4000 AND 4K2e
CONTROL SYSTEMS

TITLE	ENERGY MANAGEMENT SYSTEM DRAWING INDEX						
DWG. NO.	945001BH01	REV.	K	DATE	2-16-04	SHEET	1-1